Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Azwok CT-95024 CT-95022

Azwok CT-95024 CT-95022 Voice Remote Control User Manual

Model: CT-95024, CT-95022

Introduction

This manual provides instructions for the Azwok CT-95024 and CT-95022 Voice Remote Control, designed as a replacement for various Toshiba LED TV models. This remote control offers essential functions and voice control capabilities, ensuring a seamless user experience. Please read this manual carefully before using your new remote control.

Setup

Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Pairing Instructions

This remote control is designed for effortless pairing with compatible Toshiba LED TVs. The exact pairing procedure may vary slightly depending on your specific TV model. Generally, the steps involve:

1. Ensure your Toshiba TV is powered on.
2. Point the remote control towards the TV.
3. Press and hold the **Home** button and the **Back** button simultaneously for a few seconds (typically 3-5 seconds).
4. A pairing message should appear on your TV screen, indicating that the remote is attempting to connect.
5. Once successfully paired, a confirmation message will be displayed.

If pairing is unsuccessful, ensure there are no obstructions between the remote and the TV, and try again. Refer to your Toshiba TV's original user manual for specific pairing instructions if needed.

Operating Your Remote Control

Basic Functions

The remote control provides standard functions for navigating your Toshiba LED TV:

- **Power Button:** Turns the TV on or off.
- **Volume Up/Down:** Adjusts the TV's volume level.
- **Channel Up/Down:** Changes TV channels.
- **Mute Button:** Mutes or unmutes the TV audio.
- **Input/Source Button:** Selects different input sources (HDMI, AV, etc.).
- **Navigation Buttons (Up, Down, Left, Right):** Moves cursor or selection on screen.
- **OK/Enter Button:** Confirms selections or opens menus.
- **Back Button:** Returns to the previous screen or menu.
- **Home Button:** Accesses the TV's main smart TV interface or home screen.

Voice Control Feature

This remote control supports voice search functionality. To use voice control:

1. Press the dedicated **Voice** button (often indicated by a microphone icon) on the remote.
2. Hold the remote control close to your mouth and speak your command clearly.
3. Release the Voice button when you have finished speaking.

Examples of voice commands include:

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FHZJ7KKJ

More documents and user manuals: **https://manuals.plus/**