Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZWP EARC15RSE1, EARC10RSE1, EARC6RSE1, EARC5RD1, EARC8RSE1, EARC12RE1

ZWP Replacement Remote Control User Manual

For Emerson Quiet Kool Smart Window Air Conditioners

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your ZWP replacement remote control. This remote is specifically designed to be compatible with the following Emerson Quiet Kool Smart Window Air Conditioner models:

- EARC15RSE1
- EARC10RSE1
- EARC6RSE1
- EARC5RD1
- EARC8RSE1
- EARC12RE1

Please read this manual carefully to ensure proper use and to maximize the lifespan of your remote control.

2. Product Overview

The ZWP replacement remote control is engineered for durability and ease of use, featuring a comfortable design and responsive buttons.



Figure 2.1: Front view of the ZWP replacement remote control.



Figure 2.2: The remote control is constructed from high-quality ABS material with soft silicone buttons for comfortable operation and durability.



Figure 2.3: Close-up view of the remote control's LCD display and primary function buttons.

3. Setup: Battery Installation

The remote control requires two AAA batteries (not included) for operation. No programming is required; simply insert the batteries, and the remote will be ready to use.

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two new AAA batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.



Figure 3.1: Illustration of battery installation in the remote control. Requires two AAA batteries (not included).

4. Operating Instructions

Point the remote control directly at the air conditioner unit. The effective operational distance is approximately 8 meters (26 feet).



Figure 4.1: The remote control has an operational distance of up to 8 meters.

Button Functions:

- **ON/OFF (Power Button):** Press to turn the air conditioner on or off.
- **MODE:** Cycles through available operating modes (e.g., Auto, Cool, Dry, Fan, Heat).
- **Temperature Up (▲):** Increases the set temperature.
- **Temperature Down (▼):** Decreases the set temperature.
- **ECO:** Activates or deactivates the energy-saving ECO mode.
- **SLEEP:** Engages the sleep mode for quiet operation and adjusted temperature settings during sleep.
- **DISPLAY:** Toggles the display on the air conditioner unit.
- **FAN:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).
- **TIMER:** Sets the timer for automatic on/off operations.

5. Maintenance

Cleaning:

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the remote's finish or internal components.

Battery Replacement:

Replace batteries when the remote's performance diminishes or the display becomes dim. If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

6. Troubleshooting

Problem	Possible Cause	Solution
Remote control not responding.	Dead or incorrectly inserted batteries.	Replace batteries with new AAA batteries, ensuring correct polarity.
Remote control has limited range.	Obstruction between remote and AC unit; low battery power.	Ensure a clear line of sight to the AC unit. Replace batteries if they are low.
Air conditioner not responding to commands.	Remote control not compatible with AC unit; AC unit power issue.	Verify your AC model is listed as compatible. Check if the AC unit is powered on and functioning correctly.

7. Specifications

- **Brand:** ZWP
- **Compatible Devices:** Emerson Quiet Kool Smart Window Air Conditioners (Models: EARC15RSE1, EARC10RSE1, EARC6RSE1, EARC5RD1, EARC8RSE1, EARC12RE1)
- **Power Source:** 2 x AAA Batteries (not included)
- **Material:** High-quality ABS with soft silicone buttons
- **Color:** White
- **Special Feature:** Ergonomic design
- **Max Number of Supported Devices:** 1
- **Operational Distance:** Approximately 8 meters (26 feet)
- **Item Weight:** 2.08 ounces (approx. 59 grams)
- **Package Dimensions:** 7.4 x 2.5 x 1.1 inches (approx. 18.8 x 6.35 x 2.8 cm)

8. Support

For any questions, concerns, or assistance regarding your ZWP replacement remote control, please do not hesitate to contact the seller directly. We are committed to helping you resolve any issues you may encounter.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJ1T7DV9

More documents and user manuals: **https://manuals.plus/**