libovgogo DF-589

libovgogo Emergency Weather Radio DF-589: Instruction Manual

Model: DF-589

1. Product Overview

The libovgogo DF-589 is a versatile emergency weather radio designed for outdoor activities and emergency preparedness. It combines multiple essential functions into a compact, durable, and waterproof device, ensuring you stay informed and connected in various situations.



Figure 1: libovgogo Emergency Weather Radio DF-589

2. Key Features

- **NOAA/AM/FM Weather Radio:** Provides real-time weather alerts and broadcasts.
- **IPX5 Waterproof:** Designed to withstand heavy rain and splashes.
- **Portable Bluetooth Speaker:** Allows wireless music streaming.
- **Multiple Power Sources:** USB-C charging, solar panel, and hand crank for versatile power.
- **2000mAh Power Bank:** Can charge mobile phones and other devices in emergencies.
- **Dual-Mode Flashlight:** 0.7W 100LM flashlight with normal and flash modes.
- **SOS Alarm:** Activates a loud 95dB alarm and bright flashing red light for emergencies.
- **Durable Construction:** Dual-layer ABS+TPU for accidental drops and harsh environments.

3. Package Contents

- libovgogo Emergency Weather Radio (DF-589)

- USB-C Charging Cable
- Owner's Manual
- Belt Clip

4. Product Diagram

Figure 2: Detailed view of the radio's components and controls.

5. Setup

5.1 Initial Charging

Before first use, fully charge the radio using the provided USB-C cable. Connect the USB-C end to the radio's charging port and the USB-A end to a compatible power adapter (not included).

5.2 Antenna Extension

For optimal radio reception, extend the telescopic antenna fully when using AM/FM/NOAA functions.

6. Operating Instructions

6.1 Power On/Off

- To turn on: Press and hold the **Power button** () for 2-3 seconds.
- To turn off: Press and hold the **Power button** again for 2-3 seconds.

6.2 Radio Operation (AM/FM/NOAA)



Figure 3: Radio display showing frequency and battery level.

- **Mode Selection:** Press the **M button** to cycle through Bluetooth (BT), FM, AM, Weather Band (WB), and NOAA modes.
- **Automatic Search:** In FM or AM mode, press and hold the**M button** to automatically scan and save available stations.
- **Manual Tuning:** Use the **<** and **>** buttons to manually tune to specific frequencies.
- **Volume Adjustment:** Use the **+** and **-** buttons to adjust the volume.
- **NOAA Weather Alert:** In NOAA mode, the radio will automatically receive and alert you to severe weather or hazardous warnings.

6.3 Bluetooth Speaker Function

Your browser does not support the video tag.

Video 1: Demonstrates connecting the libovgogo Emergency Weather Radio to a smartphone via Bluetooth and playing music.

- **Pairing:** Switch the radio to Bluetooth (BT) mode. The display will show "BLUE". Enable Bluetooth on your smartphone or device and select "DF-589W" from the list of available devices.
- **Music Playback:** Once paired, you can play music from your device through the radio's speaker. Use the

radio's **Power button** to play/pause, and the **<** and **>** buttons to skip tracks.

- **Volume Control:** Adjust volume using the **+** and **-** buttons on the radio or your connected device.

6.4 Flashlight Operation



Figure 4: Flashlight in use and SOS alarm feature.

- **Turn On/Off:** Press the dedicated **Flashlight button** (usually located near the flashlight lens) once for normal steady light.
- **Strobe Mode:** Press the **Flashlight button** a second time to activate the flashing strobe mode.
- **Turn Off:** Press the **Flashlight button** a third time to turn off the flashlight.

6.5 SOS Alarm

- **Activation:** Press and hold the **SOS button** (located on the side/bottom) for 2-3 seconds to activate the loud 95dB alarm and flashing red light.
- **Deactivation:** Press the **SOS button** briefly to turn off the alarm.

6.6 Charging the Device



Figure 5: Three ways to charge the emergency radio.

- **USB-C Charging:** Connect the provided USB-C cable to the radio's USB-C input port and a power source. The battery indicator on the display will show charging status.
- **Solar Charging:** Place the radio with the solar panel facing direct sunlight. This method is primarily for maintaining battery life and is not recommended for full charging in emergencies.
- **Hand Crank Charging:** Unfold the hand crank and rotate it clockwise or counter-clockwise at a steady pace (approximately 130-150 rotations per minute). Cranking for 30 minutes can provide approximately 200mAh of power.

6.7 Power Bank Function




Figure 6: Using the radio as a power bank to charge a phone.

- The built-in 2000mAh battery can act as an emergency power bank.
- Open the port cover and connect your device's charging cable to the radio's USB-A output port.
- This function is designed for emergency charging of mobile phones or other small devices during power outages.

7. Maintenance

- **Cleaning:** Wipe the device with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the radio in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery health, fully charge the device at least once every three months, even if not in use.

8. Troubleshooting

Problem	Possible Cause	Solution
Radio does not power on.	Low battery.	Charge the radio using USB-C, solar, or hand crank.
Poor radio reception.	Antenna not extended, weak signal.	Extend the telescopic antenna fully. Try moving to an open area.
Bluetooth not connecting.	Radio not in BT mode, device not discoverable.	Ensure radio is in BT mode. Check your device's Bluetooth settings.
Flashlight not working.	Low battery, button not pressed correctly.	Charge the radio. Press the flashlight button firmly.
External device not charging.	Low radio battery, incorrect cable.	Ensure radio has sufficient charge. Use a compatible USB cable.

9. Specifications

- **Model:** DF-589
- **Product Dimensions:** 5 x 1 x 2 inches
- **Item Weight:** 9.3 ounces
- **Battery:** 2000mAh Nonstandard Battery (included)
- **Input:** 5V === 1.5A (USB-C)
- **Connectivity Technology:** Bluetooth 5.0
- **Tuner Technology:** AM-FM, NOAA Weather Band (7-Band)
- **Special Feature:** SOS Alarm, Flashlight (0.7W 100LM), Solar Charging, Hand Crank Charging, IPX5 Waterproof

10. Warranty and Support

This libovgogo Emergency Weather Radio is backed by a**365-day warranty** against manufacturing defects.
If you have any questions or encounter issues with your radio, please contact us via the "Buyer Message" feature on Amazon. We are committed to providing immediate solutions and support.

© 2026 libovgogo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question