Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Simfer SM 8679

Simfer SM 8679 Built-in Stainless Steel Range Hood User Manual

Model: SM 8679

1. Introduction

Thank you for choosing the Simfer SM 8679 Built-in Stainless Steel Range Hood. This manual provides essential information for the safe installation, operation, and maintenance of your appliance. Please read these instructions carefully before use and keep them for future reference.

2. Safety Information

To ensure safe operation, please observe the following safety precautions:

- Ensure the appliance is installed by a qualified technician.
- Always disconnect the power supply before cleaning or performing maintenance.
- Do not flambé under the range hood.
- Ensure adequate ventilation in the room when the range hood is used simultaneously with gas or other fuel-burning appliances.
- Regularly clean grease filters to prevent fire hazards.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. Product Overview

The Simfer SM 8679 is a 60cm built-in stainless steel range hood designed to integrate seamlessly into your kitchen cabinetry. It features a powerful extraction system, adjustable speed settings, and efficient lighting to enhance your cooking experience.

Key Features:

- Stainless steel exterior provides a modern and durable design.
- 3 adjustable speeds to suit various cooking requirements.
- Mechanical push-button controls for easy and reliable use.
- Operates at a low noise level of 58 dB(A).
- Dishwasher-safe aluminum cassette filters for easy, hassle-free care.
- Two 50-watt halogen lamps for optimal hob illumination.
- Airflow capacity of 650 m^3/h.



Figure 1: Simfer SM 8679 Built-in Stainless Steel Range Hood. This image shows the sleek silver finish and integrated design of the appliance.

4. Setup & Installation

Installation of the Simfer SM 8679 range hood should be performed by a qualified professional to ensure proper functioning and safety. The unit is designed for wall-mounted installation and can operate in ductless/recirculation mode.

General Installation Guidelines:

1. **Unpacking:** Carefully remove the range hood from its packaging and check for any damage. Retain packaging materials for potential future transport.
2. **Mounting:** Securely mount the range hood to the wall above your cooking surface, ensuring it is at the recommended height (refer to specific installation diagrams in the full instruction manual, not provided here).
3. **Electrical Connection:** Connect the appliance to a 220V power supply. Ensure all electrical connections comply with local regulations.
4. **Ventilation (Recirculation Mode):** If using in recirculation mode, ensure the charcoal filters are installed (sold separately, if not included) and that air outlets are clear.
5. **Final Checks:** After installation, test all functions (fan speeds, lighting) to ensure correct operation.

For detailed installation instructions, please refer to the comprehensive manual included with your product.

5. Operating Instructions

The Simfer SM 8679 range hood features mechanical push-button controls for straightforward operation.

Controls:

- **Fan Speed Buttons:** Press the corresponding button to select one of the three fan speeds (Speed 1, Speed 2, Speed 3). Speed 1 is suitable for light cooking, while Speed 3 is for intense frying or strong odors.
- **Light Button:** Press the light button to turn the halogen lamps on or off, illuminating your cooking area.
- **Off Button:** Press the off button to turn off the fan.

Usage Tips:

- Turn on the range hood a few minutes before you start cooking to create an airflow.
- Allow the range hood to run for approximately 10-15 minutes after cooking to clear any remaining steam or odors.
- Adjust the fan speed according to the intensity of cooking.

6. Maintenance

Regular maintenance ensures the longevity and optimal performance of your range hood.

Cleaning the Grease Filters:

The aluminum cassette filters collect grease particles and should be cleaned regularly (approximately every 2-4 weeks, depending on usage) to prevent fire hazards and maintain extraction efficiency.

1. **Disconnect Power:** Always switch off and unplug the appliance before cleaning.
2. **Remove Filters:** Locate the filter release latches, push them, and carefully pull down the filters.
3. **Clean Filters:** The filters are dishwasher-safe. Alternatively, wash them by hand in hot water with a mild detergent. Rinse thoroughly and allow them to dry completely before reinstallation.
4. **Reinstall Filters:** Insert the dry filters back into their slots until they click into place.

Cleaning the Exterior:

Clean the stainless steel exterior with a soft cloth and a non-abrasive stainless steel cleaner. Avoid using abrasive pads or harsh chemicals that could scratch the surface.

Replacing Halogen Lamps:

If a halogen lamp needs replacement:

1. **Disconnect Power:** Ensure the appliance is unplugged and the lamps have cooled down.
2. **Remove Cover:** Carefully remove the lamp cover (if applicable).
3. **Replace Bulb:** Unscrew the old halogen bulb and replace it with a new 50-watt halogen bulb of the same type.
4. **Reattach Cover:** Securely reattach the lamp cover.

7. Troubleshooting

Before contacting customer service, please check the following common issues:

Problem	Possible Cause	Solution
Range hood does not start.	No power supply; plug not inserted; fuse blown.	Check power connection; insert plug firmly; check/replace fuse.
Poor extraction performance.	Grease filters are dirty; incorrect fan speed; obstruction in air duct (if ducted).	Clean grease filters; select higher fan speed; check for obstructions.
Excessive noise.	Loose components; fan blades obstructed; incorrect installation.	Check for loose parts; ensure fan blades are clear; contact a technician for installation check.
Lights not working.	Bulb faulty; power issue.	Replace faulty bulb; check power supply.

8. Specifications

Feature	Detail
Brand	Simfer
Model Number	SM 8679
Product Dimensions (D x W x H)	45 cm x 60 cm x 20 cm
Color	Silver
Material	Stainless Steel
Airflow Capacity	650 m^3/h
Noise Level	58 dB(A)
Number of Speeds	3
Control Type	Push Button
Light Source	Halogen (2 x 50W)

Feature	Detail
Special Features	Grease Filter
Installation Type	Wall Mount, Under-Cabinet
Ventilation Type	Ductless/Recirculation
Voltage	220V
Item Weight	7 Kilograms
Country of Origin	Turkey

9. Warranty & Support

Warranty Information:

The Simfer SM 8679 Range Hood comes with a**two-year warranty** from the date of purchase. This warranty covers manufacturing defects and material faults under normal use. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by improper installation, misuse, neglect, unauthorized repairs, or normal wear and tear.

Customer Support:

For technical assistance, spare parts, or warranty claims, please contact your local Simfer service center or the retailer where you purchased the product. Please have your model number (SM 8679) and purchase date ready when contacting support.

© 2023 Simfer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJNZDVDW

More documents and user manuals: **https://manuals.plus/**