Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Turbo Jet Hydro X5 Max

Turbo Jet Hydro X5 Max Portable Cordless Pressure Washer User Manual

Model: Hydro X5 Max

Introduction

The Turbo Jet Hydro X5 Max is a portable cordless pressure washer designed for versatile cleaning tasks. It features a high-efficiency rechargeable 21V 5000mAh battery, providing up to 350 PSI of pressure for effective cleaning without the need for power cords or gas. Its dual water intake system allows connection to a garden hose or drawing water from a bucket or other open sources, offering exceptional flexibility for various applications. This manual provides essential information for safe and efficient operation, setup, maintenance, and troubleshooting.

What's Included

Your Turbo Jet Hydro X5 Max package includes the following components:

- Turbo Jet Hydro X5 Max Pressure Washer Unit
- 21V 5000mAh Lithium-Ion Battery
- Battery Charger
- 6-in-1 Multi-Function Spray Nozzle
- Metal Extender Wand
- Soap Bottle / Foam Cannon
- Water Filter
- 16ft Detachable Hose (for siphon mode)
- 3/4" Hose Quick Connector (for garden hose connection)
- Hard Carry Case



Image: All components of the Turbo Jet Hydro X5 Max Portable Cordless Pressure Washer, including the main unit, battery, charger, various nozzles, hose, soap bottle, and hard carry case.

Setup

1. **Charge the Battery:** Before first use, fully charge the 21V 5000mAh Lithium-Ion battery using the provided charger. Ensure the battery is securely inserted into the charger and the charger is connected to a power outlet. The indicator light on the charger will show charging status.



Image: The 21V 5000mAh Lithium-Ion battery pack.

2. **Attach the Battery:** Once charged, slide the battery pack into the base of the pressure washer unit until it clicks securely into place.
3. **Connect the Metal Extender Wand:** Attach the metal extender wand to the front of the pressure washer unit.
4. **Select and Attach Nozzle:** Choose the desired spray pattern from the 6-in-1 multi-function nozzle (0°, 15°, 25°, 40°, fan, or shower) and attach it to the end of the metal extender wand.



Image: The 6-in-1 multi-function spray nozzle demonstrating its various spray patterns.

5. **Connect Water Source:** The Hydro X5 Max offers dual water source options:
    - **Garden Hose Connection:** Attach a standard garden hose to the 3/4" hose quick connector on the pressure washer.
    - **Siphon Mode (Bucket/Open Water Source):** Connect the 16ft detachable hose with the water filter to the pressure washer's water intake. Place the filtered end of the hose into a bucket of water or an open water source (e.g., lake, pool).



Image: Dual water source setup, showing connection to a garden hose or siphoning from a bucket.

6. **Prime the Pump (Siphon Mode Only):**When using the siphon hose, hold down the trigger for up to 20 seconds to allow water to flow through and reach the tool before starting operation.

Operating Instructions

1. **Power On:** Press the power button on the unit to turn it on.
2. **Start Cleaning:** Aim the nozzle at the surface to be cleaned and press the trigger to activate the water spray.



Image: The pressure washer in use, cleaning windows, siding, pavers, and decks.

3. **Adjust Spray Pattern:** Rotate the 6-in-1 multi-function nozzle to switch between different spray patterns (0° for concentrated stream, 15°, 25°, 40° for wider coverage, fan for general cleaning, and shower for gentle rinsing).
4. **Using the Soap & Foam Dispenser:**
    - Fill the soap bottle with appropriate cleaning solution.
    - Attach the foam cannon to the pressure washer unit.
    - Spray the solution onto the desired surface. Allow it to dwell for a few minutes before rinsing with clear water.



Image: The foam cannon attachment in action, applying soap.

5. **Power Off:** Release the trigger to stop the water flow. Press the power button to turn off the unit.

Maintenance

- **Cleaning:** After each use, rinse the pressure washer and all accessories with clean water to remove any soap residue or debris.
- **Water Filter:** Regularly check and clean the water filter to prevent clogging and ensure optimal performance.
- **Drying:** Ensure all components are thoroughly dry before storing to prevent mold or damage.
- **Storage:** Store the pressure washer and its accessories in the hard carry case in a cool, dry place, away from direct sunlight and extreme temperatures. Remove the battery before long-term storage.
- **Battery Care:** Store the battery in a cool, dry place. For long-term storage, charge the battery to approximately 50% every 3-6 months to maintain its lifespan.

Troubleshooting

No water flow or weak pressure:

- Ensure the battery is fully charged and properly inserted.
- Check the water source connection for kinks or blockages in the hose.
- Clean the water filter if it's clogged.
- If using siphon mode, ensure the hose is fully submerged and the pump has been primed (hold trigger for 20 seconds).

Unit does not turn on:

- Verify the battery is charged and correctly attached.
- Press the power button firmly.

Leaks from connections:

- Ensure all connections (hose, wand, nozzle) are tightened securely.
- Check O-rings and seals for damage and replace if necessary.

Specifications

Feature	Specification
Brand	Turbo Jet
Model	Hydro X5 Max
Power Source	Battery Powered
Battery Type	21V 5000mAh Lithium-Ion
Maximum Pressure	350 PSI
Hose Length	16 Feet
Nozzle Types	6-in-1 Multi-Function (0°, 15°, 25°, 40°, Fan, Shower)
Water Intake	Dual (Garden Hose, Siphon from Bucket/Open Source)
Item Weight	5.71 Pounds
UPC	735541037252



Image: Key specifications and components of the Hydro X5 Max.

Warranty and Support

For warranty information, technical support, or to purchase replacement parts, please refer to the contact details provided on the product packaging or visit the official Turbo Jet website. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJSQZ276

More documents and user manuals: **https://manuals.plus/**