Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM ILSC7DRSC-NO

T4TREAM 7-Drawer Fluted Dresser with Gold Accents (Natural Oak) Instruction Manual

Your guide to assembling, operating, and maintaining your new T4TREAM dresser.

1. Introduction

Thank you for choosing the T4TREAM 7-Drawer Fluted Dresser. This manual provides detailed instructions for assembly, operation, and maintenance to ensure long-lasting enjoyment of your furniture. Please read all instructions carefully before beginning assembly.



Image 1.1: The T4TREAM 7-Drawer Fluted Dresser in a bedroom setting.

2. Safety Guidelines

- Always ensure all parts and hardware are available before beginning assembly.
- Follow each step carefully to ensure the proper assembly of this product.
- Two people are recommended for ease in the assembly of this product.
- A Phillips head screwdriver is required for the assembly of this product (not included).
- To prevent tipping, secure the dresser to a wall using the provided anti-tipping hardware.
- Do not climb on or allow children to play on the dresser.
- Do not overload drawers.

3. Package Contents

3.1. Dimensions



Image 3.1: Product dimensions for the 7-drawer dresser.

Overall dimensions: 54"W x 15.75"D x 32"H. Please refer to the image above for detailed measurements of the dresser and individual drawers.

3.2. Parts and Hardware

All parts and hardware are clearly labeled. Please ensure all components are present before starting assembly. Refer to the assembly manual included in your package for a complete list and diagrams of all parts and hardware.

4. Assembly Instructions

Assembly is straightforward, but attention to detail is crucial, especially when installing drawers. Two people are recommended for optimal assembly.

4.1. General Assembly Tips

- Lay out all components on a soft, clean surface to prevent scratches.
- Identify each part by its label before starting.

- Do not overtighten screws to avoid damaging the wood.

4.2. Drawer Installation Guidance

Important: Ensure drawers are placed in their correct, corresponding slots. Drawers are often numbered or specifically designed for left/right or top/bottom positions. Incorrect placement will prevent drawers from closing properly and affect the seamless appearance.

The video below demonstrates the importance of correct drawer placement. If drawers do not close flush, verify their positions.

Video 4.1: Demonstration of correct drawer placement for seamless fit.

For detailed step-by-step visual instructions on assembling the dresser and installing the drawer slides, please refer to the official installation guide video provided by the manufacturer:

Video 4.2: Official installation guide for a fluted dresser, demonstrating assembly steps.

5. Operating Instructions

The T4TREAM dresser features 4 spacious drawers and 3 smaller drawers, totaling 7 drawers for versatile storage. Each drawer is equipped with metal glides for smooth operation.

- To open a drawer, gently pull the gold metallic handle.
- To close a drawer, gently push it until it is flush with the dresser frame.
- Avoid forcing drawers open or closed to prevent damage to the glides.



Image 5.1: Detail of a drawer with its gold metallic handle.

6. Maintenance

- Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- Periodically check all screws and fasteners to ensure they are tight. Retighten as necessary.
- Keep the dresser away from direct sunlight and extreme temperature changes to prevent warping or fading.

7. Troubleshooting Common Issues

7.1. Drawers Not Closing Properly

If a drawer does not close flush with the dresser frame, it is likely due to incorrect placement during assembly. Each drawer is designed for a specific slot.

- Remove the problematic drawer.
- Check the labels or markings on the drawer and its corresponding slot on the dresser frame.

- Reinsert the drawer into its correct position.

7.2. Drawers Not Gliding Smoothly

- Ensure the drawer slides are free of obstructions.
- Verify that all screws attaching the slides to both the drawer and the dresser frame are securely tightened.
- Lightly lubricate the drawer slides with a silicone-based lubricant if necessary.

Video 7.1: Guide on adjusting drawer slides for optimal function.

8. Product Specifications

Feature	Detail
Brand	T4TREAM
Model Name	ILSC7DRSC-NO
Product Dimensions	15.75"D x 54"W x 32"H
Color	Natural Oak
Material	FSC-Certified Engineered Wood
Finish Type	Painted
Number of Drawers	7
Item Weight	125 Pounds
Assembly Required	Yes

9. Warranty and Customer Support

For any questions, concerns, or warranty claims regarding your T4TREAM dresser, please contact our customer support team. Refer to your purchase documentation for specific warranty details and contact information.
You can also visit the T4TREAM Store on Amazon for additional product information and support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FJYBJD26

More documents and user manuals: **https://manuals.plus/**