GDKLXL Rs1003

GDKLXL Rechargeable Electric Razor User Manual

Model: Rs1003 | Brand: GDKLXL

Introduction

Thank you for choosing the GDKLXL Rechargeable Electric Razor. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new shaver. Please read it thoroughly before first use and keep it for future reference.

Product Overview

The GDKLXL Electric Razor is designed for a comfortable and close shave, featuring advanced technology for sensitive skin and versatile wet/dry use.



Figure 1: GDKLXL Rechargeable Electric Razor and its retail packaging.

Key Features:

- **5D Floating Head & Hypoallergenic Blades:** Adapts to facial contours for a smooth shave, reducing irritation.
- **IPX6 Waterproof:** Allows for easy cleaning under running water and versatile wet/dry shaving.
- **Fast Charging:** 1.5-hour fast charge provides 90 minutes of shaving time. A 30-minute quick boost offers 30 minutes of use.
- **Pop-Up Trimmer:** Integrated trimmer for precise grooming of sideburns and mustaches.
- **LED Display:** Shows battery life percentage and charging status.
- **Travel Lock:** Prevents accidental activation during travel.

Setup

Initial Charging:

1. Before first use, fully charge the razor.
2. Connect the provided USB charging cable to the charging port at the bottom of the shaver.
3. Plug the USB-A end of the cable into a compatible USB power adapter (not included) or a USB port on a computer.
4. The LED display will show the charging progress. A full charge takes approximately 1.5 hours.
5. Once fully charged, the display will show 100%. Disconnect the shaver from the power source.



Figure 2: Connecting the USB-A charging cable to the razor.

Activating Travel Lock:

To prevent accidental activation during travel, press and hold the power button for 3 seconds until a lock icon appears on the LED display. To unlock, press and hold the power button again for 3 seconds.

Operating Instructions

Shaving:

1. Press the power button to turn on the shaver. The LED display will show the remaining battery percentage.
2. For a dry shave, ensure your face is clean and dry. For a wet shave, apply shaving foam or gel to

your face.

3. Gently press the shaver head against your skin and move it in small, circular motions. The 5D floating heads will adapt to the contours of your face, neck, and jawline for an efficient and comfortable shave.
4. After shaving, press the power button to turn off the shaver.



Figure 3: The 5D flexible floating head adapts to facial contours for a close shave.



Figure 4: The razor supports both wet shaving with foam or gel, and dry shaving.

Using the Pop-Up Trimmer:

1. Locate the pop-up trimmer switch on the back of the shaver.
2. Slide the switch upwards to activate the trimmer.
3. Use the trimmer to shape sideburns, mustaches, or for detailed grooming.
4. After use, slide the switch downwards to retract the trimmer.

Maintenance

Cleaning the Shaver Head:

Regular cleaning ensures optimal performance and hygiene.

1. Ensure the shaver is turned off and disconnected from any power source.
2. Press the release button on the side of the shaver head to open it.
3. Rinse the shaver head and the internal cutting unit under warm running water. The IPX6 waterproof rating allows for thorough rinsing.
4. For a more thorough cleaning, use the provided cleaning brush to remove any trapped hair from the blades and internal components.

5. Allow the shaver head to air dry completely before closing it or reattaching it to the shaver body.



Figure 5: The detachable head can be easily rinsed under running water for cleaning.

Blade Replacement:

For best shaving results, it is recommended to replace the shaver blades every 12 months, or sooner if you notice a decrease in performance.

Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is low or dead; Travel lock is activated.	Charge the shaver; Deactivate travel lock by pressing and holding the power button for 3 seconds.
Poor shaving performance.	Blades are dull or clogged with hair; Shaver head is not clean.	Clean the shaver head thoroughly; Consider replacing the shaver blades.
Shaver stops during use.	Battery is depleted.	Recharge the shaver.

Problem	Possible Cause	Solution
Razor feels hot.	Prolonged use; Blocked blades.	Allow the shaver to cool down; Clean the shaver head.

Specifications

- **Model Number:** Rs1003
- **Brand:** GDKLXL
- **Product Dimensions:** 5 x 5 x 5 inches; 9.59 ounces
- **Power Source:** Battery Powered (1 AA battery included)
- **Special Features:** Dry Shave, Fast Charging, Floating Head, High Efficiency, Waterproof (IPX6)
- **Recommended Uses:** Face
- **Manufacturer:** GDKLXL
- **Date First Available:** July 28, 2025

Warranty and Support

The GDKLXL Rechargeable Electric Razor comes with a 1-year warranty from the date of purchase, covering manufacturing defects. Additionally, lifetime customer support is provided for any inquiries or assistance you may need.
For warranty claims, technical support, or general inquiries, please contact GDKLXL customer service through the retailer's platform or visit the official GDKLXL store page on Amazon: GDKLXL Store.

© 2025 GDKLXL. All rights reserved.