Spopal Portable Camping Shower

Spopal 8000mAh Rechargeable Portable Camping Shower Instruction Manual

Overview What's in the Box Key Features Setup Operation Maintenance Troubleshooting Specifications Warranty Support

1. Product Overview

The Spopal 8000mAh Rechargeable Portable Camping Shower kit is designed for easy portability and versatile use. It is suitable for various outdoor activities such as beach trips, camping, and hiking, as well as for tasks like bathing children or pets, washing cars, and watering plants.

This portable shower features an upgraded 8000mAh battery for extended runtime, a 5-stage power control for precise flow adjustment, and an IPX8 waterproof rating for durability in wet conditions. The intelligent LED digital display provides clear information on battery status and water temperature.

2. What's in the Box

- 1 x Camping Shower Pump
- 1 x Shower Head
- 1 x 6.5 ft (2m) Hose
- 1 x USB Type-C Charging Cable (Power adapter not included)
- 1 x Multi-functional Hook
- 1 x Bath Loofah
- 3 x Suction Cups
- 1 x Storage Bag
- 2 x Silicone Rings

3. Key Features

- **Intelligent Operation Protocol:** The unit does not heat water. Always submerge the pump in water before powering on to activate the dry-run protection system. Do not expose the unit to liquids above 140°F (60°C).
- **Upgraded 5-Stage Power Control:** Offers five adjustable speed settings for water flow, defaulting to Level 3 at startup. Allows for precise control from gentle rinsing (Level 1) to high-pressure cleaning (Level 5).

- **Upgraded 8000mAh Battery:** Provides over 180 minutes of runtime on a full charge. Rechargeable via any USB-C source (e.g., power bank, car charger, PC).
- **IPX8 Waterproof Rating:** Ensures the pump and charging port are protected against submersion, making it suitable for use in various outdoor conditions.
- **Integrated Filter System:** Features a 3-in-1 filter designed to remove up to 98% of sediments, maintaining a consistent 1.8 GPM flow rate.
- **Twist-Lock Nozzle:** Prevents accidental changes to spray modes during use.
- **4 Adjustable Shower Modes:** The shower head offers four practical water dispensing settings for varied uses and water conservation.
- **Compact and Portable Design:** Includes a 2-meter anti-kink hose, a multi-angle hanging hook (supports up to 15 lbs), and a compact organizer bag for easy transport and storage.
- **Quiet Operation:** Equipped with a durable motor that operates quietly for a peaceful user experience.

4. Setup Instructions

1. **Charge the Pump:** Before first use, fully charge the shower pump using the provided USB Type-C cable. The LED display will indicate charging status. Ensure the charging port cover is tightly sealed before exposing to water.
2. **Connect Components:** Connect the shower hose to both the pump and the shower head. Ensure all connections are secure to prevent leaks.
3. **Prepare Water Source:** Place the pump into a bucket or container filled with water. The water temperature should not exceed 140°F (60°C). This unit does not heat water.
4. **Submerge and Activate:** Ensure the pump is fully submerged in water. Wait a few seconds for any air bubbles to escape from the pump. Then, press and hold the On/Off button on the pump's display for more than 1 second to start the pump.
5. **Position Shower Head:** Use the multi-functional hook or suction cups to position the shower head at a desired height or location.



Image: Step-by-step guide for setting up the Spopal Portable Camping Shower.

Your browser does not support the video tag.

Video: Unboxing and demonstration of the Spopal Rechargeable Outdoor Shower, showing assembly and initial use.

5. Operating Instructions

1. **Power On/Off:** After submerging the pump, press and hold the power button on the pump's LED display for 2-3 seconds to turn the unit on or off.
2. **Adjust Water Flow:** Use the '+' and '-' buttons on the pump's display to cycle through the 5 adjustable water flow speeds. Level 1 is the lowest flow, and Level 5 is the highest.
3. **Select Spray Mode:** Rotate the switch on the shower head to select one of the four available spray modes: Spray Mode, Mixed Mode, Rainfall Mode, or Spray Gun Mode.
4. **Monitor Display:** The LED display shows the battery percentage, current water temperature (note: the unit does not heat water, it only displays the temperature of the water it is pumping), and the selected water volume level.
5. **Charging:** When the battery is low, connect the USB Type-C charging cable to the pump and a suitable USB

power source. The unit can be charged via PC, power bank, or car charging port.



Image: Intelligent LED Digital Display on the Spopal Portable Camping Shower pump.



Image: Adjustable water flow modes and spray gun mode on the shower head.

Your browser does not support the video tag.

Video: Overview of the Spopal 8000mAh Rechargeable Camping Shower, demonstrating its features and operation.

6. Maintenance

- **Cleaning the Pump:** The pump features a removable cleaning design. Periodically detach the base and clean the pump impeller and filter mesh to ensure optimal performance and prevent sediment buildup.
- **Filter Maintenance:** Regularly inspect the 3-in-1 filter for debris. Clean or replace the filter as needed to maintain efficient water flow and prevent clogging.
- **Hose and Shower Head:** Rinse the hose and shower head after each use, especially if using with soapy water, to prevent residue buildup.
- **Storage:** After use, ensure all components are dry before storing them in the compact organizer bag. Store in a cool, dry place away from direct sunlight.
- **Battery Care:** For long-term storage, charge the battery to approximately 50-70% every 3-6 months to prolong battery life.



Image: Unique design of the Spopal pump for removable cleaning.

7. Troubleshooting

Problem	Possible Cause	Solution
No water flow or weak flow	Pump not fully submerged; Low battery; Clogged filter/shower head; Incorrect flow setting.	Ensure pump is completely underwater. Charge the battery. Clean the filter and shower head. Increase flow setting using '+' button.
Unit does not turn on	Battery is depleted; Power button not pressed correctly.	Charge the battery fully. Press and hold the power button for 2-3 seconds.
Water leaks from connections	Hose not securely attached; Missing or damaged silicone rings.	Ensure all hose connections are tightened. Check and replace silicone rings if damaged.
Water temperature displayed is incorrect	Misunderstanding of feature.	The unit displays the temperature of the water it is pumping; it does not heat the water. Ensure water used is within safe temperature limits (below 140°F/60°C).

8. Specifications

- **Model Name:** Portable Camping Shower
- **Brand:** Spopal
- **Battery Capacity:** 8000mAh
- **Working Time:** 120-180 minutes
- **Charging Time:** Approximately 4-5 hours
- **Waterproof Rating:** IPX8
- **Water Flow Rate:** Up to 1.8 GPM
- **Hose Length:** 2 meters (6.5 feet)
- **Material:** Plastic
- **Item Weight:** 0.9 Kilograms
- **Item Dimensions (LxWxH):** 6.69 x 3.15 x 9.65 inches
- **Color:** Deep Black

9. Warranty Information

This Spopal Portable Camping Shower comes with a**1-Year Limited Warranty** from the date of purchase. This warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

10. Customer Support

For any questions, technical assistance, or warranty claims, please contact Spopal customer support. You can find more information and contact details by visiting the official Spopal store:

Visit the Spopal Store on Amazon

© 2026 Spopal. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question