Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Eclathome HC001

Eclathome Display Cabinet with Glass Doors (Model: HC001) User Manual

Comprehensive instructions for assembly, operation, and maintenance.

Important Safety Information

Always secure the cabinet to the wall using the provided anti-tip kit to prevent tipping. Do not overload the shelves beyond the maximum weight capacity of 100 pounds. Be cautious during assembly to avoid injury from sharp edges or heavy components. Always follow the assembly instructions carefully.

Product Overview

The Eclathome Display Cabinet with Glass Doors, Model HC001, is a 4-tier storage solution designed for displaying collectibles and other items. It features tempered glass doors, three adjustable shelves, two drawers, and a side cabinet for versatile storage. Integrated LED lights with three color options (warm, white, blue) and a human body motion sensor enhance visibility and user convenience. The cabinet is constructed with a reinforced wood frame and includes an anti-tip kit for stability.

Key Features:

- **Smart Motion LED Lights:** Tri-color (warm, white, blue) LED lights with adjustable brightness and a built-in motion sensor that activates lights when someone is within 2-3 meters.
- **Functional Display & Storage:** Three sturdy wooden shelves behind tempered glass doors for display, plus two drawers and a side cabinet for discreet storage.
- **Durable Build with Safety Features:** Reinforced wood frame, tempered glass front doors, and an anti-tip kit. Each shelf supports up to 100 lbs.
- **Modern Style:** Black oak finish with minimalist lines and handle-free pop-up doors.

Product Dimensions:

- Overall: 31.5"W x 13.8"D x 63"H
- Per Shelf Weight Capacity: 100 lbs
- Item Weight: 93 lbs



Image: Eclathome Display Cabinet showing overall dimensions and shelf weight capacity. The cabinet is black oak with glass doors, three display shelves, two drawers, and a side cabinet.

Package Contents

Before beginning assembly, ensure all parts listed in the instruction manual are present and undamaged. The package includes all necessary hardware, with extra parts provided to account for any missing components. The cabinet is shipped in reinforced packaging with foam and glass protection.



Image: Illustration of the reinforced packaging, extra hardware, and precision-drilled holes, highlighting the care taken in shipping and manufacturing.

Setup and Assembly

Assembly is required for this display cabinet. Follow the included English instruction manual carefully. All parts are labeled for easy identification. It is recommended to assemble the cabinet in the room where it will be used due to its weight (93 lbs).

Key Assembly Steps:

1. Unpack all components and verify against the parts list.
2. Assemble the main frame according to the diagrams.
3. Install the LED lighting strips into the recessed channels.
4. Attach the tempered glass doors using the push-to-open mechanisms and hinges.
5. Assemble and install the drawers and side cabinet door.
6. Secure the anti-tip device to the wall and the cabinet for safety.

Your browser does not support the video tag.

Video: An overview of the Eclathome Glass Display Cabinet with drawers, demonstrating its features and assembly process. This video is provided by LIPBUSYCARE INC, a seller of the product.

Your browser does not support the video tag.

Video: A short video showcasing the quality and lighting system of the Eclathome Display Cabinet. This video is provided by Berkay Kaya, a seller of the product.

Operating Instructions

LED Lighting System:

The cabinet features a control panel for the LED lights, located on the side of the unit. This panel allows you to adjust light color and brightness, and activate the motion sensor.

- **Changing Light Color:** Short press the light control button to cycle through warm, white, and blue light options.
- **Adjusting Brightness:** Long press the light control button to adjust the brightness level.
- **Motion Sensor Activation:** Press the motion sensor button to enable or disable the human body sensor. When active, lights will turn on automatically when motion is detected within 2-3 meters and turn off after a period of inactivity.



Image: Illustrates the 3-color lighting options (warm, white, blue) and the smart human motion sensor feature of the display cabinet.

Glass Doors and Drawers:

- **Opening Glass Doors:** The glass doors feature a push-to-open mechanism. Gently press the door to release the latch, then pull to open.
- **Closing Glass Doors:** Push the door firmly until it clicks into place, securing it with the magnetic latch.
- **Drawers:** The two bottom drawers operate on silent gliding mechanisms for smooth opening and closing.



Image: Detailed view of the cabinet's features, including the push-to-open mechanism for glass doors, smooth and silent hinges, the anti-tip device, and silent gliding drawers.

Maintenance

- **Cleaning:** Use a soft, damp cloth to wipe down the wood surfaces. For glass, use a non-abrasive glass cleaner. Avoid harsh chemicals that may damage the finish.
- **Dusting:** Regularly dust the interior and exterior to maintain clarity and appearance.
- **Inspections:** Periodically check all screws and connections to ensure they are tight. Re-tighten if necessary. Verify the anti-tip kit remains securely fastened.
- **Weight Capacity:** Do not exceed the 100 lbs per shelf weight limit to prevent damage or instability.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
LED lights not turning on.	Power cord not connected; motion sensor disabled; faulty connection.	Ensure power cord is securely plugged in. Check if the motion sensor is enabled. Inspect wiring connections.
Glass doors not closing properly.	Misaligned hinges; obstruction; faulty push-to-open mechanism.	Adjust hinges if possible. Remove any obstructions. Contact customer service if mechanism is faulty.
Drawers not sliding smoothly.	Obstruction in tracks; misaligned tracks; overloaded drawer.	Check for and remove obstructions. Ensure tracks are correctly aligned. Reduce weight in the drawer.
Cabinet feels unstable.	Anti-tip kit not installed or loose; uneven floor; overloaded shelves.	Ensure anti-tip kit is correctly installed and secured. Place cabinet on a level surface. Distribute weight evenly and do not exceed capacity.

Specifications

Feature	Detail
Brand	Eclathome
Model Name	Glass Display Cabinet
Item Model Number	HC001
Color	Black Oak
Material	Wood, Tempered Glass, Acrylic
Product Dimensions	13.8"D x 31.5"W x 63"H
Item Weight	93 Pounds
Weight Limit (per shelf)	100 Pounds
Number of Shelves	3 (display), plus 2 drawers and 1 side cabinet
Special Feature	Dustproof, Unbreakable (Tempered Glass), Smart Motion LED Lights (3-Color)
Mounting Type	Floor Mount (with Anti-tip Kit)
Assembly Required	Yes
UPC	710050502446

Warranty and Support

For any questions, concerns, or assistance with your Eclathome Display Cabinet, please contact our customer service team. We offer 24/7 support to ensure your satisfaction.
Please refer to your purchase documentation for specific warranty details. Protection plans may be available for extended coverage.
Contact Information: Refer to the contact details provided with your product packaging or on the official Eclathome website.

© 2026 Eclathome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FKGWYRFY

More documents and user manuals: **https://manuals.plus/**