T&G TG117

T&G Portable Bluetooth Speaker TG117 Instruction Manual

Model: **TG117** | Brand: **T&G**





Image: Front view of the T&G Portable Bluetooth Speaker TG117 in black.

Introduction

This manual provides detailed instructions for the T&G Portable Bluetooth Speaker, Model TG117. Please read this manual carefully before use to ensure proper operation and to maximize your listening experience. Keep this manual for future reference.

Product Features

- **Immersive Sound & Dual Connectivity:** Experience exceptional sound quality with dual drivers and advanced audio technology. Supports True Wireless Stereo (TWS) pairing for enhanced sound.
- **IPX4 Waterproof Protection:** Resistant to water splashes, rain, and light water exposure, making it suitable for outdoor activities.
- **Portable & Compact Design:** Lightweight and easy to transport, ideal for travel, fitness, and outdoor adventures.
- **Upgraded Bluetooth 5.3 Connectivity:** Ensures a stable connection up to 66 feet with fast pairing and smooth music

streaming.

- **Versatile for Every Occasion:** Designed for both indoor and outdoor use, offering powerful, balanced sound for parties, hiking, or relaxing.



Image: Illustration of dual internal speakers for enhanced audio output.



Image: Speaker being splashed with water, highlighting its IPX4 waterproof feature.



Image: A person holding the compact speaker, emphasizing its portability for outdoor use.



Image: Diagram showing the speaker wirelessly connecting to a laptop and smartphone, illustrating its versatile connectivity.

Package Contents

The package typically includes the following items:

- T&G Portable Bluetooth Speaker TG117
- USB Charging Cable
- AUX Cable
- User Manual

Controls and Ports

Familiarize yourself with the speaker's controls and ports for optimal use.



Image: Detailed view of the T&G TG117 speaker's control panel and input ports, including Power, Volume Up/Next Track, Volume Down/Previous Track, Mode, AUX Jack, USB Port, TF Card Slot, and Charging Port.

- **Power Button:** Press and hold to turn on/off. Short press to play/pause.
- **Volume Up / Next Track Button:** Short press for next track, long press for volume up.
- **Volume Down / Previous Track Button:** Short press for previous track, long press for volume down.
- **Mode Button (M):** Short press to switch between Bluetooth, FM Radio, TF Card, and AUX modes.
- **AUX Jack:** For wired audio input.
- **USB Port:** For USB flash drive playback.
- **TF Card Slot:** For Micro SD card playback.
- **Charging Port:** Connect the USB charging cable here.
- **Microphone:** For hands-free calls.

Setup and First Use

Charging the Speaker

Before first use, fully charge the speaker to ensure optimal battery performance.

1. Connect the provided USB charging cable to the speaker's charging port.
2. Connect the other end of the USB cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. Once fully charged, the light may change color or turn off.

Powering On/Off

Press and hold the **Power button** for approximately 3 seconds to turn the speaker on or off.

Operating Instructions

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode (indicated by a flashing blue LED). If not, press the 'M' (Mode) button to switch to Bluetooth mode.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "TG117" from the list of devices.
4. Once paired, the speaker will emit a confirmation tone, and the LED indicator will stop flashing.

True Wireless Stereo (TWS) Pairing

To achieve a stereo sound experience, you can pair two TG117 speakers together.

1. Ensure both TG117 speakers are powered on and in Bluetooth mode, but not connected to any device.
2. On one speaker (this will be the primary speaker), press and hold the 'M' (Mode) button until you hear a pairing tone.
3. The two speakers will automatically connect to each other. Once connected, the primary speaker's LED will flash, and the secondary speaker's LED will be solid.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described above.

Using Other Audio Inputs

AUX Mode

Connect one end of the 3.5mm AUX cable to the speaker's AUX port and the other end to your audio device. The speaker will automatically switch to AUX mode or you may need to press the 'M' button.

USB Flash Drive / TF Card Mode

Insert a USB flash drive into the USB port or a TF (Micro SD) card into the TF card slot. The speaker will automatically detect the media and begin playback, or you may need to press the 'M' button to switch modes.

FM Radio Mode

Press the 'M' (Mode) button to switch to FM Radio mode. Use the Volume Up/Down buttons to scan for stations.

Hands-Free Calling

When connected via Bluetooth, the speaker can be used for hands-free calls.

- To answer an incoming call: Short press the **Power button**.
- To end a call: Short press the **Power button**.
- To reject a call: Press and hold the **Power button**.

Maintenance and Care

Waterproofing (IPX4)

The TG117 speaker is IPX4 rated, meaning it is resistant to splashes of water from any direction. It is suitable for use in environments where it might encounter light rain or splashes, such as by the pool or at the beach.
Important: Do not submerge the speaker in water. Ensure the rubber flap covering the ports is securely closed to maintain water resistance.

Cleaning

Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.

Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

- **Speaker not turning on:** Ensure the battery is charged. Connect to a power source and try again.
- **Cannot pair via Bluetooth:** Make sure the speaker is in Bluetooth pairing mode (flashing LED) and not connected to another device. Ensure your device's Bluetooth is enabled and within range. Try restarting both the speaker and your device.
- **No sound:** Check the volume levels on both the speaker and your connected device. Ensure the correct mode (Bluetooth, AUX, etc.) is selected.
- **Poor sound quality:** Ensure the speaker is within Bluetooth range and there are no obstructions. For wired connections, check the AUX cable.
- **TWS pairing issues:** Ensure both speakers are not connected to any other device before initiating TWS pairing. Follow the TWS pairing steps carefully.

Official Product Video

Your browser does not support the video tag.

Video: An overview of the T&G Portable Bluetooth Speaker TG117, showcasing its features and portability.

Specifications



Image: Visual representation of the speaker's dimensions and battery capacity (1200 mAh, 6-8 hours playtime).

Feature	Detail
Model Name	TG117
Brand	T&G
Wireless Technology	Bluetooth 5.3
Waterproof Rating	IPX4
Speaker Output Power	10 Watts (5W x 2)
Frequency Response	40 Hz
Connectivity Options	Bluetooth, AUX, USB, TF Card, FM Radio
Control Method	Push Button
Maximum Range	66 Feet (Bluetooth)

Power Source	Battery Powered
Item Weight	14.5 ounces
Product Dimensions	6.3"D x 2.72"W x 2.72"H
Warranty Type	Limited

Warranty and Support

This T&G Portable Bluetooth Speaker TG117 comes with a **limited warranty**. For specific warranty terms and conditions, please refer to the warranty card included in your package or contact T&G customer support.
For technical support or further assistance, please visit the official T&G website or contact their customer service department.

© 2025 T&G. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question