Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TAKMEHOME TM-1112

TAKMEHOME 4L Oil-Free Air Fryer

Model: TM-1112 | User Manual

Introduction

Thank you for choosing the TAKMEHOME 4L Oil-Free Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods, utilizing rapid air circulation technology to achieve crispy results with minimal to no oil. Please read this manual thoroughly before operating the appliance and retain it for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block any ventilation openings.

Product Components

Familiarize yourself with the main parts of your TAKMEHOME Air Fryer:

- **Main Unit:** Houses the heating element and fan.
- **Control Panel:** Features a timer dial for operation.
- **Air Fryer Basket:** Removable non-stick basket for holding food.
- **Crisper Plate/Grill:** Sits inside the basket to allow air circulation around food.
- **Handle:** Insulated handle for safe removal of the basket.



Image: The TAKMEHOME Air Fryer showing the internal hot air circulation system and the removable basket with crisper plate.

Setup

1. **Unpack:** Carefully remove all packaging materials and any promotional labels or stickers from the air fryer.
2. **Clean:** Wash the air fryer basket and crisper plate with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely. Wipe the inside and outside of the main unit with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, and heat-resistant surface. Ensure there is at least 10 cm (4 inches) of free space at the back and sides of the appliance, and 10 cm (4 inches) above it, to allow for proper air circulation.
4. **Power:** Plug the power cord into a grounded wall outlet.

Operating Instructions

The TAKMEHOME Air Fryer features simple analog controls for easy operation.

1. **Prepare Food:** Place your ingredients into the air fryer basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the air fryer basket back into the main unit until it clicks securely into place.
3. **Set Timer:** Turn the timer dial to your desired cooking time (0-60 minutes). The appliance will automatically turn on once the timer is set.



Image: A hand demonstrating how to adjust the timer dial on the front of the air fryer.

4. **Cooking Process:** The air fryer will begin heating. The 360° rapid air circulation will cook your food.
5. **Shaking (Optional):** For some foods, especially smaller items like fries, it is recommended to shake the basket halfway through the cooking time to ensure even crisping. To do this, carefully pull out the basket by its handle, shake it, and then slide it back in.
6. **Completion:** When the timer reaches zero, the air fryer will automatically turn off and a bell will sound.
7. **Remove Food:** Carefully pull out the basket and place it on a heat-resistant surface. Use tongs to remove the cooked food.
8. **Cool Down:** Allow the appliance to cool down completely before cleaning.



Image: The air fryer basket pulled out, showing a batch of perfectly cooked golden fries.

Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer and allow it to cool down completely before cleaning.
2. **Basket and Crisper Plate:** The non-stick air fryer basket and crisper plate are dishwasher safe. Alternatively, they can be washed by hand with hot water, dish soap, and a non-abrasive sponge. For stubborn food residue, soak them in warm, soapy water for about 10 minutes before cleaning.



Image: The air fryer basket and crisper plate placed in a dishwasher for cleaning.

3. **Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scourers, as they can damage the surface.
4. **Interior:** If necessary, wipe the interior of the appliance with a damp cloth. For any baked-on food, a soft brush can be used.
5. **Heating Element:** Gently clean the heating element with a dry brush to remove any food residue.
6. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.

Troubleshooting

If you encounter any issues with your air fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Air fryer does not turn on.	The appliance is not plugged in. The timer is not set.	Ensure the power cord is securely plugged into a grounded outlet. Turn the timer dial to the desired cooking time.
Food is not cooked evenly.	Basket is overfilled. Food items are too close together.	Do not overfill the basket. Cook food in smaller batches if necessary. Shake the basket halfway through cooking.
Food is not crispy.	Not enough oil (for certain foods). Temperature or time is too low.	Lightly brush or spray food with a small amount of oil. Increase cooking time or adjust the timer.
White smoke comes from the appliance.	Fat residue from previous use. Excess oil on food.	Clean the basket and crisper plate thoroughly after each use. Pat food dry before air frying to remove excess moisture/oil.

Specifications

- **Model:** TM-1112
- **Capacity:** 4 Liters
- **Wattage:** 700 Watts
- **Dimensions (D x W x H):** 30.5 cm x 34.5 cm x 30.5 cm
- **Color:** Black
- **Basket Material:** Non-stick coating
- **Dishwasher Safe Parts:** Non-stick basket and crisper plate

Warranty and Support

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact TAKMEHOME customer service. Keep your purchase receipt as proof of purchase.
For further assistance, please visit our official website or contact our support team directly.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FKNFF16R

More documents and user manuals: **https://manuals.plus/**