Cecotec A01_EU01_109567

Cecotec Freestyle Grind & Latte Coffee Machine User Manual

Model: A01_EU01_109567

1. Introduction

Thank you for choosing the Cecotec Freestyle Grind & Latte Coffee Machine. This appliance is designed to provide a versatile coffee experience, allowing you to prepare a wide range of beverages from intense espresso to creamy lattes, using both coffee beans, ground coffee, and various capsule types. Please read this manual carefully before operating the machine to ensure safe and optimal performance. Keep this manual for future reference.

2. Safety Instructions

- Always connect the appliance to a grounded power outlet.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- Keep the appliance out of reach of children.
- Unplug the machine before cleaning and when not in use.
- Do not operate the appliance if the power cord or plug is damaged.
- Use only original accessories and spare parts.
- Ensure the water tank is filled with fresh, cold water before use.
- Hot surfaces: Avoid contact with hot parts of the machine, such as the brewing unit and steam nozzle, during and immediately after operation.

3. Product Overview

The Cecotec Freestyle Grind & Latte coffee machine combines advanced features for a complete coffee experience. Key components include a conical grinder, a multi-capsule system, a milk frother, and a touch control panel.



Figure 3.1: Front view of the Cecotec Freestyle Grind & Latte coffee machine with its various components and accessories, including the milk tank, drip tray, and capsule adapters.



Figure 3.2: A slightly angled front view of the coffee machine, highlighting the sleek design and integrated milk frother.

Key Features:

- **Multi-Capsule System:** Compatible with Dolce Gusto, Nespresso, and K-fee capsules.
- **Integrated Conical Grinder:** For fresh coffee beans with 15 grind levels.
- **Thermoblock System:** Ensures rapid heating and precise temperature control.
- **20 Bars Pressure:** For optimal coffee extraction.
- **Touch Control Panel:** Intuitive operation for various coffee selections.
- **Automatic Cleaning System:** For convenient maintenance.
- **Detachable Milk Tank:** 350ml capacity for easy preparation and cleaning of milk-based beverages.
- **Water Tank:** 1.6L capacity.
- **Bean Hopper:** 40g capacity.

4. Setup

4.1 Unpacking and Initial Cleaning

1. Carefully remove all packaging materials.
2. Wash the water tank, milk tank, drip tray, and capsule adapters with warm soapy water. Rinse thoroughly and dry.
3. Wipe the exterior of the machine with a damp cloth.

4.2 Filling the Water Tank

- Remove the water tank from the back of the machine.
- Fill it with fresh, cold drinking water up to the MAX level (1.6L).
- Place the water tank back into its position, ensuring it is securely seated.

4.3 Filling the Milk Tank

- Detach the milk tank (350ml) from the side of the machine.
- Fill with cold milk up to the desired level.
- Reattach the milk tank, ensuring the milk frother tube is correctly inserted into the machine.

4.4 Adding Coffee



Figure 4.1: Adding coffee beans to the integrated hopper and adjusting the grind setting.

- **For Coffee Beans:** Open the lid of the bean hopper (40g capacity) on top of the machine and pour in fresh coffee beans. Close the lid securely. Adjust the grind level using the dial inside the hopper (15 levels available).
- **For Ground Coffee or Capsules:** Use the appropriate adapter. Open the adapter, add ground coffee or insert a capsule (Dolce Gusto, Nespresso, or K-fee compatible), and close it. Insert the adapter into the designated slot.



Figure 4.2: The multi-capsule adapter, showing how to insert ground coffee or a compatible capsule.

4.5 First Use Cycle

Before first use, perform a rinsing cycle without coffee to clean the internal system. Follow the on-screen instructions on the touch panel for this process.

5. Operating the Coffee Machine

The machine features an intuitive touch control panel for selecting your desired beverage.



Figure 5.1: The touch control panel displaying options for different coffee types and functions.

5.1 Making Coffee

1. Ensure the water tank is filled and coffee (beans, ground, or capsule) is loaded.
2. Place a cup on the drip tray. The sliding support can be adjusted for different cup sizes.
3. Turn on the machine using the power button. The machine will preheat.
4. On the touch screen, select your desired beverage (e.g., Espresso, Lungo, Latte, Steam Milk).
5. For milk-based drinks, ensure the milk tank is filled and properly attached.
6. The machine will automatically brew and dispense the selected drink.



Figure 5.2: Coffee being brewed and dispensed into a cup, illustrating the brewing process.



Figure 5.3: A user enjoying a latte, with the coffee machine in the background preparing another beverage.

5.2 Customizing Your Drink

- **Grind Level:** Adjust the conical grinder for finer or coarser coffee. Finer grind for stronger espresso, coarser for lighter coffee.
- **Temperature:** The Thermoblock system allows for temperature customization. Refer to the on-screen menu for specific settings.
- **Volume:** Most drink options allow for volume adjustment via the touch screen.

6. Maintenance

Regular cleaning and maintenance ensure the longevity and optimal performance of your coffee machine.

6.1 Automatic Cleaning System

- The machine features an automatic cleaning function. Follow the prompts on the touch screen for routine cleaning cycles.
- This function helps maintain hygiene and prevents coffee residue buildup.

6.2 Cleaning the Milk System

- After preparing milk-based drinks, it is recommended to clean the milk system immediately.
- Detach the milk tank and rinse all components with warm water.
- Use a mild detergent if necessary, then rinse thoroughly.

6.3 Cleaning the Drip Tray and Coffee Grounds Container

- Empty and clean the drip tray and coffee grounds container regularly to prevent overflow and mold growth.
- Wash with warm soapy water, rinse, and dry before reinserting.

6.4 Descaling

- Depending on water hardness and usage, the machine will indicate when descaling is required.
- Use a suitable descaling solution specifically designed for coffee machines.
- Follow the instructions provided with the descaling solution and the machine's on-screen prompts for the descaling process.

7. Troubleshooting

This section addresses common issues you might encounter with your coffee machine.

Problem	Possible Cause	Solution
No coffee dispensed	Water tank empty; coffee clogged; machine not preheated.	Fill water tank; clean coffee outlet; wait for preheating.
Weak coffee	Insufficient coffee; grind too coarse; descaling needed.	Add more coffee; adjust grind to finer setting; descale machine.
Milk not frothing	Milk tank empty; milk system clogged; cold milk not used.	Fill milk tank; clean milk frother; use cold milk.
Machine leaks	Water tank not properly seated; drip tray full.	Ensure water tank is secure; empty drip tray.
Error message on screen	Specific internal issue.	Refer to the specific error code in the full manual or contact customer support.

8. Specifications

- **Model Name:** Freestyle Grind & Latte
- **Model Number:** A01_EU01_109567
- **Power:** 1400W
- **Pressure:** 20 Bars
- **Water Tank Capacity:** 1.6 L
- **Milk Tank Capacity:** 350 ml
- **Coffee Bean Hopper Capacity:** 40 g

- **Dimensions:** 31.5 x 24 x 37.5 cm (Length x Width x Height)
- **Weight:** 6.5 kg
- **Compatibility:** Dolce Gusto, Nespresso, K-fee capsules, ground coffee, coffee beans.

9. Warranty and Support

This product is manufactured by Cecotec. For specific warranty details, please refer to the warranty card included with your purchase or visit the official Cecotec website. Spare parts availability in the EU is guaranteed for 10 years from the manufacturing date (2025).
For technical assistance, troubleshooting beyond this manual, or to inquire about spare parts, please contact Cecotec customer support through their official channels.

© 2025 Cecotec. All rights reserved.