Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BETMI 2.4GHz Wireless Controller

BETMI Wireless Gaming Controller User Manual

Model: 2.4GHz Wireless Controller

1. Introduction

Thank you for choosing the BETMI Wireless Gaming Controller. This controller is designed to provide a versatile and immersive gaming experience across multiple platforms. Please read this manual carefully to ensure proper setup and operation.

2. Package Contents

- BETMI Wireless Gaming Controller
- 2.4GHz Wireless Adapter
- USB-C Charging Cable
- User Manual

3. Product Overview

The BETMI Wireless Gaming Controller features an ergonomic design for comfortable grip and sensitive controls for precise gameplay. It includes advanced features such as dual vibration, turbo function, and macro programming.



Image: The BETMI Wireless Gaming Controller, highlighting its ergonomic design for a comfortable grip during extended gaming sessions.



Image: Detailed view of the controller's sensitive joysticks, high-precision buttons, and linear triggers, designed for accurate and responsive input.

4. Setup

4.1 Multi-Platform Compatibility

This controller is compatible with a variety of platforms, including Xbox One, Xbox One S/X, Xbox Series S/X, and PC (Windows 8/10/11).



Image: The BETMI controller displayed with icons indicating its compatibility with Xbox One, Xbox One X, Xbox One S, Xbox Series S, Xbox Series X, and PC (Windows 8/10/11).

4.2 Connecting via 2.4GHz Wireless Adapter

1. Insert the **2.4GHz wireless adapter** into a USB port on your host device (Xbox console or PC). The LED on the adapter will flash slowly.
2. Press and hold the controller's **HOME** button for 1 second to turn on the device. The controller's LED will flash slowly.
3. Short press the controller's **HOME** button again, then press the button on the**2.4GHz wireless adapter**. Both the controller and adapter LEDs will flash quickly, indicating they are in pairing mode.
4. Once successfully connected, the LEDs on both the adapter and controller will remain steadily lit. You can now start playing.

Your browser does not support the video tag.

Video: A demonstration of how to connect the BETMI Wireless Gaming Controller to an Xbox console using the 2.4GHz wireless adapter. The video shows plugging in the adapter, turning on the controller, and initiating the pairing process until a successful connection is established.

4.3 Charging the Controller

The controller is equipped with a 600mAh battery, offering up to 8 hours of gameplay on a single charge. Use the included USB-C cable to charge your controller.



Image: An internal view of the BETMI controller highlighting the 600mAh large capacity battery and the USB-C charging port.

Charging Tips:

- The controller can be charged using a PC USB port.
- You can use a 5V 2A or lower charger for charging.
- Do not use a fast-charging phone charger to charge the controller.
- Do not use a non-standard power adapter to charge the controller.
- Do not use an over-voltage or over-current power adapter for charging.

5. Operating Instructions

5.1 Turbo Function

The Turbo button allows you to activate rapid-fire mode for quick and efficient gameplay, providing a competitive edge. Press the **Turbo** button along with a desired action button to enable or disable this feature.



Image: The BETMI controller with an overlay illustrating the Turbo function, showing different shots per second settings for rapid-fire actions in games.

5.2 Macro Programming Function

The upgraded Macro Programming Function enables you to swiftly execute a series of commands with a single button press. The controller features two additional programmable buttons (MR and ML) on the back.



Image: The rear view of the BETMI controller, highlighting the MR (Macro Right) and ML (Macro Left) programmable buttons, which can be assigned to complex command sequences.

5.3 Dual Vibration Feedback

Experience a more realistic gaming experience with the dual-motor vibration feedback. The intensity of the vibration will vary based on in-game actions, enhancing immersion.

6. Maintenance

- Keep the controller dry and away from moisture.
- Avoid exposing the controller to extreme temperatures.
- Clean the controller with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the controller in a safe place when not in use to prevent damage.

7. Troubleshooting

7.1 Controller Not Connecting

- Ensure the 2.4GHz wireless adapter is securely plugged into the host device.
- Verify that the controller is powered on (long press HOME button).
- Repeat the pairing process as described in Section 4.2.
- Try plugging the adapter into a different USB port on your host device.
- Ensure the controller is sufficiently charged.

7.2 Controller Not Charging

- Check the USB-C cable for any damage and ensure it is properly connected to both the controller and the power source.
- Use a compatible charger (5V 2A or lower). Avoid fast chargers.
- Try charging from a different USB port or power adapter.

7.3 Input Lag or Disconnections

- Ensure there are no significant obstructions between the controller and the wireless adapter.
- Move closer to the host device to reduce potential interference.
- Avoid using the controller near other strong wireless signals or electronic devices that might cause interference.

8. Specifications

Feature	Detail
Connectivity Technology	2.4GHz Wireless
Compatible Devices	Xbox One, Xbox One S/X, Xbox Series S/X, PC (Windows 8/10/11)
Controller Type	Gamepad
Battery Capacity	600mAh
Playtime	Up to 8 hours
Item Weight	220 Grams
Item Dimensions	6.1 x 4.33 x 2.17 inches
Additional Features	Dual Vibration, Turbo Function, Macro Programming, Ergonomic Design

9. Warranty and Support

BETMI products are designed for quality and reliability. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official BETMI website. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FKTDFM97

More documents and user manuals: **https://manuals.plus/**