Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KAUDGHY 6202204

KAUDGHY BOHO-1 Rattan Flush Mount Ceiling Fan with Light and Remote Instruction Manual

Model: 6202204

Introduction Safety Information Package Contents Setup & Installation Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for purchasing the KAUDGHY BOHO-1 Rattan Flush Mount Ceiling Fan with Light and Remote. This manual provides detailed instructions for the safe installation, operation, and maintenance of your new ceiling fan. Please read this manual thoroughly before installation and keep it for future reference.

This 20-inch coastal boho ceiling fan features a handwoven rattan design, integrated lighting, and a convenient remote control for adjusting fan speeds and light settings. Its low-profile structure is ideal for rooms with lower ceilings, providing both air circulation and ambient illumination.



Image 1.1: The KAUDGHY BOHO-1 Rattan Flush Mount Ceiling Fan, showcasing its natural rattan design and integrated lighting.

2. Safety Information

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these instructions:

- Read all instructions and safety information before installing your new fan.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- Ensure the installation site can support the fan's weight.
- Before installation, disconnect power at the main circuit breaker to prevent electrical shock.
- Do not operate the fan with damaged wiring.
- Avoid placing objects in the path of the fan blades.
- This fan is designed for indoor use only.
- Use only E26 base bulbs, maximum 60W per bulb.

3. Package Contents

Carefully unpack your fan and check that all contents are present. If any parts are missing or damaged, contact customer support.

- Rattan Flush Mount Ceiling Fan Unit
- Mounting Bracket
- Remote Control
- Hardware Pack (screws, wire nuts, etc.)
- Instruction Manual

4. Setup & Installation

Tools Required: Screwdriver, wire strippers, adjustable wrench, ladder.

1. **Turn off Power:** Before beginning, ensure the power is OFF at the circuit breaker.
2. **Mounting Bracket Installation:** Secure the mounting bracket to the ceiling junction box. Ensure the junction box is securely fastened to the building structure and can support the fan's weight.
3. **Wiring:** Connect the fan's electrical wires to the household wiring according to local electrical codes. Use the provided wire nuts to secure connections. Ensure all connections are tight and insulated.
4. **Attach Fan Unit:** Carefully lift the fan unit and attach it to the mounting bracket. Secure it with the provided screws.
5. **Install Light Bulbs:** Screw in four E26 base light bulbs (not included) into the sockets.
6. **Power On:** Restore power at the circuit breaker.



Image 4.1: The low-profile design of the fan, suitable for various ceiling heights.

5. Operating Instructions

Your KAUDGHY BOHO-1 fan is controlled by the included remote control.

5.1 Remote Control Functions

- **Fan ON/OFF:** Press the fan button to turn the fan on or off.
- **Fan Speed:** Use the speed buttons (1-6) to adjust the fan speed. There are 6 adjustable speeds.
- **Light ON/OFF:** Press the light button to turn the light on or off.
- **Light Dimming:** (If applicable, check product details for dimming capability. Assuming basic ON/OFF for E26 bulbs unless specified).
- **Timer:** Set the fan to turn off automatically after 1, 2, or 4 hours using the timer buttons.
- **Reverse Rotation:** Press the reverse button to change the direction of the fan blades. This feature allows for summer cooling (downward airflow) and winter circulation (upward airflow).



Image 5.1: Key features of the fan, including 6-speed reversible motor and dual control for fan and light.

6. Maintenance

Regular maintenance ensures optimal performance and extends the life of your fan.

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Blade Balance:** If the fan wobbles, check that all screws are tightened and the blades are balanced.
- **Light Bulb Replacement:** Ensure power is off before replacing light bulbs. Use E26 base bulbs, maximum 60W.
- **Rattan Care:** The rattan material can be gently dusted with a soft brush or cloth. Avoid excessive moisture.



Image 6.1: Detail of the natural rattan craftsmanship, highlighting the material's texture.

7. Troubleshooting

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low.	Check circuit breaker; Verify all wire connections are secure; Replace remote control battery.
Light does not work	Light bulb faulty; Loose wire connection; No power to the light.	Replace light bulb; Check light wiring; Ensure power is on.
Fan wobbles	Loose mounting screws; Unbalanced blades.	Tighten all mounting screws; Ensure blades are securely attached and balanced.

Problem	Possible Cause	Solution
Remote control not working	Battery low or incorrectly inserted; Remote not paired with fan.	Replace battery, ensuring correct polarity; Refer to remote pairing instructions (if applicable, usually automatic for ceiling fans).

8. Specifications

- **Brand:** KAUDGHY
- **Model Number:** 6202204
- **Product Dimensions:** 19.68"D x 19.68"W x 9.05"H (50cm D x 50cm W x 23cm H)
- **Material:** Rattan
- **Electric Fan Design:** Ceiling Fan
- **Mounting Type:** Flush Mount
- **Number of Blades:** 7
- **Number of Speeds:** 6
- **Controller Type:** Remote Control
- **Light Base:** 4 x E26 (Max 60W per bulb)
- **Voltage:** 120 Volts
- **Wattage:** 60 Watts
- **Indoor/Outdoor Usage:** Indoor
- **Special Features:** Low Profile, Memory Function, Remote Controlled, Reversible Airflow, Timer (1H/2H/4H)
- **Recommended Room Size:** 90-120 sq ft
- **Certification:** UL Listed



Image 8.1: Detailed dimensions of the ceiling fan.

9. Warranty & Support

The KAUDGHY BOHO-1 Rattan Flush Mount Ceiling Fan comes with a**1-year warranty** from the date of purchase, covering defects in materials and workmanship.

For warranty claims, technical support, or any questions regarding your product, please contact KAUDGHY customer service. Please have your model number (6202204) and proof of purchase ready.

Contact Information: Please refer to the packaging or the official KAUDGHY website for the most up-to-date customer support contact details.

© 2023 KAUDGHY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FL7BC9LS

More documents and user manuals: **https://manuals.plus/**