ChooChoo SC2301-WH-NEW-1

ChooChoo SC2301-WH-NEW-1 67-inch Tall Storage Cabinet User Manual

Model: SC2301-WH-NEW-1

Safety Information Product Overview Parts List Setup & Assembly Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Safety Information

WARNING: Ensure proper assembly and use of the anti-tip kit to prevent tipping. Handle with care during assembly to avoid injury or damage. Always follow all assembly instructions carefully.



Image: Illustration showing the anti-tip kit being installed to secure the cabinet to a wall, emphasizing safety.

2. Product Overview

The ChooChoo SC2301-WH-NEW-1 is a versatile 67-inch tall storage cabinet designed to maximize vertical space. It features two doors, one drawer, and adjustable shelves, making it suitable for various rooms such as bathrooms, living rooms, or kitchens. Its slim design and elegant pearl white finish complement modern interiors.



Image: The ChooChoo 67-inch Tall Storage Cabinet in a pearl white finish, positioned in a kitchen setting, showcasing its design and utility.

Key Features:

- **Adjustable Shelves:** Customize storage space behind two doors for items of varying heights.
- **Slim Design:** Measures 15.7"W × 11.8"D × 67"H, ideal for narrow spaces.
- **Versatile Use:** Suitable for bathrooms, kitchens, hallways, or living rooms.
- **Elegant Aesthetic:** Classic lines, paneled doors, and sleek silver knobs.
- **Durable Construction:** Made from premium MDF with a raised base for moisture protection.
- **Safety:** Includes an anti-tip kit for stability.



Image: Close-up view highlighting key features such as decorative molding, line design, exquisite handle, metal hinges, adjustable shelves, and a stable base.

3. Parts List

Before assembly, ensure all parts are present and undamaged. Refer to the included instruction manual for a complete, detailed list of components and hardware. Do not discard packaging until assembly is complete.

Main Components:

- Top Panel
- Bottom Panel
- Side Panels (Left & Right)
- Back Panel
- Adjustable Shelves
- Door Panels (Upper & Lower)

- Drawer Front, Sides, Back, and Bottom

Hardware (Typical):

- Cam Bolts and Locks
- Wood Dowels
- Screws (various sizes)
- Hinges
- Door Knobs
- Drawer Glides
- Anti-tip Kit (Wall Anchor, Screws, Strap)

4. Setup & Assembly

Assembly is required for this product. The cabinet comes with clear instructions and labeled hardware for straightforward assembly. It is recommended to have at least two people for assembly to ensure stability and ease of handling larger components.

Tools Required (Not Included):

- Phillips Head Screwdriver
- Hammer (for dowels)
- Drill (for wall anchor installation, if applicable)

Assembly Steps (General Guidance):

1. Unpack all components and verify against the parts list in the included manual.
2. Attach cam bolts and dowels to the designated panels as per the manual's diagrams.
3. Assemble the main frame of the cabinet, securing panels with cam locks.
4. Install drawer glides onto the side panels and assemble the drawer. Ensure correct orientation for flush fit.
5. Attach hinges to the doors and then to the cabinet frame. Adjust hinges for proper door alignment.
6. Insert adjustable shelf pins into desired height positions and place shelves.
7. Secure the back panel to the cabinet.
8. Install door knobs and drawer pull.
9. **Crucial:** Install the anti-tip kit to a wall stud using the provided hardware to prevent accidental tipping.

Refer to the detailed graphical instructions provided in your product packaging for precise step-by-step guidance.

Your browser does not support the video tag.

Video: A demonstration of the ChooChoo storage cabinet's features and assembly process. This video provides a visual guide to understanding the product's functionality and construction.

5. Operating Instructions

Adjusting Shelves:

The cabinet features adjustable shelves to accommodate items of various sizes. To adjust a shelf, remove all items from the shelf. Carefully lift the shelf and remove the four shelf pins from their current holes. Reinsert the pins into the desired new height positions, ensuring they are level, and then place the shelf back onto the pins.

Using Doors and Drawer:

- **Doors:** Gently pull the knob to open the doors. Push firmly to close. Avoid slamming to prevent damage to hinges and the cabinet structure.
- **Drawer:** Pull the drawer front to open. Push until it is fully closed and flush with the cabinet frame. Do not overload the drawer to ensure smooth operation of the glides.



Image: A detailed view of the cabinet's single drawer, showcasing its capacity for storing various small items.





Image: The interior of the cabinet with doors open, revealing adjustable shelves and a drawer, demonstrating its storage versatility.

6. Maintenance

Cleaning:

Wipe the cabinet surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the finish. Dry immediately with a clean cloth.

General Care:

- Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- Ensure the anti-tip kit remains securely fastened to the wall.
- Avoid placing extremely hot or cold items directly on the cabinet surface without protection.
- Keep the cabinet away from direct sunlight and excessive humidity to prevent warping or discoloration.

7. Troubleshooting

Problem	Possible Cause	Solution
Cabinet is wobbly.	Screws or cam locks are loose; anti-tip kit not installed or loose.	Tighten all assembly hardware. Ensure the anti-tip kit is properly installed and secured to a wall stud.
Drawer does not close flush.	Drawer glides are misaligned or installed incorrectly.	Review assembly instructions for drawer glide installation. Ensure glides are in the correct position (e.g., "further back" setting if multiple holes are present).
Doors are misaligned or do not close properly.	Hinges are loose or incorrectly adjusted.	Adjust the screws on the hinges to align the doors. Refer to the manual for hinge adjustment details.
Strong odor from the cabinet.	New product odor from manufacturing materials.	Allow the cabinet to air out in a well-ventilated area for a few days. The odor should dissipate.

8. Specifications

Feature	Detail
Brand	ChooChoo
Model Number	SC2301-WH-NEW-1
Color	Pearl White
Material	Wood (Engineered Wood)
Product Dimensions (D x W x H)	11.81" x 15.7" x 66.9"
Item Weight	37.59 Pounds
Number of Doors	2
Number of Drawers	1

Feature	Detail
Additional Features	Adjustable Shelf, Anti-tip Kit Included
Installation Type	Freestanding, Floor Mount
Required Assembly	Yes



Image: A diagram illustrating the precise dimensions of the ChooChoo 67-inch Tall Storage Cabinet, including height, width, and depth.

9. Warranty & Support

For warranty information, replacement parts, or technical support, please contact ChooChoo customer service. Refer to your purchase documentation for specific warranty terms and contact details.

Manufacturer: ChooChoo

Contact: Please visit the ChooChoo Store on Amazon or refer to the contact information provided in your product packaging.

© 2026 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question