Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Driftless Ridge Supply 10x7 ft Golf Net

Driftless Ridge Supply 10x7 ft Golf Net Instruction Manual

Model: 10x7 ft Golf Net

Product Overview

The Driftless Ridge Supply 10x7 ft Golf Net is designed for golf practice, offering a robust solution for both indoor and outdoor use. This training aid allows golfers to practice full swings with real golf balls, chips, and irons, enhancing skill development in various environments.

Key Features:

- **Durable Construction:** Features 270D high-density netting and a 600D shock-absorbent target designed to withstand thousands of impacts from golf balls.
- **Dual-Turf Mat:** Includes a 20" x 16" mat with 35mm rough turf and 16mm fairway turf for varied practice scenarios.
- **Versatile Use:** Suitable for indoor setups (garages, basements) and outdoor environments (backyards).
- **Easy Assembly:** Designed for quick setup and takedown using fiberglass support rods and ground stakes.
- **Complete Kit:** Comes with the golf net, large target, dual-turf mat, 5 practice balls, a tee, 2 fiberglass rods, 4 stakes, and a carrying bag.

Setup Guide

Follow these steps to assemble your Driftless Ridge Supply Golf Net. Assembly typically takes 10-20 minutes.

1. **Unpack Components:** Carefully remove all items from the carrying bag. Verify that all components listed in the 'Set Includes' section are present.
2. **Assemble the Frame:** Connect the fiberglass rods to form the main support structure. Ensure all connections are secure.
3. **Stand Up the Net:** Drape the net over the assembled frame. The net is designed to fit the frame's curvature.
4. **Secure the Net:** Attach the net to the frame using the provided bungee loops or ties. Ensure the net is taut and evenly distributed. If setting up outdoors, use the ground stakes to secure the base of the net.
5. **Hang the Target:** Attach the large target cloth to the designated points inside the net. This target helps absorb impact and provides visual feedback for shot accuracy.



Image: Visual guide for the easy setup process of the golf net.



Image: All components included in the golf net training system.

Operating Your Golf Net

The golf net is designed for practicing various golf shots, from powerful drives to delicate chips. Ensure the net is properly set up and secured before use.

- **Positioning:** Place the net in an open area, ensuring sufficient clearance behind and to the sides for safety.
- **Using the Mat:** Utilize the dual-turf mat for realistic practice. The 16mm fairway turf is ideal for standard shots, while the 35mm rough turf simulates shots from thicker grass.
- **Shot Practice:** The net is suitable for drivers, irons, wedges, and chipping. Aim for the target cloth to maximize impact absorption and reduce ball bounce-back.
- **Safety:** Always maintain a safe distance from the net and ensure no one is in the path of a potential errant shot. Use the provided practice balls or real golf balls as desired.



Image: Golfer using the net for practice in a backyard setting.



Image: The golf net can be used for practice both indoors and outdoors.



Image: The included dual-turf mat for practicing from different lies.

Care and Maintenance

Proper care will extend the life of your golf net.

- **Cleaning:** The net and target cloth can be cleaned with a damp cloth and mild soap. Allow to air dry completely before storing.
- **Storage:** When not in use for extended periods, or during severe weather conditions (e.g., strong winds, heavy rain), disassemble the net and store it in its carrying bag in a dry, protected area.
- **Inspection:** Regularly inspect the netting, target cloth, and fiberglass rods for any signs of wear or damage. Replace damaged components as necessary to ensure safety and performance.



Image: Detail of the durable netting and target material.

Troubleshooting

Refer to the table below for common issues and their solutions.

Issue	Possible Cause	Solution
Net appears unstable or sways excessively.	Improper assembly; insufficient anchoring (outdoor use).	Ensure all fiberglass rods are fully connected and the net is taut. For outdoor use, firmly insert all ground stakes. Avoid use in high winds.

Issue	Possible Cause	Solution
Fiberglass poles break.	Excessive force during assembly/disassembly; impact from golf balls; structural fatigue.	Handle poles carefully. Ensure the net is properly tensioned to absorb ball impact. Avoid hitting directly at the poles. Contact customer support for replacement parts if needed.
Netting tears or shows significant wear.	Repeated high-velocity impacts in the same spot; sharp objects; material fatigue.	Ensure the target cloth is always in place to absorb the primary impact. Distribute shots across the net surface. Inspect for sharp edges on clubs. Consider replacing the net if damage compromises safety.
Ball bounces back too much.	Target cloth not properly installed or damaged; net not taut enough.	Verify the target cloth is securely attached and positioned correctly. Ensure the net is assembled tightly.

Product Specifications

Feature	Detail
Model	10x7 ft Golf Net
Dimensions	10 ft (Width) x 7 ft (Height)
Material	Fiberglass (rods), Nylon (netting), Polyester (target cloth)
Netting Density	270D
Target Cloth Density	600D
Mat Dimensions	20" x 16"
Mat Turf Heights	35mm (Rough), 16mm (Fairway)
Item Weight	8.82 Pounds
Color	Black
UPC	199284171459
ASIN	B0FLF9BYXF

Warranty and Support Information

This product is sold by Driftless Ridge Supply and fulfilled by Amazon. For any issues or concerns, please refer to Amazon's standard return policy, which typically allows for returns or replacements within 30 days of purchase.

For specific product support or inquiries regarding replacement parts, please contact Driftless Ridge Supply directly through the Amazon platform or their official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FLF9BYXF

More documents and user manuals: **https://manuals.plus/**