PROTKPETS CD Player-PK

PROTKPETS Portable CD Player with Bluetooth 5.3

Model: CD Player-PK

User Instruction Manual

1. Introduction

Thank you for choosing the PROTKPETS Portable CD Player. This device combines classic CD playback with modern connectivity options, including Bluetooth 5.3, 3.5mm AUX input, and USB playback. Designed for ease of use and portability, it delivers clear, high-fidelity sound for your listening pleasure. Please read this manual carefully before operating the device to ensure proper use and to maximize its lifespan.

2. Product Overview



Figure 2.1: PROTKPETS Portable CD Player (Brown)

Key Features:

- **Multi-Function:** CD player, Bluetooth speaker, 3.5mm AUX input, USB playback.
- **Retro Design:** Vintage walnut finish with an acrylic dust cover.
- **Wide Compatibility:** Supports CD, CD-R, CD-RM, CD-G, MP3, WMA, and WAV formats.
- **Hi-Fi Speakers:** Built-in dual stereo speakers for rich sound.
- **Portability:** Compact and lightweight design for easy transport.

Components and Controls:



Figure 2.2: Rear Ports and Top Controls

1. **CD Tray/Turntable:** Area for placing CDs.
2. **Tonearm Pick:** Used to initiate CD playback (visually resembles a tonearm).
3. **Control Buttons:** Play/Pause, Skip Forward, Skip Backward, Stop, Mode (M).
4. **Volume Knob:** Adjusts audio output level.
5. **ON/OFF Switch:** Power switch located at the rear.
6. **Type-C 5V/2A Port:** Power input for charging/operation.
7. **USB Port:** For USB drive playback.
8. **Audio Input Port (AUX IN):** Connect external audio sources.
9. **Audio Output Port (AUX OUT):** Connect to external speakers or headphones.

3. Setup

3.1 Powering the Device

- Connect the provided Type-C USB cable to the **Type-C 5V/2A Port** on the rear of the player.
- Connect the other end of the USB cable to a compatible USB power adapter (not included) or a powered USB port.
- Flip the **ON/OFF Switch** on the rear to the 'ON' position. The power indicator light will illuminate.

3.2 Initial Charge

For optimal performance, fully charge the internal battery before first use. The charging indicator light will show charging status (e.g., red for charging, green for fully charged, if applicable to your model).

4. Operating Instructions

4.1 CD Playback Mode

1. Ensure the player is powered on.
2. Gently lift the acrylic dust cover.
3. Place a CD (CD, CD-R, CD-RM, CD-G) onto the CD tray, ensuring it is centered.
4. Close the dust cover.
5. Press the **Mode (M)** button until 'CD' mode is selected.
6. Move the **Tonearm Pick** over the CD to initiate playback.
7. Use the **Play/Pause**, **Skip Forward**, **Skip Backward**, and **Stop** buttons to control playback.
8. Adjust the volume using the **Volume Knob**.



Figure 4.1: Top-Loading CD Mechanism

4.2 Bluetooth Mode

1. Ensure the player is powered on.
2. Press the **Mode (M)** button until 'BT' (Bluetooth) mode is selected. The Bluetooth indicator will flash, indicating it's ready for pairing.
3. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select 'PROTKPETS CD Player' (or similar name) from the list of devices to pair.
5. Once paired, the Bluetooth indicator will stop flashing and remain solid. You can now stream audio from your device to the CD player.
6. Adjust volume via the player's **Volume Knob** or your connected device.



Figure 4.2: Bluetooth 5.3 Connectivity

4.3 AUX Input Mode

1. Ensure the player is powered on.
2. Connect one end of a 3.5mm audio cable (not included) to the **Audio Input Port (AUX IN)** on the rear of the CD player.
3. Connect the other end of the audio cable to the headphone jack or audio output of your external device (e.g., MP3 player, computer).
4. Press the **Mode (M)** button until 'AUX' mode is selected.
5. Play audio from your external device.
6. Adjust volume via the player's **Volume Knob** and/or your external device.

4.4 USB Playback Mode

1. Ensure the player is powered on.

2. Insert a USB flash drive containing MP3, WMA, or WAV audio files into the **USB Port** on the rear of the player.
3. Press the **Mode (M)** button until 'USB' mode is selected.
4. The player will automatically detect and begin playing audio files from the USB drive.
5. Use the **Play/Pause**, **Skip Forward**, **Skip Backward**, and **Stop** buttons to control playback.
6. Adjust the volume using the **Volume Knob**.



Figure 4.3: Multi-functional Playback Options

4.5 Remote Control

The player includes a remote control for convenient operation from a distance. Functions typically include power on/off, mode selection, play/pause, skip tracks, and volume control. Refer to the remote control's specific button layout for detailed functionality.

5. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the player. For the acrylic dust cover, use a slightly damp cloth and avoid abrasive cleaners.
- **CD Care:** Handle CDs by their edges. Clean CDs with a soft, lint-free cloth, wiping from the center outwards.
- **Storage:** Store the player in a cool, dry place away from direct sunlight, extreme temperatures, and humidity.
- **Avoid Liquids:** Do not expose the player to water or other liquids.

6. Troubleshooting

Problem	Possible Cause	Solution
Player does not power on.	No power, battery drained, power switch off.	Check power connection, charge battery, ensure ON/OFF switch is on.
CD does not play or skips.	CD dirty/scratched, incorrect mode, tonearm not positioned.	Clean CD, select 'CD' mode, ensure tonearm is over the CD.
No sound.	Volume too low, incorrect mode, external device not connected properly.	Increase volume, select correct mode (CD/BT/AUX/USB), check cable connections.
Bluetooth not pairing.	Player not in BT mode, device too far, previously paired.	Ensure 'BT' mode is selected, move device closer, unpair from other devices.
USB playback not working.	USB drive not inserted correctly, unsupported file format, incorrect mode.	Reinsert USB drive, ensure files are MP3/WMA/WAV, select 'USB' mode.

7. Specifications

Feature	Detail
Brand	PROTKPETS
Model Name	CD Player-PK (also referred to as Cd-bt100)
Color	Brown
Connectivity Technology	Bluetooth 5.3
Supported Audio Formats	CD, MP3, WMA, WAV, CD-R, CD-RM, CD-G
Number of Discs	1
Headphones Jack	3.5mm Jack
Item Dimensions (L x W x H)	8"L x 6"W x 6"H
Item Weight	1.4 Pounds
Power Input	Type-C 5V/2A

8. Warranty and Support

This PROTKPETS CD Player comes with a**one-year warranty** from the date of purchase. For warranty claims, technical support, or any inquiries regarding your product, please contact PROTKPETS customer service. Keep your purchase receipt as proof of purchase for warranty validation.
Manufacturer: PROTKPETS

9. Product Videos

CD Player for Home - Overview

[redacted]

This video provides a general overview of the PROTKPETS Portable CD Player, demonstrating its features and functionality for home use. It highlights the compact design and ease of operation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question