Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LUMENA LM_FS-3Z

LUMENA Fan Stand 3Z Portable Oscillating Desk Fan User Manual

Model: LM_FS-3Z

1. Introduction

The LUMENA Fan Stand 3Z is a portable oscillating desk fan designed for versatile use in various environments, including home, office, or outdoor settings. It features a sleek matte design, a 4000mAh rechargeable battery for cordless operation, four speed settings, 120° automatic oscillation, and a timer function. This manual provides essential information for the safe and efficient use of your fan.



The LUMENA Fan Stand 3Z, highlighting its compact design and core features.

2. Package Contents

Please check the package for the following items:

- LUMENA Fan Stand 3Z Main Unit
- Type-C Charging Cable
- User Manual



Included items in the LUMENA Fan Stand 3Z package.

3. Product Features

- **Refined Design:** Sleek matte exterior with an anodized aluminum stand.
- **Adjustable Airflow:** 4 speed levels, 120° automatic oscillation, and 45° manual tilt (30° up, 15° down).
- **Quiet and Efficient:** 6-inch aerodynamic fan head and energy-efficient BLDC motor for minimal noise.
- **Wireless Operation:** 4000mAh rechargeable battery provides up to 20 hours of cordless use (at lowest speed).
- **Compact & Durable:** Stable tabletop use with easy portability, built for daily use.



The fan offers 120° oscillation for wide air coverage.



Key features including battery life, motor type, and speed levels.

Product Overview Video

Your browser does not support the video tag.

This video provides a comprehensive overview of the LUMENA Fan Stand 3Z, demonstrating its features and functionality.

4. Setup

4.1 Initial Charging

Before first use, fully charge the fan using the provided Type-C charging cable. Connect the cable to the fan's charging port and a compatible USB power adapter (not included). The charging indicator will show the charging status.

4.2 Placement

Place the fan on a stable, flat surface. Ensure there are no obstructions around the fan that could impede airflow or oscillation.

5. Operating Instructions

The LUMENA Fan Stand 3Z features a single jog dial for all controls.



The intuitive jog dial controls all fan functions.

5.1 Power On/Off and Speed Adjustment

- **To Power On:** Rotate the jog dial clockwise. The fan will start at speed level 1.
- **To Adjust Speed:** Continue rotating the jog dial clockwise to cycle through the 4 speed levels. Rotate counter-clockwise to decrease speed.
- **To Power Off:** Rotate the jog dial counter-clockwise until it clicks off.

5.2 Oscillation Function

- **To Activate/Deactivate Oscillation:** Press and hold the jog dial for approximately 2 seconds. The fan will begin or stop oscillating 120° horizontally.

5.3 Timer Function

- **To Set Timer:** While the fan is on, short press the jog dial to cycle through timer settings (1 hour, 2 hours, 4 hours). The fan will automatically turn off after the selected duration.

5.4 Manual Tilt Adjustment

The fan head can be manually tilted up to 30° upwards and 15° downwards to direct airflow vertically.

6. Maintenance

6.1 Cleaning the Fan Guard

To clean the fan blades and guard:

1. Ensure the fan is turned off and unplugged from any power source.
2. Gently hold both sides of the front fan guard.
3. Turn the front guard counter-clockwise to detach it.
4. Wipe the fan blades and guards with a soft, damp cloth. For stubborn dirt, use mild soap and water.
5. Ensure all parts are completely dry before reattaching the front guard by aligning and turning clockwise until secure.



Detaching the fan guard for easy cleaning.

6.2 Storage

When not in use for extended periods, store the fan in a cool, dry place, away from direct sunlight and extreme temperatures. Ensure the fan is clean and fully charged before storage.

7. Troubleshooting

Problem	Possible Cause	Solution
Fan does not turn on.	Battery is drained.	Charge the fan using the Type-C cable.
Fan does not oscillate.	Oscillation function not activated or control issue.	Press and hold the jog dial for 2 seconds to activate oscillation. If issue persists, turn the fan off and on again.
Weak airflow.	Fan speed is too low or battery is low.	Increase fan speed using the jog dial. Ensure the fan is fully charged.
Unusual noise during operation.	Obstruction in fan blades or loose parts.	Turn off and unplug the fan. Carefully check for any obstructions and remove them. Ensure the fan guard is securely attached.

8. Specifications

Feature	Detail
Brand	LUMENA
Model Name	Fan Stand 3Z
Model Number	LM_FS-3Z
Power Source	Battery Powered
Battery Capacity	4000mAh

Feature	Detail
Number of Speeds	4
Oscillation	120° Automatic
Tilt Adjustment	45° Manual (30° up, 15° down)
Control Method	Jog Dial / Push Button
Product Dimensions (D x W x H)	5.16"D x 6.5"W x 10.55"H
Wattage	6 watts
Indoor/Outdoor Usage	Indoor

9. Safety Information

- Do not insert fingers or foreign objects into the fan guard while the fan is operating.
- Keep the fan away from water and other liquids. Do not use in wet environments.
- Do not block the air intake or outlet.
- Keep out of reach of children and pets.
- Use only the provided charging cable or a certified Type-C cable for charging.
- Do not attempt to disassemble or repair the fan yourself. Contact customer support for assistance.

10. Warranty and Support

10.1 Warranty Information

LUMENA products are manufactured with high-quality standards. For specific warranty details, please refer to the warranty card included with your product or visit the official LUMENA website.

10.2 Customer Support

For any questions, technical support, or service inquiries, please visit theLUMENA Brand Store on Amazon or contact LUMENA customer service directly.

© 2026 LUMENA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FLQ5K7VX

More documents and user manuals: **https://manuals.plus/**