Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Futanwei DR03 Smartwatch Accessories

Futanwei DR03 Smartwatch Accessories

Quick Release Watch Band & Screen Protector User Manual

1. Introduction

This manual provides instructions for the installation, use, and maintenance of your Futanwei DR03 Smartwatch Accessories, which include a quick-release watch band and screen protectors. These accessories are designed to enhance the functionality and protection of compatible DR03 series smartwatches.

2. Package Contents

Please verify that all items are present in your package:

- 1 x Quick Release Watch Band (18mm)
- 3 x Smartwatch Screen Protector

3. Compatibility

These accessories are compatible with the following smartwatch models:

- YMZ DR03 Smart Watch
- KIBFLE DR03 Smart Watch
- PROTKPETS DR03 Smart Watch
- Yoever DR03 Smart Watch
- jevesen DR03 Smart Watch

Note: Not compatible with YMZ K53 (1.27 Inches) Smart Watch or other devices not listed above.

Figure 3.1: Visual representation of compatible smartwatch models and included accessories.

4. Setup

4.1. Watch Band Installation

1. Locate the quick-release spring bar on the back of the watch band.

2. Insert one end of the spring bar into the lug hole on your smartwatch.
3. Pull the quick-release lever to retract the other end of the spring bar.
4. Align the retracted end with the opposite lug hole and release the lever. Ensure both ends of the spring bar are securely seated in the lug holes.
5. Gently tug on the band to confirm it is securely attached before wearing.



Figure 4.1: Detail of the quick-release spring bar for easy band installation.

4.2. Screen Protector Application

The screen protectors are made of flexible TPU material.

1. **Clean the Screen:** Thoroughly clean your smartwatch screen with a microfiber cloth to remove any dust, smudges, or fingerprints. Ensure the screen is completely dry.
2. **Peel Off Layer 1:** Carefully peel off the protective film labeled 'Layer 1' or 'Back' from the adhesive side of the screen protector. Avoid touching the adhesive surface.
3. **Align and Apply:** Carefully align the screen protector with the edges of your smartwatch screen. Once aligned, gently lay it down from one edge to the other.
4. **Smooth Out Bubbles:** Use a soft card (like a credit card wrapped in a cloth) or your finger to gently push out any air bubbles towards the edges of the screen.
5. **Peel Off Layer 2:** Once the protector is applied and bubbles are removed, carefully peel off the top protective film labeled 'Layer 2' or 'Front'.



Figure 4.2: Screen protector applied to a smartwatch, demonstrating its features.

5. Operating

5.1. Watch Band Adjustment

The watch band features multiple holes, allowing you to adjust the length for a comfortable and secure fit on your wrist. Use the tang buckle to fasten the band at your desired length.

5.2. Screen Protector Usage

The TPU screen protector is designed to be highly responsive and touch-sensitive, ensuring normal operation of your smartwatch's touch functions. It also provides HD clarity for an unobstructed view of your screen.

6. Maintenance

6.1. Watch Band Care

- Clean the silicone band regularly with mild soap and water.
- Rinse thoroughly and dry with a soft cloth.
- Avoid exposure to harsh chemicals or extreme temperatures, which may damage the material.

6.2. Screen Protector Care

- Wipe the screen protector with a soft, lint-free cloth to remove smudges or dust.
- Avoid using abrasive materials or harsh cleaning agents, which can scratch or damage the protector's oleophobic

coating.

7. Troubleshooting

7.1. Watch Band Issues

- **Band not attaching securely:** Ensure the quick-release spring bars are fully seated in the lug holes. Check for any obstructions in the lug holes.
- **Difficulty detaching band:** Ensure the quick-release lever is fully pulled back when attempting to remove the band.

7.2. Screen Protector Issues

- **Bubbles under the protector:** Most small bubbles will disappear within 24-48 hours. For larger bubbles, gently lift the nearest edge of the protector and re-apply, pushing the bubble out with a soft card. Ensure the screen is clean before re-application.
- **Protector not adhering:** Ensure the screen was thoroughly cleaned and dry before application. Avoid touching the adhesive side during installation.
- **Reduced touch sensitivity:** Ensure the protector is correctly aligned and free of large air bubbles. If issues persist, re-apply or replace the protector.

8. Specifications

Product Type	Smartwatch Accessories (Watch Band & Screen Protector)
Watch Band Material	High-quality Soft Silicone
Buckle Material	Stainless Steel
Clasp Type	Tang Buckle
Watch Band Lengths	86 mm and 119 mm
Screen Protector Material	Flexible TPU (Not Tempered Glass)
Screen Protector Features	HD Clear, Oleophobic, Hydrophobic, Anti-fingerprint, Anti-scratch, Touch Sensitive

9. Warranty and Support

For warranty information and customer support, please refer to the original product listing or contact the seller directly. Keep your purchase receipt for any warranty claims.

© 2025 Futanwei. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FLXD3GQ4

More documents and user manuals: **https://manuals.plus/**