Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KIPMAX X20

KIPMAX X20 Cordless Vacuum Battery Instruction Manual

MODEL: X20

Safety | Contents | Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty

1. Safety Instructions

Please read all instructions carefully before using the KIPMAX X20 Cordless Vacuum. Retain this manual for future reference.

- Do not use the appliance on wet surfaces or to pick up liquids.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Use only the charger supplied by the manufacturer to recharge the battery.
- Do not use the appliance if any part is damaged. Contact customer support for assistance.
- Ensure the filter is correctly installed before operation.
- This appliance is for household use only.

2. Package Contents

Verify that all components are present in the package:

- KIPMAX X20 Main Unit (Handheld Vacuum)
- Telescopic Extension Tube
- Motorized Floor Brush
- Crevice Tool
- 2-in-1 Brush Tool
- Wall-Mount Dock
- Power Adapter
- User Manual
- Spare Filter (Cartridge Type)



Figure 2.1: KIPMAX X20 Cordless Vacuum with included accessories. The image displays the main handheld unit, extension tube, floor brush, and various smaller attachments.

3. Setup

3.1 Battery Installation and Charging

1. Align the battery pack with the slot on the main unit.
2. Slide the battery pack into place until it clicks securely.
3. Connect the power adapter to the charging port on the battery pack.
4. Plug the adapter into a wall outlet. The battery indicator lights will illuminate during charging. A full charge takes approximately 4 hours.

3.2 Assembling the Vacuum

1. Attach the telescopic extension tube to the main unit by aligning the connectors and pushing until it clicks.

2. Attach the motorized floor brush to the other end of the telescopic tube.
3. Alternatively, attach any desired accessory (crevice tool, 2-in-1 brush) directly to the main unit or the telescopic tube.

3.3 Wall-Mount Dock Installation

The wall-mount dock provides convenient storage and charging. Choose a suitable location near a power outlet.

1. Mark the desired position for the dock on the wall.
2. Drill holes and insert wall anchors if necessary.
3. Secure the wall-mount dock using screws.
4. Place the vacuum onto the dock for storage and charging.



Figure 3.1: The KIPMAX X20 Cordless Vacuum mounted on its wall dock, illustrating convenient storage and charging.

4. Operating Instructions

4.1 Power On/Off and Suction Modes

1. Press the power button on the top of the main unit to turn the vacuum on.
2. The LED display will show the current battery level and suction mode.
3. Press the mode button to cycle through available suction modes: Low, Medium, and High (Turbo).
4. Press the power button again to turn the vacuum off.

4.2 Using Attachments

- **Motorized Floor Brush:** Ideal for cleaning hard floors and carpets. The brush roll effectively picks up debris.
- **Crevice Tool:** Use for narrow gaps, corners, and hard-to-reach areas like between sofa cushions or car seats.
- **2-in-1 Brush Tool:** Features both a brush and a wide nozzle. Use the brush for delicate surfaces like upholstery or

curtains, and the nozzle for general dusting.

4.3 Adjusting Telescopic Tube Length

To adjust the length of the telescopic tube, press the release button on the tube and extend or retract it to the desired length. Release the button to lock it in place.

Video 4.1: This video demonstrates the assembly and various operational modes of a cordless vacuum, including the use of different attachments and suction settings. It highlights the versatility and ease of use for different cleaning tasks.

Video 4.2: This video showcases the practical convenience of cordless vacuum cleaners in daily life, demonstrating quick cleanups and adaptability to various household surfaces and situations.

---

5. Maintenance

5.1 Emptying the Dustbin

1. Ensure the vacuum is turned off.
2. Locate the dustbin release button on the main unit.
3. Press the button to open the dustbin flap and empty contents into a trash receptacle.
4. Close the dustbin flap securely until it clicks.

5.2 Cleaning Filters

Regular filter cleaning is essential for maintaining optimal suction power. It is recommended to clean filters after every few uses or when suction noticeably decreases.

1. Twist and pull to remove the dustbin from the main unit.
2. Remove the pre-filter and HEPA filter from the dustbin.
3. Tap the filters gently to remove loose dust and debris.
4. Rinse the filters under running water until the water runs clear. Do not use detergent.
5. Allow filters to air dry completely for at least 24 hours before reassembling. Ensure they are completely dry to prevent damage.
6. Reassemble the filters and dustbin, then reattach to the main unit.



Figure 5.1: The cartridge filter for the KIPMAX X20 Cordless Vacuum, designed for efficient dust and debris capture. Regular cleaning is vital for performance.

5.3 Cleaning the Brush Roll

Periodically check the motorized floor brush for tangled hair or debris. Use scissors to carefully cut away any tangled hair and remove it.

6. Troubleshooting

If you encounter issues with your KIPMAX X20, refer to the following common problems and solutions:

- **No Power:** Check if the battery is fully charged. Ensure the battery pack is securely installed.
- **Low Suction:** Empty the dustbin. Clean or replace the filters. Check the telescopic tube and brush head for blockages. Ensure all connections are secure.
- **Brush Roll Not Rotating:** Check for tangled hair or debris obstructing the brush roll. Ensure the brush head is correctly attached.
- **Unusual Noise:** Turn off the vacuum immediately. Check for any foreign objects caught in the brush roll or air ducts.

Video 6.1: This video provides guidance on common issues that may prevent a cordless vacuum from working, offering troubleshooting steps to resolve problems like low suction or blockages.

7. Specifications

- **Brand:** KIPMAX
- **Model Name:** X20
- **Special Feature:** Cordless
- **Filter Type:** Cartridge
- **Power Source:** Battery Powered
- **Voltage:** 220 Volts
- **Capacity:** 0.5 Liters
- **Recommended Uses:** Carpeted floors, Hardwood floors
- **Form Factor:** Handheld
- **Color:** Gold
- **Manufacturer:** KIPMAX
- **Item Dimensions L x W x H:** 5L x 5W x 5H Centimetres

8. Warranty and Support

The KIPMAX X20 Cordless Vacuum comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your package or contact customer support.

Customer Support:

- **Email:** supportca@kipmax.com

Please have your model number (X20) and purchase date ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FLXF4KNL

More documents and user manuals: **https://manuals.plus/**