Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Voukad H1906

Voukad H1906 Electric Beard Trimmer User Manual

Model: H1906

Introduction

Thank you for choosing the Voukad H1906 Electric Beard Trimmer. This all-in-one grooming kit is designed for precise trimming of beards, mustaches, face, and ear hair, offering versatility for various grooming needs. This manual provides essential information for the safe and effective use, maintenance, and care of your trimmer.

Safety Information

Please read all safety instructions before use.

- Ensure there is no water in the charging port before connecting the charger.
- Verify that the blade is correctly installed before each use to prevent injury.
- This appliance is waterproof (IPX7 rated) and can be used in the shower, but ensure the charging port is dry before charging.
- Keep the appliance out of reach of children.
- Do not disassemble or attempt to repair the trimmer yourself. Contact customer support for assistance.

Package Contents

Your Voukad H1906 Electric Beard Trimmer package includes the following items:

- Voukad H1906 Electric Beard Trimmer unit
- U-shaped beard trimmer head
- Detailer trimmer head
- Nose hair trimmer head
- Adjustable guide combs (2 units, providing 40 length settings from 0.5mm to 20mm)
- USB-C Charging Cable
- Soft Pouch for storage and travel
- Cleaning Brush



Image: The Voukad H1906 trimmer with its various attachments, including the U-shaped trimmer, detailer, nose trimmer, guide combs, USB-C cable, and soft pouch, displayed alongside its packaging.

Product Overview

The Voukad H1906 is a versatile grooming tool designed for precision and convenience. Key features include:

- **All-in-One Grooming:** Suitable for beard, face, neck, mustache, head, chest, legs, and nose hair.

- **40 Length Settings:** Adjustable from 0.5mm to 20mm in 0.5mm steps using two guide combs and the integrated ProWheel.
- **Ultra-Sharp Blades:** Engineered for a smooth, even, and comfortable shave without pulling or irritation.
- **IPX7 Waterproof:** Allows for convenient use in the shower and easy cleaning under running water.
- **Long-Lasting Battery:** Provides up to 240 minutes of cordless runtime on a single 1.5-hour charge via USB-C.
- **Travel Lock Function:** Prevents accidental activation during transport.



Image: A close-up of the Voukad H1906 trimmer, illustrating its key features such as the ProWheel for length adjustment, waterproof

design, long battery life, and travel lock function.

Setup

1. Initial Charging

1. Before first use, ensure the trimmer is fully charged.
2. Connect the provided USB-C charging cable to the trimmer's charging port.
3. Plug the other end of the USB-C cable into a compatible USB power adapter (not included).
4. The battery indicator lights will illuminate to show charging progress. A full charge takes approximately 1.5 hours and provides up to 240 minutes of runtime.
5. Ensure the charging port is dry before connecting the cable.

2. Attaching/Detaching Trimmer Heads and Guide Combs

- To attach a trimmer head (U-shaped, detailer, or nose trimmer), align the head with the trimmer body and press firmly until it clicks into place.
- To detach, gently push the head away from the body.
- To attach a guide comb, slide it onto the desired trimmer head until it locks securely.
- To remove a guide comb, gently slide it off.



Image: A close-up of the Voukad H1906 trimmer's ProWheel, demonstrating the 40 precision length settings from 0.5mm to 20mm, controlled by a fingertip.

Operating Instructions

1. Powering On/Off

- Press the power button once to turn the trimmer on.
- Press the power button again to turn the trimmer off.

2. Adjusting Trimming Length

- With a guide comb attached, rotate the ProWheel dial on the trimmer body to select your desired trimming length.
- The dial allows for precise adjustments from 0.5mm to 20mm in 0.5mm increments.

3. Trimming Techniques

- **Beard and Mustache:** Use the U-shaped trimmer head with a guide comb. Start with a longer setting and gradually reduce it until the desired length is achieved. Move the trimmer against the direction of hair growth for an even cut.
- **Detailing and Edging:** Use the detailer trimmer head without a guide comb for sharp lines, shaping, and intricate designs.
- **Nose and Ear Hair:** Attach the nose hair trimmer head. Gently insert the trimmer tip into the nostril or ear canal and move it in a circular motion to trim unwanted hair.
- **Body Hair:** The U-shaped trimmer with a guide comb can be used for chest, legs, and underarms. Adjust the length setting as needed.

4. Travel Lock Function

- To activate the travel lock, press and hold the power button for 3 seconds until the indicator light flashes. This prevents accidental activation.
- To deactivate, press and hold the power button for 3 seconds again until the indicator light stops flashing.



Image: The Voukad H1906 trimmer shown in use for facial hair, chest hair, nose hair, underarm hair, detailing, and arm/leg hair, demonstrating its multi-purpose functionality.

Maintenance

1. Cleaning

- The trimmer is IPX7 waterproof. After each use, detach the trimmer head and rinse it thoroughly under running water.

- You can also rinse the entire trimmer body under water, ensuring the charging port is closed and dry before any subsequent charging.
- Use the provided cleaning brush to remove any stubborn hair clippings from the blades and inside the trimmer head.
- Allow all parts to air dry completely before reassembling or storing.

2. Blade Care

- For optimal performance and longevity, it is recommended to periodically lubricate the blades with a drop of light machine oil (not included) after cleaning and drying.
- The blades are designed to be ultra-sharp and replaceable. If you notice a decrease in cutting performance, consider replacing the blade head.



Image: The Voukad H1906 trimmer being rinsed under a stream of water, demonstrating its IPX7 waterproof capability for easy cleaning.

Troubleshooting

- **Trimmer not turning on:** Ensure the battery is charged. Check if the travel lock function is activated (deactivate by holding the power button for 3 seconds).
- **Poor cutting performance or pulling hair:** The blades may be dull or clogged with hair. Clean the trimmer head and blades thoroughly. Consider lubricating the blades or replacing the blade head if performance does

not improve.

- **Trimmer not charging:** Ensure the USB-C cable is securely connected to both the trimmer and the power source. Verify the charging port is dry and free of debris. Try a different USB-C cable or power adapter.
- **Excessive noise or vibration:** Ensure the trimmer head is correctly attached and secured. Clean the blades and check for any obstructions.

If you encounter issues not listed here or if troubleshooting steps do not resolve the problem, please contact customer support.

Specifications

Feature	Specification
Model Number	H1906
Brand	Voukad
Power Source	Battery Powered (1 x 12V battery included)
Charging Type	USB-C
Charging Time	Approx. 1.5 hours
Runtime	Up to 240 minutes
Waterproof Rating	IPX7
Length Settings	40 (0.5mm to 20mm)
Item Weight	0.39 Kilograms (13.76 ounces)
Package Dimensions	8.62 x 5.2 x 2.24 inches
Recommended Uses	Beard, Chest, Face, Mustache, Neck

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact Voukad customer service directly. Keep your proof of purchase for any warranty claims.
For further assistance, please visit the official Voukad website or contact their customer support channels.

© 2025 Voukad. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FM3TBZYL

More documents and user manuals: **https://manuals.plus/**