Prasky BK688

Prasky 2400W/1000W Blender & Grinder Combo (Model BK688) User Manual

Model: BK688

Safety Overview Setup Operation Maintenance Troubleshooting Specifications Warranty

1. Important Safety Information

Please read all instructions carefully before using your Prasky Blender. Failure to follow these safety guidelines may result in injury or damage to the appliance.

General Safety Precautions:

- Always ensure the blender is unplugged before assembling, disassembling, or cleaning.
- Do not immerse the motor base in water or any other liquid.
- Keep hands and utensils out of the container while blending to reduce the risk of severe personal injury.
- Blades are sharp. Handle with extreme care when cleaning or emptying the container.
- Never operate the blender with damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

Overheating Protection:

The Prasky Blender is equipped with a thermal protection system to prevent overheating. If the motor overheats, the blender will automatically shut off. Allow the unit to cool down for approximately 15-20 minutes before attempting to use it again.



Image: Prasky Blender highlighting its features, including overheating protection.

2. Product Overview

The Prasky Blender & Grinder Combo is a versatile kitchen appliance designed for a variety of tasks, from making smoothies to grinding grains. It features a powerful motor and durable, BPA-free containers.

Components:

- **Motor Base:** The main unit housing the powerful 2400W/1000W motor and control panel.
- **Large Container (68oz/2L):** Ideal for blending smoothies, shakes, frozen desserts, and soups. Made from food-grade, BPA-free, shatterproof, heat-resistant, and scratch-resistant material.
- **Small Container (Grinder Attachment):** Designed for grinding coffee beans, nuts, spices, and grains.
- **Lid with Removable Cap:** Secures the container during operation and allows for adding ingredients while blending.
- **Tamper:** Used to push ingredients down towards the blades for thick mixtures.



Image: Overview of the Prasky Blender's main components and material benefits.

Key Features:

- **High-Performance Motor:** 3.0-HP motor (up to 25000 RPM) for efficient blending.
- **6-Blade Stainless Steel System:** Designed to crush ice, fruits, and vegetables into smooth textures.
- **BPA-Free Containers:** Ensures safety for food preparation.
- **Variable Speed Control:** Adjustable dial for precise texture control.
- **Pulse Function:** For quick bursts of power and chopping.
- **Multi-functional:** Replaces up to 6 kitchen appliances (blend, crush, chop, grind, puree, liquefy).



Image: Visual representation of the blender's 10-in-1 capabilities, including food processing, juicing, and ice crushing.

3. Getting Started: Setup

Unpacking:

1. Carefully remove all components from the packaging.
2. Remove any protective materials or stickers.
3. Wash the containers, lids, and tamper with warm, soapy water before first use. Rinse thoroughly and dry.

Assembly:

1. Place the motor base on a clean, dry, and stable surface.
2. Align the desired container (large or small) onto the motor base. Ensure it is securely seated.
3. Add your ingredients to the container. Do not overfill past the maximum fill line.
4. Place the lid securely onto the container. Ensure the removable cap is in place.

5. Plug the power cord into a grounded electrical outlet.

Video: This video demonstrates the unboxing and assembly of the Prasky Professional Blender, showing how to set up the main unit and attach the containers and lids.

4. Operating Your Prasky Blender

Control Panel:

The control panel features an ON/OFF switch, a variable speed dial, and a Pulse switch. The speed dial offers settings for Fruits, Milkshake, Sand Ice, and Grains, along with a range from Low Speed to High Speed (MAX).



Image: Close-up of the Prasky Blender's control panel, showing the ON/OFF switch, speed dial with various settings, and Pulse function.

General Blending:

1. Ensure the blender is properly assembled and plugged in.
2. Add ingredients to the container. For best results, add liquids first, then soft ingredients, and finally hard or frozen

ingredients.

3. Secure the lid and ensure the removable cap is in place.
4. Turn the ON/OFF switch to the 'ON' position.
5. Select your desired speed or function using the central dial (e.g., Fruits for smoothies, Sand Ice for crushing ice). You can adjust the speed from Low to MAX.
6. For quick bursts of power, use the 'Pulse' switch. Hold it down for desired duration and release.
7. Once blending is complete, turn the ON/OFF switch to 'OFF' and unplug the unit before removing the container.

Using the Large Container (68oz/2L):

This container is ideal for preparing larger batches of:

- Smoothies and Shakes
- Frozen Desserts
- Hot Soups (ensure ingredients are not boiling hot when adding)
- Nut Butters, Sauces, Hummus, Dips, and Fresh Juices



Image: The Prasky Blender with its large container, suitable for blending smoothies, ice, shakes, and juices.

Using the Small Container (Grinder Attachment):

The smaller container is specifically designed for dry grinding tasks:

- Grinding Coffee Beans
- Processing Nuts
- Grinding Spices
- Milling Grains



Image: The Prasky Blender with its grinder attachment, ideal for processing coffee beans, nuts, and spices.

5. Care and Maintenance

Self-Cleaning Function:

For quick and easy cleaning of the large container:

1. Add a small amount of dish soap and warm water to the container.
2. Secure the lid.
3. Turn the ON/OFF switch to 'ON'.
4. Adjust the speed dial to 'High Speed' or use the 'Pulse' function for 30-60 seconds.
5. Rinse the container thoroughly with clean water.



Image: Step-by-step guide illustrating the self-cleaning process of the Prasky Blender.

Manual Cleaning:

- **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse in water.
- **Containers, Lids, and Tamper:** These parts are dishwasher-safe. For hand washing, use warm, soapy water and a non-abrasive brush for the blades. Handle blades with extreme caution.
- Ensure all parts are completely dry before storing or reassembling.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Blender does not turn on.	Not plugged in; power switch off; container not properly seated; thermal protection activated.	Ensure unit is plugged in and power switch is ON. Check that the container is securely placed on the base. If motor overheated, allow 15-20 minutes to cool.
Ingredients not blending smoothly.	Too little liquid; too many ingredients; ingredients are too large or hard.	Add more liquid. Reduce the amount of ingredients. Cut ingredients into smaller pieces. Use the tamper to push ingredients towards the blades. Increase speed or use pulse function.
Motor smells or smokes.	Overloading; prolonged use; thermal protection activated.	Immediately turn off and unplug the blender. Allow the unit to cool down for 15-20 minutes. Reduce load for future use. If smoking persists, contact customer support.
Lid leaks during blending.	Lid not properly secured; container overfilled.	Ensure the lid is firmly pressed onto the container. Do not fill past the maximum fill line.

7. Technical Specifications

Feature	Detail
Brand	Prasky
Model Number	BK688
Power Source	AC (2400W/1000W)
Motor Speed	Up to 25,000 RPM
Large Container Capacity	68 ounces (2 Liters / 3000 Milliliters)
Container Material	BPA-Free, Shatterproof, Heat Resistant, Scratch Resistant
Special Features	Adjustable Speed Control, Pulse Function, Thermal Protection System
Product Dimensions	7.9"D x 6.7"W x 7.1"H
Item Weight	7.92 pounds

8. Warranty and Customer Support

Warranty Information:

Prasky products are manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship under normal household use. Please refer to the warranty card included in your product packaging for specific terms and conditions, including the duration of coverage.

Customer Support:

For product inquiries, usage guidance, or assistance with any issues, please contact our customer support team. We are committed to providing excellent after-sales service.

- **Email:** support@praskylife.com
- **Phone:** 1-866-228-7981
- **Website:** praskylife.com

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question