Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Avrsol DRFG-1

Avrsol Kids Play Tent with Mat

Model: DRFG-1

Introduction

Thank you for choosing the Avrsol Kids Play Tent with Mat. This play tent is designed to provide a fun and imaginative space for children indoors or outdoors. It features a spacious interior, a comfortable padded mat, and durable construction for long-lasting enjoyment. Please read this manual carefully before assembly and use to ensure proper setup and safe operation.

Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

- Always supervise children when they are playing in or around the tent.
- Keep the tent away from open flames, heat sources, and electrical appliances.
- Ensure all poles are securely connected and the fabric is properly attached before use.
- Do not allow children to hang on the tent structure.
- Inspect the tent regularly for any damage or wear. Discontinue use if damaged.
- This tent is not intended for use as a climbing structure.

Package Contents

Before assembly, please verify that all components are present:

- Play Tent Fabric Cover
- Padded Mat
- Set of Sturdy Support Poles
- Connectors for Poles
- Storage Bag (if included)

Setup Instructions

Assembly of the Avrsol Kids Play Tent is designed to be simple and quick. Follow these steps:

1. **Unpack Components:** Carefully remove all items from the packaging and lay them out on a clean, flat surface.

2. **Assemble Poles:** Connect the support poles using the provided connectors. Ensure each connection is firm and secure. Refer to the diagram for the correct pole configuration.
3. **Insert Poles into Fabric:** Slide the assembled poles into the designated sleeves or pockets within the tent fabric cover.
4. **Secure the Structure:** Once all poles are in place, gently raise the tent and ensure the fabric is taut and evenly distributed over the frame. Secure any ties or fasteners on the fabric to the poles as instructed.
5. **Place the Mat:** Lay the padded mat inside the tent for a comfortable play area.



Image: Fully assembled play tent, highlighting its spacious design and mesh curtains.

Operating Instructions

The Avrsol Kids Play Tent is designed for imaginative play and relaxation. Here are some tips for optimal use:

- **Creative Play:** Encourage children to use the tent as a fort, a reading nook, a secret hideaway, or a space for role-playing games.
- **Comfortable Space:** The included padded mat provides a soft and comfortable surface for sitting, lying down, or

playing.

- **Ventilation:** The tent features mesh elements (curtains, windows) to allow for gentle airflow, ensuring a comfortable environment.
- **Indoor/Outdoor Use:** The tent is suitable for both indoor playrooms and outdoor adventures in a backyard or garden. Ensure it is placed on a flat, stable surface.



Image: Children enjoying playtime inside the tent, illustrating its capacity and appeal.



Image: A child reading inside the tent, showcasing its suitability for quiet activities.

Maintenance

Proper care will extend the life of your play tent:

- **Cleaning the Fabric:** The tent fabric and padded mat are machine washable. Use a gentle cycle with cold water and mild detergent. Do not bleach. Air dry thoroughly.
- **Cleaning Poles:** Wipe poles with a damp cloth if they become dirty. Ensure they are dry before storage.
- **Storage:** When not in use, disassemble the tent and store all components in the provided storage bag in a cool, dry place away from direct sunlight.



Image: Detail of the comfortable, machine-washable padded mat.

Troubleshooting

Problem	Possible Cause	Solution
Tent is unstable or wobbly.	Poles not fully connected or inserted.	Ensure all pole connectors are securely fastened and poles are fully seated in their sleeves. Check that the tent fabric is evenly stretched.
Fabric appears loose or saggy.	Poles not correctly positioned or fabric not secured.	Re-check pole assembly and ensure all fabric ties or fasteners are attached to the frame.
Difficulty disassembling.	Poles are tightly fitted.	Gently twist and pull poles apart. Do not force.

Specifications

- **Model Number:** DRFG-1
- **Brand:** Avrsol
- **Material:** Polycotton
- **Color:** Brown
- **Product Dimensions:** 144.78 x 90.17 x 134.62 cm (57 x 35.5 x 53 inches)
- **Item Weight:** 4.15 kg (9.14 lbs)
- **Assembly Required:** Yes
- **Batteries Required:** No
- **Manufacturer Recommended Age:** 3 years and up
- **UPC:** 786750427600



Image: The play tent's exterior, highlighting its brown and white color scheme.

Warranty Information

Avrsol products are manufactured with quality and durability in mind. While specific warranty details are not provided in this manual, please retain your proof of purchase. For any manufacturing defects or issues, please contact Avrsol customer support within a reasonable timeframe from the date of purchase.

Customer Support

For further assistance, questions, or concerns regarding your Avrsol Kids Play Tent, please refer to the retailer's customer service contact information or visit the official Avrsol website for support options.
We value your feedback and are committed to providing a positive experience with our products.

© 2026 Avrsol. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FMDZ81MZ

More documents and user manuals: **https://manuals.plus/**