POXURIO LDQXJ-HX

POXURIO Cordless Washer LDQXJ-HX User Manual

Model: LDQXJ-HX | Brand: POXURIO

1. Important Safety Information

Please read all instructions carefully before operating the POXURIO Cordless Washer. Failure to follow these instructions may result in electric shock, fire, and/or serious injury.

- Always wear appropriate personal protective equipment, including eye protection, when operating the pressure washer.
- Do not direct the water spray at people, pets, electrical devices, or the unit itself. High-pressure spray can cause injury.
- Ensure the battery is fully charged before use and properly secured in its compartment.
- Keep children and bystanders away from the operating area.
- Do not operate the pressure washer in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Disconnect the battery pack before performing any adjustments, changing accessories, or storing the pressure washer.
- Use only POXURIO recommended accessories and replacement parts.
- Store the unit indoors in a dry, secure location when not in use.

2. Product Overview

The POXURIO Cordless Washer is a portable, battery-powered pressure washer designed for various cleaning tasks. It features a foldable design for easy storage and transport, multiple pressure modes, and a large water tank.

2.1 Components and Parts Diagram

Familiarize yourself with the components of your cordless washer using the diagram below.



Image: Numbered diagram showing the various parts of the POXURIO Cordless Washer, including the jet nozzle, high-pressure gun, safety lock, trigger, water hose interfaces, water reservoir, battery pack cover, battery platform, pressure/power levels display, adjustable button, ON/OFF button, and universal wheels.

Parts Designation

No.	Designation	No.	Designation
1	2-in-1 Jet Nozzle	11	Switch on the Cover
2	Pushing Button	12	Water Reservoir
3	High Pressure Gun	13	Cover for Battery Pack
4	Safety Lock	14	Battery Platform
5	Trigger	15	Water Hose Interface on the Bucket
6	Self-Locking Button	16	Pressure & Power Levels Display
7	Water Hose Interface on the Gun	17	Pressure Levels Adjustable Button
8	3m/15FT High Pressure Hose	18	ON/OFF Button
9	Water Hose Interface on the Gun	19	Universal Wheels with Brake
10	3m/15FT High Pressure Hose	20	Universal Wheels without Brake

2.2 Included Components

The following items are included with your POXURIO Cordless Washer:



Image: A visual representation of the complete package contents, including the cordless pressure sprayer, 10ft high-pressure hose, charging cable, user manual, 4 wheels, foam tank, two 5.0Ah battery packs, and high-pressure gun.

- Cordless Pressure Sprayer Unit
- 10FT High-Pressure Hose
- Charging Cable
- User Manual (this document)
- 4 Universal Wheels
- Foam Tank
- Two 5.0Ah Battery Packs
- High Pressure Gun with 2-in-1 Jet Nozzle

3. Setup Instructions

Follow these steps to set up your POXURIO Cordless Washer for first use.

3.1 Unfolding the Unit

The unit is designed to be foldable for compact storage. To unfold, gently pull the top section upwards until it locks into place. To fold, press the release buttons (if present) and push the top section down.



Image: Comparison of the POXURIO Cordless Washer in its compact, folded state (5.5 inches height) and its extended, unfolded state (15.75 inches height), demonstrating its portable design.

3.2 Attaching the Wheels

Attach the four universal wheels to the designated slots on the bottom of the main unit. Ensure two wheels with brakes are placed at the front for stability.

3.3 Battery Installation and Charging

Insert a charged 5.0Ah battery pack into the battery platform located under the cover. Ensure it clicks securely into place. Charge both battery packs fully before first use using the provided charging cable.

Your browser does not support the video tag.

Video: This video demonstrates the assembly and initial setup of the POXURIO Portable Pressure Washer, including battery installation and connecting the hose.

3.4 Connecting the High-Pressure Hose and Nozzle

1. Connect one end of the 10FT high-pressure hose to the water hose interface on the main unit (15).
2. Connect the other end of the high-pressure hose to the water hose interface on the high-pressure gun (7 or 9).
3. Attach the 2-in-1 jet nozzle to the end of the high-pressure gun. Ensure it is securely twisted into place.

3.5 Filling the Water Reservoir

Open the cover of the water reservoir (12) and fill it with clean water. The tank has a capacity of 4.5 gallons (15L). Close the cover securely after filling.



Image: The 15L (4.5 Gallon) water tank of the POXURIO Cordless Washer, highlighting its capacity and the two 5000mAh batteries for extended runtime.

4. Operating Instructions

Learn how to operate your POXURIO Cordless Washer effectively for various cleaning tasks.

4.1 Powering On/Off

- To power on the unit, press the ON/OFF button (18) on the control panel. The pressure and power levels display (16) will illuminate.
- To power off, press the ON/OFF button again.

4.2 Adjusting Pressure Modes

The unit features 4 adjustable pressure modes. Use the Pressure Levels Adjustable Button (17) to cycle through the modes (M1, M2, M3, M4) to suit your cleaning needs.



Image: Visual representation of the four distinct pressure modes (M1: 1-1.5Mpa, M2: 2-2.0Mpa, M3: 3-2.5Mpa, M4: 4-3.0Mpa) and their corresponding spray patterns, demonstrating the versatility of the pressure washer.

- **M1 (1-1.5Mpa):** Gentle spray for delicate surfaces or rinsing.
- **M2 (2-2.0Mpa):** Medium spray for general cleaning.
- **M3 (3-2.5Mpa):** Stronger spray for tougher dirt.
- **M4 (4-3.0Mpa):** Maximum pressure for stubborn grime.

4.3 Using the High-Pressure Gun

1. Point the nozzle away from yourself and others.
2. Disengage the safety lock (4).
3. Press the trigger (5) to start the water flow.
4. Release the trigger to stop the water flow. Engage the safety lock when not spraying.

4.4 Applications

The POXURIO Cordless Washer is suitable for a wide range of cleaning tasks:



Image: A collage illustrating diverse uses for the POXURIO Cordless Washer, including mountain bike cleaning, house cleaning, general outdoor cleaning, and pet cleaning.

- Car washing
- Patio and deck cleaning
- Camping equipment cleaning
- Bicycle cleaning
- Pet washing
- Garden furniture cleaning

Your browser does not support the video tag.

Video: A detailed demonstration of the 750PSI Portable Pressure Washer Cordless, showcasing its features and various cleaning applications.

Your browser does not support the video tag.

Video: This video provides an overview of the 750PSI Portable Pressure Washer, highlighting its portability and effectiveness for outdoor cleaning tasks.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your pressure washer.

5.1 Cleaning the Unit

- After each use, drain any remaining water from the reservoir and hose.
- Wipe down the exterior of the unit with a damp cloth. Do not use harsh chemicals.
- Clean the nozzle regularly to prevent blockages.

5.2 Battery Care

- Store batteries in a cool, dry place away from direct sunlight and extreme temperatures.
- Do not store batteries in a discharged state for extended periods. Recharge them periodically.
- If a battery pack is damaged, discontinue use and dispose of it properly according to local regulations.

5.3 Storage

- Ensure the unit is clean and dry before storing.
- Fold the unit into its compact form for space-saving storage.
- Store the pressure washer, batteries, and accessories in a secure, dry, and frost-free environment.

6. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Unit does not turn on	Battery not charged or improperly installed; ON/OFF button not pressed.	Ensure battery is charged and correctly inserted. Press the ON/OFF button firmly.
No water pressure or weak spray	Water tank empty; hose kinked or blocked; nozzle clogged; air in the system.	Refill water tank. Check hose for kinks or blockages. Clean the nozzle. Prime the pump by running water through the system without the nozzle attached for a few seconds.
Water leaking from gun or connections	Loose connections; damaged O-rings or seals; faulty nozzle.	Tighten all connections. Inspect O-rings and seals for wear and replace if necessary. Check nozzle for damage.
Short battery runtime	Battery not fully charged; old battery; operating at highest pressure continuously.	Ensure batteries are fully charged. Consider replacing old batteries. Use lower pressure modes when possible to conserve power.

7. Specifications

Technical specifications for the POXURIO Cordless Washer LDQXJ-HX.

- **Brand:** POXURIO
- **Model Number:** LDQXJ-HX
- **Power Source:** Battery Powered (2x 5.0Ah Lithium Batteries)
- **Maximum Pressure:** 750 PSI
- **Tank Volume:** 4.5 Gallons (15 Liters)

- **Hose Length:** 10 Feet
- **Adjustable Modes:** 4 Pressure Modes (M1-M4)
- **Runtime:** Approximately 60-70 minutes (with 10000mAh total capacity)
- **UPC:** 720141063039

8. Warranty and Support

The POXURIO Cordless Washer LDQXJ-HX typically includes a complimentary 1-month warranty from the date of purchase. For specific warranty details or to inquire about service, please contact the seller directly through your purchase platform. Please note that customer service phone numbers may not be available, and communication may be primarily via email or messaging services provided by the retailer.

Always retain your proof of purchase for warranty claims.

© 2026 POXURIO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question