Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mainstay MS54100112163

Mainstay Toaster Oven

MODEL: MS54100112163

User Instruction Manual

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before operating the toaster oven.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plug, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- To disconnect, turn any control to “OFF”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.
- A fire may occur if the toaster oven is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not place any materials other than manufacturer’s recommended accessories in this oven when not in use.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, and the like.
- Do not cover crumb tray or any part of the oven with metal foil. This will cause overheating of the oven.

Product Overview

The Mainstay Toaster Oven MS54100112163 is a versatile kitchen appliance designed for toasting, baking, and broiling. It features a compact design, easy-to-use knob controls, and comes with essential accessories for various cooking tasks.



Figure 1: The Mainstay Toaster Oven in a typical kitchen environment, showcasing its sage green finish and compact size.



Figure 2: Front view of the toaster oven, highlighting the temperature/mode dial and the timer dial on the right side.



Figure 3: A detailed view of the control panel, showing the top dial for temperature and cooking mode (Toast, Bake, Broil) and the bottom dial for the adjustable timer up to 60 minutes.

Components:

- **Temperature/Mode Dial:** Selects cooking function (Toast, Bake, Broil) and temperature.
- **Timer Dial:** Sets cooking time up to 60 minutes with an auto-shutoff feature.
- **Power Indicator Light:** Illuminates when the oven is operating.
- **Glass Door:** Dropdown style for easy access to the oven interior.
- **Heating Elements:** Two quartz heating elements for efficient cooking.

Included Accessories:



Figure 4: The included baking rack and baking pan, designed to fit perfectly within the toaster oven.

- **Baking Rack:** For toasting bread, bagels, and supporting baking pans.
- **Baking Pan:** For baking, broiling, and catching drips.



Figure 5: Diagram showing the external dimensions of the Mainstay Toaster Oven: approximately 13.19 inches wide, 11.65 inches deep, and 8.23 inches high.



Figure 6: Illustration demonstrating the various opening angles of the toaster oven's dropdown door, indicating flexibility for access.



Figure 7: An interior view of the toaster oven, showing the placement of the baking rack and pan, and the heating elements.

Setup

1. **Unpacking:** Carefully remove the toaster oven and all accessories from the packaging. Remove any protective film or packing materials.
2. **Placement:** Place the toaster oven on a stable, heat-resistant, and level surface. Ensure there is at least 4 inches (10 cm) of clearance on all sides and above the oven for proper ventilation. Do not place it near flammable materials like curtains or walls.
3. **Initial Cleaning:** Before first use, wipe the exterior with a damp cloth. Wash the baking rack and baking pan in warm, soapy water, rinse thoroughly, and dry. Do not immerse the main unit in water.
4. **First Use Burn-Off:** It is recommended to run the oven empty for about 10-15 minutes on the "Bake" setting at 450°F (230°C) to burn off any manufacturing residues. A slight odor or smoke may be present during this process; ensure the area is well-ventilated.

Operating Instructions

This toaster oven offers Toast, Bake, and Broil functions. Always ensure the oven is plugged into a standard electrical outlet.

General Operation:

- Place food on the baking rack or in the baking pan, then slide it into the oven.
- Close the glass door securely.
- Select the desired cooking function and temperature using the top dial.
- Set the cooking time using the bottom timer dial. The power indicator light will illuminate.
- The oven will automatically shut off when the timer reaches zero, and a bell will sound.

1. Toast Function:

1. Place bread slices directly on the baking rack. This oven can accommodate up to 4 slices of bread.
2. Turn the top dial to the **TOAST** setting.
3. Turn the bottom timer dial past 20 minutes, then back to your desired toast shade (light, medium, dark).
4. The oven will begin toasting. The timer will count down and shut off automatically.

2. Bake Function:

1. Place food in the baking pan or an oven-safe dish on the baking rack. This oven can fit a 9-inch pizza.
2. Turn the top dial to the desired temperature for baking (e.g., 350°F, 400°F).
3. Turn the bottom timer dial to the desired baking time, up to 60 minutes.
4. The oven will preheat and then bake. The power indicator light will remain on during operation.

3. Broil Function:

1. Place food in the baking pan. For best broiling results, position food closer to the top heating elements.
2. Turn the top dial to the **BROIL** setting.
3. Turn the bottom timer dial to the desired broiling time, up to 60 minutes. Broiling often requires shorter times and close monitoring to prevent burning.
4. Monitor food closely as broiling can cook quickly.

Cleaning and Maintenance

Regular cleaning helps maintain the performance and longevity of your toaster oven. Always unplug the oven and allow it to cool completely before cleaning.

Exterior:

- Wipe the exterior surfaces with a damp cloth and mild detergent.
- Do not use abrasive cleaners or scouring pads, as they may scratch the finish.
- Ensure no water enters the control panel or electrical components.

Interior:

- Remove the baking rack and baking pan.
- Wipe the interior walls with a damp cloth. For stubborn stains, a non-abrasive cleaner designed for oven interiors can be used sparingly.
- Do not spray cleaners directly onto the heating elements.

Baking Rack and Pan:

- Wash these accessories in warm, soapy water.
- Rinse thoroughly and dry completely before returning them to the oven.

Crumb Tray:

- The crumb tray is located at the bottom of the oven. Pull it out to remove crumbs.
- Wash the crumb tray with warm, soapy water, rinse, and dry.
- Ensure the crumb tray is reinserted correctly before using the oven.

Troubleshooting

If you encounter issues with your Mainstay Toaster Oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not turn on.	Not plugged in; power outage; timer not set.	Ensure plug is securely in outlet; check household circuit breaker; turn timer dial past 20 minutes then set to desired time.
Food not cooking evenly.	Incorrect temperature/time setting; food placement.	Adjust temperature and time as needed; ensure food is centered on the rack; preheat oven before baking.
Excessive smoke or odor during operation.	Food spills; residue from first use; flammable materials inside.	Clean interior thoroughly; ensure initial burn-off was performed; remove any non-food items from oven. If smoke persists, unplug immediately.
Timer not working.	Dial not turned past 20 minutes initially.	For toast and timed functions, always turn the timer dial past the 20-minute mark first, then back to your desired setting.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Feature	Detail
Model Number	MS54100112163

Feature	Detail
Power	1050 Watts
Capacity	Fits 4 slices of bread or a 9-inch pizza
Dimensions (D x W x H)	11.65" x 13.26" x 8.34" (approximate)
Weight	7.05 pounds
Control Type	Knob Control
Heating Elements	2 Quartz
Timer	Up to 60 minutes with auto shutoff
Color	Sage Green

Warranty and Support

This product is manufactured by Generic under the Mainstay brand. For warranty information or technical support, please refer to the documentation included with your purchase or contact the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

© 2025 Mainstay. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Do I need to remove the baking pan when toasting bread in the Mainstay MS54100112163 toaster oven?

Yes, for the best results when using the Toast function on the Mainstay MS54100112163, you should place the bread slices directly on the baking rack rather than in the baking pan. According to the...

Read full answer

Open the live page

https://manuals.plus/asin/B0FMH6VCGF

More documents and user manuals: **https://manuals.plus/**