Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jaycomey 4-Light LED Track Lighting Fixture (35in Black Gold)

Jaycomey 4-Light LED Track Lighting Fixture User Manual

Model: 35in Black Gold

1. Product Overview

The Jaycomey 4-Light LED Track Lighting Fixture is a versatile and modern lighting solution designed for various indoor spaces such as kitchens, living rooms, dining areas, bedrooms, and hallways. This fixture features four adjustable spotlights, remote control operation for dimming and color temperature adjustments, and an energy-efficient LED design.

- **Remote Control & Stepless Dimming:** Adjust brightness from 10% to 100% and color temperature from 3000K (warm light) to 6500K (daylight). Includes a memory function to recall your last setting.
- **Adjustable Rotating Spotlights:** Each of the four light heads can rotate 360° horizontally and tilt 90° vertically, allowing precise light direction.
- **Modern Durable Design:** Constructed with a strong iron base, aluminum lamp body, and high-quality acrylic shades for both durability and a sleek aesthetic.
- **Energy-Efficient 41W LED:** Delivers 2460 lumens of bright, flicker-free light, consuming only 41W of power.



Image 1.1: Jaycomey 4-Light LED Track Lighting Fixture (35in Black Gold).

2. Package Contents

Please check the package contents to ensure all parts are present and undamaged:

- 1 x LED Track Lighting Fixture
- 1 x Remote Control
- 1 x Mounting Bracket
- Screws
- Wire Nuts
- Instruction Manual (this document)

3. Safety Information

Before installation and use, please read and understand all safety instructions. Failure to do so may result in electric

shock, fire, or other injuries.

- Always turn off the power at the circuit breaker before beginning installation or performing any maintenance.
- Consult a qualified electrician if you are unsure about the installation process.
- This fixture is designed for indoor use only. Do not expose to moisture or outdoor elements.
- Do not attempt to modify the fixture or its components.
- Ensure all connections are secure and properly insulated.

4. Setup and Installation

Installation should be performed by a competent individual. Follow these general steps:

1. **Turn Off Power:** Locate your circuit breaker and turn off the power to the area where you will be installing the light fixture.
2. **Prepare Mounting Surface:** Ensure the ceiling surface is clean, dry, and capable of supporting the fixture's weight.
3. **Install Mounting Bracket:** Secure the mounting bracket to the ceiling junction box using the provided screws. It is recommended to use washers on both sides of the screws for a more secure fit.
4. **Wire Connections:** Connect the fixture's wires to your household wiring. Typically, the blue wire from the fixture connects to the white (neutral) wire from the ceiling, and the brown wire from the fixture connects to the black (live) wire from the ceiling. For the light wires, connect grey to red and white to black. Use the provided wire nuts to secure connections. Ensure all connections are tight and properly insulated.
5. **Attach Fixture to Bracket:** Carefully align the fixture with the mounting bracket and secure it with the remaining screws.
6. **Restore Power:** Once the fixture is securely installed and all connections are checked, restore power at the circuit breaker.



Image 4.1: Key components including the iron ceiling base, aluminum lamp body, and acrylic lampshade.

5. Operating Instructions

5.1 Using the Remote Control

The included remote control allows you to fully customize your lighting experience. Ensure the remote has working batteries.

- **Power On/Off:** Press the **ON/OFF** button to turn the light fixture on or off.
- **Brightness Adjustment (Dimming):** Use the **Brightness Up** and **Brightness Down** buttons to adjust the light intensity from 10% to 100%.
- **Color Temperature Adjustment:** Use the **Color Temperature Up** and **Color Temperature Down** buttons to change the light color from 3000K (warm white) to 6500K (cool white).
- **Memory Function:** The fixture will remember your last brightness and color temperature settings when turned off and on again via the remote.

Important: This fixture is NOT compatible with external dimmer switches. Use a regular wall switch for ON/OFF functionality only. All dimming and color temperature adjustments must be made via the provided remote control.



Image 5.1: Remote control functions and dimmer switch incompatibility notice.

5.2 Adjusting Spotlights

Each spotlight can be manually adjusted to direct light where needed:

- **Horizontal Rotation:** Gently rotate the spotlight head up to 360° horizontally along the track.
- **Vertical Tilt:** Tilt the spotlight head up to 90° vertically to aim the light beam.

6. Maintenance

To ensure the longevity and optimal performance of your Jaycomey LED Track Lighting Fixture, follow these maintenance guidelines:

- **Cleaning:** Before cleaning, ensure the power is turned off at the circuit breaker. Wipe the fixture with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or electrical components.
- **Bulb Replacement:** The LED chips in this fixture are designed for long-term use and are non-removable. Do not attempt to replace individual LEDs.

- **Inspection:** Periodically check for any loose connections or signs of wear. If any damage is observed, discontinue use and consult a qualified electrician.

7. Troubleshooting

If you encounter issues with your lighting fixture, refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections. Remote control battery is dead.	Check circuit breaker and wall switch. Turn off power, check and secure all wire connections. Replace remote control batteries.
Light flickers or dims unexpectedly.	Loose wire connections. Incompatible dimmer switch (if installed).	Turn off power, check and secure all wire connections. Ensure no external dimmer switch is used. This fixture requires a standard ON/OFF switch.
Remote control not working.	Dead batteries. Obstruction between remote and fixture.	Replace batteries. Ensure clear line of sight to the fixture.
One or more spotlights stop working.	Internal component failure.	Contact customer support for assistance.

8. Specifications

Feature	Detail
Product Dimensions (L x W x H)	90L x 22W x 16.5H centimetres (35.43 inches length)
Material	Aluminum, Iron Base, Acrylic Shades
Color	Black & Gold
Power Source	AC
Voltage	110 volts
Wattage	41 watts
Brightness	2460 lumens (max)
Light Source	Integrated LED
Number of Light Sources	4 spotlights + integrated ambient light
Color Temperature	3000K (Warm White) to 6500K (Cool White) adjustable
Dimming Range	10% to 100% (via remote control)
Control Method	Remote Control

Feature	Detail
Mounting Type	Ceiling Mount (Flush Mount)
Indoor/Outdoor Usage	Indoor use only

9. Warranty Information

This Jaycomey LED Track Lighting Fixture comes with a**1-Year Manufacturer Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by improper installation, misuse, accidents, modifications, or unauthorized repairs.

Please retain your proof of purchase for warranty claims.

10. Customer Support

For any questions, technical assistance, or warranty claims, please contact Jaycomey customer support through the retailer's platform where you purchased the product. Please have your product model and purchase date ready when contacting support.

© 2026 Jaycomey. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FMJSK39V

More documents and user manuals: **https://manuals.plus/**