MOKKOM MOKKOM 20 oz Nut Milk Maker (Model B0FMJXQFT8)

MOKKOM Nut Milk Maker Instruction Manual

Model: B0FMJXQFT8

1. Important Safety Instructions

Please read all instructions carefully before using the MOKKOM Nut Milk Maker. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged from the power outlet before cleaning or when not in use.
- Do not immerse the main unit, power cord, or plug in water or other liquids.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep children away from the appliance during operation.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use attachments not recommended or sold by the manufacturer.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the lid is securely closed before operating the machine.
- Exercise extreme caution when moving an appliance containing hot liquids.
- Do not open the lid during operation, especially when processing hot ingredients.
- Avoid contact with moving parts.
- This appliance is for household use only. Do not use outdoors.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.

2. Product Overview

The MOKKOM Nut Milk Maker is designed to simplify the process of creating fresh, homemade plant-based milks and other beverages. Its compact design and multiple functions make it a versatile addition to any kitchen.



Image 1: The MOKKOM Nut Milk Maker in Pearl White, showcasing its sleek design and handle.

Key Features

- **Dairy-Free Milk Production:** Capable of making smooth almond, soy, oat, and cashew milk.
- **Powerful Grinding:** Equipped with 4 durable stainless steel x-cross blades for efficient processing.
- **Quadrilateral Stirring Column:** Ensures ingredients collide repeatedly for a smooth texture.
- **Multi-function Programs:** Includes Room Temp, Warm (144°F), Hot (212°F), Boil Water, Self-clean, and Delay

Start.

- **Delay Start Function:** Offers 7, 9, or 11-hour delay options for convenient preparation.
- **Compact & Portable:** 20oz (600ml) capacity, suitable for 2-3 servings, ideal for small kitchens or travel.

Package Contents

- 1 x MOKKOM Nut Milk Maker
- 1 x Cleaning Brush
- 1 x Power Cord
- 1 x Measuring Spoon
- 1 x Instruction Manual (this document)

3. Setup

3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Retain the packaging for future storage or transport.
3. Check that all listed package contents are present and undamaged.

3.2 Initial Cleaning

Before first use, clean all parts that will come into contact with food.

1. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
2. Wash the interior of the pitcher and the lid with warm, soapy water using the provided cleaning brush.
3. Rinse thoroughly with clean water.
4. Dry all parts completely before assembly.

3.3 Assembly

1. Place the main unit on a stable, flat, and dry surface.
2. Ensure the power cord is not plugged into an outlet during assembly.
3. Place the lid securely onto the pitcher.

4. Operating Instructions

The MOKKOM Nut Milk Maker features multiple modes for various plant-based milk preparations and other functions.



Image 2: Illustration of the three basic operating modes: Room Temp, Warm (144°F), and Hot (212°F).

4.1 Basic Operation

1. Add your desired ingredients (nuts, grains, water) into the pitcher. Do not exceed the maximum fill line.
2. Securely place the lid on the pitcher.
3. Plug the power cord into a suitable electrical outlet.

4. Select the desired function using the control panel.
5. The machine will begin processing. Do not open the lid during operation.
6. Once the program is complete, the machine will beep. Unplug the appliance and carefully pour out the contents.

4.2 Making Plant-Based Milk

The MOKKOM Nut Milk Maker allows you to create various plant-based milks without pre-soaking in many cases.



Image 3: Freshly made nut milk being poured, demonstrating the smooth consistency.

- **Room Temp Mode:** Ideal for almond milk and other cold nut milks. This mode processes ingredients without heating.
- **Warm (144°F) Mode:** Suitable for warm beverages or milks that benefit from gentle heating.
- **Hot (212°F) Mode:** Perfect for soy milk, oat milk, or other hot drinks that require boiling for optimal texture and safety.

Refer to the included recipe book for specific ingredient ratios and program recommendations for different types of milk.

4.3 Delay Start Function

The Delay Start function allows you to program the machine to begin operation after a set period, so you can enjoy fresh milk at your convenience.



Image 4: Display showing the Delay Start options (7, 9, 11 hours).

1. Add ingredients and water to the pitcher.
2. Select your desired program (e.g., Hot for soy milk).
3. Press the 'Delay Start' button repeatedly to cycle through the 7, 9, or 11-hour delay options.
4. The machine will display the selected delay time and then enter standby mode. It will automatically start the chosen program after the delay period.

4.4 Boil Water Function

This function allows the machine to boil water, useful for sterilization or preparing hot water for other uses.

1. Fill the pitcher with water, ensuring it does not exceed the maximum fill line.
2. Secure the lid.
3. Select the 'Boil Water' function on the control panel.
4. The machine will heat the water to boiling point and then automatically shut off.

5. Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your MOKKOM Nut Milk Maker.



Image 5: Diagram highlighting the easy-to-clean internal components of the nut milk maker.

5.1 Self-Clean Function

The Self-Clean function helps to quickly clean the interior of the pitcher and blades.

1. After use, rinse out any large food particles from the pitcher.
2. Fill the pitcher with clean water up to the minimum fill line. Add a drop of dish soap if desired.
3. Secure the lid.
4. Select the 'Self-Clean' function on the control panel.
5. Once the cycle is complete, unplug the machine, discard the water, and rinse the interior thoroughly.

5.2 General Cleaning

- Always unplug the appliance before cleaning.
- Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or scourers.
- For stubborn residue inside the pitcher, use the provided cleaning brush and warm, soapy water.
- Ensure all parts are completely dry before storing the appliance.
- Do not wash the main unit in a dishwasher. The lid and pitcher can be hand-washed.

6. Troubleshooting

If you encounter any issues with your MOKKOM Nut Milk Maker, please refer to the following common problems and solutions.

Problem	Possible Cause	Solution
Machine does not turn on.	Not plugged in; power outage; lid not properly secured.	Ensure power cord is securely plugged in. Check power supply. Verify lid is correctly aligned and closed.
Milk is not smooth or has chunks.	Insufficient processing time; too many ingredients; hard ingredients not pre-soaked (if required).	Ensure correct program is selected. Do not overfill. Some ingredients (e.g., harder nuts) may benefit from pre-soaking. Run the cycle again if needed.
Machine stops unexpectedly.	Overheating; lid opened during operation; power interruption.	Unplug and allow to cool down for 15-20 minutes. Ensure lid remains closed during operation. Check power supply.
Burning smell during operation.	Overfilling; motor strain; foreign object.	Immediately unplug the machine. Reduce ingredients. Check for any foreign objects. If smell persists, discontinue use and contact customer support.

7. Specifications

Detailed technical specifications for the MOKKOM Nut Milk Maker.



Image 6: Visual representation of the 20oz (600ml) capacity of the nut milk maker.

Feature	Detail
Brand	MOKKOM
Model	B0FMJXQFT8
Capacity	20 fluid ounces (600 ml)
Color	Pearl White
Product Dimensions (D x W x H)	25.4D x 19.5W x 16.5H centimetres
Material	Stainless Steel (Blade, Container)
Special Feature	Portable
Power Source	AC
UPC	753902142773

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question