realme 15T 5G

realme 15T 5G Smartphone User Manual

Model: 15T 5G

1. Introduction

This manual provides essential information for using your new realme 15T 5G Smartphone. Please read it carefully to ensure proper operation and to maximize your device's potential. Keep this manual for future reference.

2. What's in the Box

Verify that all items are present in your product packaging:

- realme 15T 5G Smartphone
- Phone Case
- Power Adapter (60W Fast Charge compatible)
- USB Cable (Type-C)
- SIM Tray Ejector
- Quick Start Guide (this document)
- Warranty Card

3. Setup

3.1. SIM Card Installation

1. Locate the SIM card tray on the side of your device.
2. Insert the SIM tray ejector tool into the small hole next to the tray and press firmly until the tray pops out.
3. Place your Nano-SIM card(s) into the tray with the gold contacts facing down. Ensure proper orientation as indicated on the tray. This device supports Dual SIM.
4. Carefully reinsert the tray into the phone until it clicks into place.

3.2. Initial Power On

1. Press and hold the Power button (located on the right side) until the realme logo appears.
2. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection,

Google account setup, and security settings.

3.3. Charging the Battery

Before first use, it is recommended to fully charge the device. Connect the USB Type-C cable to the phone's charging port and the 60W Power Adapter to a wall outlet. The 7000mAh battery supports 60W fast charging.



Image: The realme 15T 5G Smartphone highlighting its 7000mAh battery and 60W fast charging feature.

4. Operating Your Device

4.1. Display Features

Your realme 15T 5G features a 6.67-inch AMOLED display with a 120Hz refresh rate, providing smooth visuals and vibrant colors. It has a resolution of 1080x2372 pixels and a peak brightness of 4000 nits for clear visibility even in bright sunlight. Eye protection is enhanced with 2160Hz PWM Dimming.

Image: Visual representation of the realme 15T 5G's AMOLED display features, emphasizing brightness, eye comfort, and color reproduction.

4.2. Camera Usage

The device is equipped with dual 50MP cameras, both front and rear, for high-quality photography. The rear camera system includes multiple lenses for versatile shooting options.

1. Open the Camera application from your home screen or app drawer.
2. Switch between Front and Rear cameras using the icon on the screen.
3. Select different modes such as Photo, Video, Portrait, Night, and more.
4. Tap the shutter button to capture photos or start/stop video recording.

Image: Close-up view of the realme 15T 5G's camera modules, highlighting the 50MP front and rear AI cameras.

4.3. Performance and Multitasking

Powered by the MediaTek Dimensity 6400 Max 5G chipset and 12GB RAM, the realme 15T 5G delivers seamless performance for multitasking, gaming, and demanding applications. The device also features a 6050mm² AirFlow VC cooling system to maintain optimal temperature during intensive use.

Image: The realme 15T 5G showcasing its Dimensity 6400 Max 5G chipset for powerful and smooth multitasking.

Image: An internal view of the realme 15T 5G, highlighting the 6050mm² AirFlow VC cooling technology.

4.4. Security Features

The realme 15T 5G includes Face Recognition for convenient and secure unlocking of your device. Set up Face Recognition in the Security settings menu.

4.5. Mini Capsule

The Mini Capsule feature provides quick access to important notifications and information, such as charging status, power saving mode, and incoming calls, displayed in a dynamic area around the front camera.

Image: The realme 15T 5G screen demonstrating the Mini Capsule feature with various notifications.

5. Maintenance

5.1. Cleaning Your Device

Use a soft, lint-free cloth to clean the screen and body of your phone. Avoid using harsh chemicals or abrasive materials. The device has an IP69 rating for dust and water resistance, offering protection against splashes and dust ingress.

Image: The realme 15T 5G demonstrating its IP69 dust and water resistance with water splashing on the device.

5.2. Software Updates

Regularly check for software updates to ensure your device has the latest features, security patches, and performance improvements. Go to **Settings > About Phone > Software Update** to check for and install updates.

5.3. Storage Management

Your device comes with 256GB of internal storage. To manage storage, go to **Settings > Storage**. You can clear cache, uninstall unused apps, and move files to cloud storage to free up space.

6. Troubleshooting

- **Device not turning on:** Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
- **Apps crashing or freezing:** Close the problematic app and reopen it. If the issue persists, restart your phone. Consider clearing the app's cache or reinstalling it.
- **Poor battery life:** Reduce screen brightness, disable unnecessary background apps, turn off Wi-Fi/Bluetooth when not in use, and limit location services.
- **Network connectivity issues:** Check if Airplane Mode is off. Restart your phone. Verify your SIM card is correctly inserted. Contact your network provider if problems persist.
- **Slow performance:** Clear cache, uninstall unused apps, and ensure sufficient storage space. Restarting the device can also help.

7. Specifications

Feature	Specification
Model	realme 15T 5G
Operating System	Android 15
Processor	MediaTek Dimensity 6400 Max 5G (2.3 GHz)
RAM	12 GB
Internal Storage	256 GB
Display	6.67-inch AMOLED, 120Hz Refresh Rate, 1080x2372 Pixels, 4000 nits Peak Brightness
Rear Camera	50 MP (Main) + 8 MP + 2 MP
Front Camera	50 MP
Battery Capacity	7000 mAh
Charging	60W Fast Charge
Connectivity	5G, Wi-Fi, Bluetooth, USB Type-C
SIM Card Slot	Dual SIM
Security	Face Recognition
Water Resistance	IP69 Rated

Dimensions	15.8 x 7.2 x 0.8 cm
Weight	181 Grams

8. Warranty Information

Your realme 15T 5G Smartphone comes with a**1 Year Manufacturer Warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.
For detailed warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official realme website.

9. Support

If you encounter any issues or have questions not covered in this manual, please contact realme customer support:

- **Online Support:** Visit the official realme support website for FAQs, troubleshooting guides, and online chat support.
- **Service Centers:** Locate authorized realme service centers in your region for in-person assistance.
- **Contact Information:** Refer to the contact details provided on the realme website or your warranty card.

© 2026 realme. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question