GOFJAJHQ KM-1838, KM-3208

GOFJAJHQ Replacement Blade Instruction Manual

For Kemei KM-1838 and KM-3208 Hair Clippers and Trimmers

Introduction

This instruction manual provides essential information for the proper installation, use, and maintenance of your GOFJAJHQ replacement blade, compatible with Kemei KM-1838 and KM-3208 hair clippers and trimmers. Please read this manual thoroughly before attempting to replace the blade to ensure safe and effective operation.

Safety Information

- Always ensure the hair clipper is turned off and unplugged from the power source before attempting any blade replacement or maintenance.
- Handle the blade with care as it is sharp. Avoid direct contact with the cutting edges to prevent injury.
- Keep replacement blades out of reach of children.
- Use only genuine or compatible replacement parts as specified for your device.
- Inspect the new blade for any damage before installation. Do not install a damaged blade.

Setup: Blade Installation

Replacing the blade on your Kemei KM-1838 or KM-3208 hair clipper is a straightforward process. Follow these steps carefully:

1. **Prepare the Clipper:** Ensure the hair clipper is switched off and unplugged from the power outlet.
2. **Remove the Old Blade:**
    - Depending on your specific Kemei model (KM-1838 or KM-3208), the blade attachment mechanism may vary slightly.
    - Typically, blades are held in place by small screws or a snap-on mechanism. Locate these and carefully detach the old blade. Refer to your original clipper's manual if you are unsure.
    - Place the old blade aside safely for disposal.
3. **Clean the Clipper Head:** Use a small brush to remove any accumulated hair or debris from the clipper head

area before installing the new blade.

4. **Install the New Blade:**
    - Align the new GOFJAJHQ replacement blade with the clipper head's mounting points.
    - If your clipper uses screws, gently secure the blade, ensuring it is seated correctly and not overtightened. If it's a snap-on design, press firmly until it clicks into place.
    - Ensure the blade is level and securely attached.
5. **Test the Clipper:** Plug in the clipper and turn it on briefly to ensure the blade moves smoothly and there are no unusual noises. Turn it off and unplug it again.



Image 1: Front view of the replacement blade, showing the cutting teeth and main body.



Image 2: Rear view of the replacement blade, illustrating the attachment points and internal spring mechanism.

Operating the Clipper with New Blade

Once the new GOFJAJHQ replacement blade is securely installed, your Kemei KM-1838 or KM-3208 hair clipper is ready for use. The new sharp blade is designed to provide efficient and precise cutting performance.

- Ensure the clipper is fully charged or plugged into a power source.
- Turn on the clipper and begin trimming or cutting hair as desired.

- The sharp cutting head helps reduce stuttering and allows for smoother passes, especially on thick or long hair.
- Always refer to your original Kemei hair clipper manual for specific operating instructions and techniques.

Maintenance

Proper maintenance of your replacement blade will ensure its longevity and optimal performance.

- **Cleaning After Each Use:** After each use, turn off and unplug the clipper. Use the provided cleaning brush (or a similar small brush) to remove all hair clippings from the blade and clipper head.
- **Oiling the Blades:** Regularly apply a few drops of clipper oil (not included) to the blade teeth. Turn on the clipper for a few seconds to distribute the oil evenly. This lubrication reduces friction, prevents rust, and maintains cutting efficiency.
- **Storage:** Store the clipper with the blade attached in a clean, dry place, away from moisture and extreme temperatures.
- **Blade Replacement:** Even with proper maintenance, blades will dull over time. Replace the blade when you notice a decrease in cutting performance, pulling of hair, or increased noise from the clipper. This replacement blade helps extend the life of your clipper by reducing motor strain.

Troubleshooting

If you encounter issues after installing your new replacement blade, consider the following:

Problem	Possible Cause	Solution
Clipper pulls hair or cuts poorly	Blade not properly aligned or secured; Blade needs oiling; Hair buildup.	Turn off and unplug the clipper. Re-align and secure the blade. Clean and oil the blade.
Unusual noise from clipper	Blade not properly seated; Debris caught in blade mechanism.	Turn off and unplug the clipper. Check blade seating. Clean blade area thoroughly.
Clipper motor feels strained	Blade friction due to lack of oil or debris.	Clean and oil the blade. Ensure no hair is impeding movement.

If problems persist, consult the original Kemei clipper manual or contact the seller for further assistance.

Specifications

- **Compatibility:** Kemei KM-1838, Kemei KM-3208 Hair Clippers and Trimmers
- **Item Weight:** 1.76 ounces (approx.)
- **Package Dimensions:** 0.39 x 0.39 x 0.39 inches (approx.)
- **Batteries Required:** No
- **Material:** (Not specified, typically stainless steel or ceramic)

Warranty and Support

Specific warranty information for this replacement blade may vary. Please refer to the product listing or contact the seller directly for details regarding warranty coverage and customer support.

For general inquiries or assistance, please reach out to the GOFJAJHQ customer service.

© 2023 GOFJAJHQ. All rights reserved.