Shocknshop W29

Shocknshop Sports Army Digital Watch

Model: W29

Introduction

This manual provides detailed instructions for the Shocknshop Sports Army Digital Watch, Model W29. Please read this manual thoroughly to understand the watch's functions and ensure proper use and maintenance. This digital watch features a round black dial with an army camouflaged pattern, a durable plastic strap, and multiple functions including alarm, stopwatch, and backlight.



Image: Front view of the Shocknshop Sports Army Digital Watch W29, showcasing its digital display and camouflage design.

Product Features

- **Digital Display:** Clear digital time, date, and day display.
- **Alarm Function:** Set daily alarms.
- **Backlight/Night Light:** Illuminates the display for visibility in low light conditions.
- **Stopwatch:** For timing events.
- **Calendar:** Displays date and day of the week.
- **Water Resistance:** Rated for 30 meters (3 ATM), suitable for splashes or brief immersion, but not for swimming or diving.
- **Durable Construction:** Plastic case and strap with a mineral crystal.

Setup

1. **Initial Inspection:** Upon unboxing, inspect the watch for any visible damage.
2. **Battery Activation:** The watch comes with a pre-installed battery. If the display is off, check for a plastic tab near the crown or buttons that needs to be removed to activate the battery.
3. **Wearing the Watch:** Adjust the plastic strap to a comfortable fit on your wrist. Ensure it is not too tight or too loose.

Operating Instructions

Familiarize yourself with the watch buttons and display indicators:



Image: Diagram illustrating the functions of each button and display segment on the Shocknshop W29 digital watch.

Button Functions:

- **Light Button (Top Left):** Activates the backlight for a few seconds.
- **Mode Button (Bottom Left):** Cycles through different modes: Time Display, Alarm Setting, Stopwatch, Date Setting.

- **Start/Stop Button (Top Right):** Used to start/stop the stopwatch or adjust values during setting modes.
- **Reset Button (Bottom Right):** Used to reset the stopwatch or confirm selections during setting modes.

Setting Time and Date:

1. From the normal time display, press the **Mode Button** repeatedly until the seconds start flashing. This indicates you are in time setting mode.
2. Press the **Start/Stop Button** to adjust the flashing value (seconds, hours, minutes).
3. Press the **Mode Button** to move to the next setting item (e.g., from seconds to hours, then minutes, then month, day, year).
4. Use the **Start/Stop Button** to change the value of the flashing item.
5. Once all settings are correct, press the **Reset Button** to exit the setting mode and save changes.

Using the Alarm:

1. From the normal time display, press the **Mode Button** until "ALM" (Alarm) appears on the display and the alarm time starts flashing.
2. Use the **Start/Stop Button** to adjust the hour.
3. Press the **Mode Button** to move to the minutes setting.
4. Use the **Start/Stop Button** to adjust the minutes.
5. Press the **Reset Button** to exit alarm setting mode.
6. To turn the alarm ON/OFF, in alarm display mode, press the **Start/Stop Button**. An alarm icon will appear/disappear to indicate its status.

Using the Stopwatch:

1. From the normal time display, press the **Mode Button** until "SPL" (Split) or "STW" (Stopwatch) appears on the display, showing "00:00:00".
2. Press the **Start/Stop Button** to start timing.
3. Press the **Start/Stop Button** again to stop timing.
4. Press the **Reset Button** to clear the stopwatch to "00:00:00".

Activating Backlight:

Press the **Light Button** (Top Left) to illuminate the display for a few seconds. This is useful in dark environments.



Image: Comparison of the watch display in normal light and with the backlight activated, showing improved visibility.

Maintenance

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, then dry thoroughly. Avoid harsh chemicals or abrasive materials.
- **Water Resistance (30 Metres):** This watch is water-resistant up to 30 meters (3 ATM). It is suitable for everyday use, splashes, and brief immersion in water. **Do not press buttons underwater.** Not suitable for swimming, diving, or showering with hot water.
- **Temperature:** Avoid exposing the watch to extreme temperatures (hot or cold) for extended periods, as this can affect battery life and accuracy.
- **Battery Replacement:** When the display becomes dim or the watch stops functioning, the battery may need replacement. It is recommended to have this done by a professional watch repair service to ensure water resistance is maintained.



Image: Rear view of the Shocknshop W29 watch, displaying the stainless steel back and water resistance markings.

Troubleshooting

Problem	Possible Cause	Solution
Display is blank or dim.	Low or dead battery.	Replace the battery. If new, ensure any battery activation tab is removed.
Time is incorrect.	Time was not set correctly or reset accidentally.	Refer to the "Setting Time and Date" section to reset the time.
Buttons are unresponsive.	Watch may be in a locked mode or battery is low.	Try pressing the Mode button to cycle through modes. If still unresponsive, replace battery.

Problem	Possible Cause	Solution
Water inside the watch.	Water resistance limits exceeded or buttons pressed underwater.	Immediately take the watch to a professional for inspection and repair to prevent further damage.

Specifications



Image: Detailed product information diagram for the Shocknshop W29 watch, including dimensions and materials.

Model Number	W29
Display Type	Digital
Movement Type	Quartz

Dial Diameter	53 Millimeters
Case Material	Plastic
Strap Material	Plastic
Strap Width	24 Millimeters
Crystal Material	Mineral
Water Resistance Depth	30 Metres (3 ATM)
Item Weight	100 Grams
Product Dimensions (LxWxH)	22 x 5.3 x 1.6 Centimeters
Special Features	Alarm, Back Light, Night Light, Stop Watch, Calendar

Warranty and Support

This Shocknshop W29 watch comes with a**6-month manufacturer's warranty** covering manufacturing defects from the date of purchase. This warranty does not cover damage caused by improper use, accidents, unauthorized repairs, or normal wear and tear.
For warranty claims or technical support, please contact Shocknshop customer service through their official channels or the retailer where the product was purchased. Please retain your proof of purchase for warranty validation.

© 2023 Shocknshop. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question