Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

GOUYESHO B0FMR3X6Y6

GOUYESHO Universal TV Remote Control Instruction Manual

Model: B0FMR3X6Y6

Introduction

This manual provides comprehensive instructions for the GOUYESHO Universal TV Remote Control, Model B0FMR3X6Y6. This remote is designed as a replacement for a wide range of TV brands, offering ease of use without complex programming for most compatible devices. Please read this manual carefully before use to ensure optimal performance and longevity of your remote control.

Package Contents:

- 1 x GOUYESHO Universal Infrared Remote Control

Note: AAA batteries and a detailed instruction booklet are not included in the package. This digital manual serves as your guide.

Setup

1. Battery Installation

The remote control requires two (2) 1.5V AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.



Figure 1: Battery installation for the GOUYESHO Universal Remote Control. Requires two 1.5V AAA batteries.

2. Initial Setup (No Programming Required for Most TVs)

For most compatible TV brands, the GOUYESHO Universal Remote Control is designed to work immediately after battery installation without any programming or pairing. Simply insert the batteries, point the remote at your TV, and begin using it.



Figure 2: The GOUYESHO Universal Remote Control typically requires no setup for immediate use with compatible TVs.

Compatible TV Brands include: Samsung, LG, Sony, Panasonic, Sharp, Toshiba, Philips, Haier, Hisense, Skyworth, TCL, Changhong, Hitachi, Sanyo, and various Smart TV models.

3. Alternative Setup (Brand Express Method)

If the remote does not function automatically with your TV, you may need to use the "BRAND EXPRESS" setup method. This method allows you to manually select your TV brand for improved compatibility.

1. Turn on your TV manually.
2. Press and hold the specific "Brand" key on the remote control (e.g., SAMSUNG, LG, SONY, etc.) for approximately 6 seconds. The remote will begin searching for the correct code.
3. Release the "Brand" key when the "VOL+" mark appears on the TV screen.
4. Immediately press the "SET" button to confirm the setting.
5. Check if the remote control functions correctly. If not, repeat the process or try another brand key if your TV brand is not explicitly listed but is a sub-brand or compatible with another major brand.



Figure 3: "BRAND EXPRESS" setup instructions for manual brand selection.

Operating Instructions

Once set up, the GOUYESHO Universal Remote Control functions like your original TV remote. Point the remote directly at your TV's infrared receiver for optimal performance.

Key Features:

- **Standard TV Controls:** Power, Volume Up/Down, Channel Up/Down, Mute, Input/Source selection, Menu, Guide, and Number buttons (0-9).
- **Navigation:** Directional pad (Up, Down, Left, Right) and OK button for menu navigation.
- **Quick Access Buttons:** Dedicated buttons for popular streaming services like Netflix, YouTube, Disney+, and Google Play for direct access.
- **Long Distance Control:** Utilizes Infrared 3.0 technology for a strong signal, allowing control from up to 26 meters (approximately 85 feet) with a wide angle of over 120 degrees.



Figure 4: Layout of the GOUYESHO Universal Remote Control buttons.



Figure 5: Quick access buttons for streaming services on the remote control.



Figure 6: The remote offers long-distance and precise control.

Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops:** While designed with durable ABS material, avoid dropping the remote control to prevent internal damage.

Troubleshooting

If you encounter issues with your GOUYESHO Universal Remote Control, please refer to the following common solutions:

Problem	Solution
Remote does not work after battery installation.	1. Ensure batteries are inserted with correct polarity (+/-). 2. Replace with fresh AAA batteries. 3. Ensure there are no obstructions between the remote and the TV's IR receiver. 4. Try the "Alternative Setup (Brand Express Method)" described above.
Remote only controls some functions, not all.	1. The remote might not be fully compatible with all specific functions of your TV model. 2. Try the "Alternative Setup (Brand Express Method)" again to ensure the correct brand code is selected.
Buttons are unresponsive or sticky.	1. Clean the remote control as described in the Maintenance section. 2. Replace batteries.
Remote range is reduced.	1. Replace batteries with fresh ones. 2. Ensure there are no strong light sources (like direct sunlight) interfering with the IR signal. 3. Ensure a clear line of sight to the TV's IR receiver.

Specifications

Brand	GOUYESHO
Model Number	B0FMR3X6Y6
Color	Black
Connectivity Technology	Infrared (IR 3.0)
Compatible Devices	Universal (Samsung, LG, Sony, Panasonic, Sharp, Toshiba, Philips, Haier, Hisense, Skyworth, TCL, Changhong, Hitachi, Sanyo, Smart TV)
Maximum Range	Up to 26 meters (approximately 85 feet)
Number of Buttons	25
Controller Type	Button Control
Power Source	2 x AAA 1.5V Batteries (not included)
Material	ABS (Acrylonitrile Butadiene Styrene)
Special Feature	Ergonomic design



Figure 7: Approximate dimensions of the remote control (7.52in length, 1.77in width, 0.75in thickness).

Warranty and Support

GOUYESHO is committed to product quality and customer satisfaction. While specific warranty details are not provided in this manual, if you have any questions regarding your order, product compatibility, or require technical assistance, please contact the seller directly.

Customer support typically responds within 12 hours on weekdays to address your concerns.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FMR3X6Y6

More documents and user manuals: **https://manuals.plus/**