PZL B0FMR59CHQ

PZL Replacement Walking Pad Remote Control User Manual

Compatible with Lichico DK-38AB-2 Under Desk Treadmill

1. Introduction

This manual provides instructions for the PZL Replacement Walking Pad Remote Control, designed for use with various walking pads and under-desk treadmills, including the Lichico DK-38AB-2, UT-38AB IY, and AD-4000 Plus models. This remote control offers essential functions for managing your treadmill's operation.



Image 1.1: PZL Replacement Walking Pad Remote Control in use with a walking pad treadmill.

The remote allows you to monitor and control key workout metrics such as time, speed, calories burned, and distance covered. It is designed for direct use without complex programming.



Image 1.2: The remote control displaying icons for Time, Speed, Calories, and Distance, indicating its monitoring capabilities.

2. Product Features

- **Sensitive Buttons:** Designed for soft touch and fast response.
- **Durable Material:** Constructed from environmentally friendly ABS material.
- **Ergonomic Grip:** Provides a comfortable feel during use.
- **Stable Signal:** Features an upgraded chip for reliable infrared connectivity.



Image 2.1: Detailed view highlighting the sensitive buttons, durable ABS material, comfortable grip, and quality assurance of the remote control.

3. Setup

3.1 Battery Installation

The remote control requires one CR2025 coin cell battery (not included). Ensure correct polarity when inserting the battery.

1. Locate the battery compartment on the back of the remote control.
2. Open the compartment cover.
3. Insert one CR2025 battery with the positive (+) side facing up.
4. Close the battery compartment cover securely.



Image 3.1: The remote control indicating the requirement for a CR2025 battery, which is not included.

3.2 Pairing Instructions

To pair the remote control with your walking pad or treadmill, follow these steps:

1. Press and hold the power button on the new remote control.
2. While still holding the power button on the remote, manually turn on the walking pad or treadmill.
3. Continue holding the power button on the remote until the device's screen displays "0000".
4. Release the power button on the remote control.
5. Press the pause button on the remote control.
6. Manually turn off the treadmill and then restart it. The connection should now be successful.

4. Operating Instructions

The PZL Replacement Remote Control is designed for straightforward operation without the need for complex programming.



Image 4.1: The remote control being held, emphasizing its direct usability without programming.

4.1 Button Functions

- **Power Button ( ):** Turns the treadmill on or off.
- **Start/Pause Button ( ):** Starts or pauses the treadmill's operation.
- **Mode Button (M):** Cycles through different display modes or workout programs on your treadmill.
- **Speed Up Button (+):** Increases the treadmill's speed.
- **Speed Down Button (-):** Decreases the treadmill's speed.

4.2 Control Range and Signal

The remote control operates effectively within a maximum range of 26 feet and supports multi-angle control up to 120 degrees, ensuring a stable connection to your walking pad.



Image 4.2: The remote control demonstrating a stable signal connection to the walking pad treadmill.



Image 4.3: Visual representation of the remote's 26-foot long-range and 120-degree multi-angle control capabilities.

5. Maintenance

Proper care will extend the life of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace the CR2025 battery when the remote's response becomes sluggish or it stops functioning. Refer to Section 3.1 for battery installation instructions.
- **Storage:** Store the remote in a dry place, away from direct sunlight and extreme temperatures.

6. Troubleshooting

If you encounter issues with your remote control, refer to the following common solutions:

- **Remote Not Responding:**
    - Check if the battery is correctly installed and has sufficient charge. Replace the CR2025 battery if

necessary.
    - Ensure there are no obstructions between the remote control and the treadmill's infrared receiver.
    - Re-attempt the pairing process as described in Section 3.2.
- **Pairing Failure:**
    - Confirm that the treadmill is powered on during the pairing process.
    - Follow each step of the pairing instructions (Section 3.2) precisely.
    - Ensure the remote is within close proximity to the treadmill during pairing.
- **Laggy Response:**
    - This can sometimes occur if the battery is low. Replace the CR2025 battery.
    - Reduce the distance between the remote and the treadmill.
    - Ensure no other infrared devices are causing interference.

7. Specifications

Brand	PZL
Model Name (ASIN)	B0FMR59CHQ
Compatible Devices	Walking Pad (Lichico DK-38AB-2, UT-38AB IY, AD-4000 Plus)
Connectivity Technology	Infrared
Button Quantity	5 (Power, Start/Pause, Mode, Speed Up, Speed Down)
Controller Type	Button Control
Maximum Range	26 feet
Battery Type	CR2025 (Lithium Coin Cell)
Color	Black
Special Feature	Ergonomic

8. Warranty and Support

For any questions regarding your PZL Replacement Walking Pad Remote Control, please contact customer service. We are committed to providing prompt assistance for your inquiries.

Please note that batteries and additional instructions beyond this manual are not included in the package.

© 2026 PZL. All rights reserved.