Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LEGO 31380

LEGO Creator 3 in 1 Retro Gaming Console (31380) Instruction Manual

Model: 31380 | Brand: LEGO

Introduction

The LEGO Creator 3 in 1 Retro Gaming Console (31380) offers three distinct building experiences from a single set of LEGO bricks. This set allows you to construct a handheld gaming console, a desktop mini computer, or a mini arcade game machine. Designed for builders aged 8 and up, this set encourages creativity and provides engaging construction challenges.
Please read this manual carefully to ensure proper assembly and enjoyment of your LEGO Creator set.

Safety Information

WARNING: CHOKING HAZARD - Small Parts.
Not for children under 3 years.
This LEGO set contains small parts which may pose a choking hazard. Adult supervision is recommended for younger children, even if they are within the recommended age range of 8+ years, to prevent accidental ingestion or loss of pieces.
Always build in a well-lit area and keep all pieces organized to avoid misplacing them.

What's in the Box

Your LEGO Creator 3 in 1 Retro Gaming Console (31380) package includes:

- 268 LEGO Building Elements (various colors and shapes)
- Instruction booklets for building the three different models

Please verify all components are present before beginning assembly. If any pieces are missing, refer to the "Troubleshooting" section for assistance.

Setup and Assembly

This set offers three distinct building options. You can only build one model at a time. Choose your desired model and follow the corresponding instructions.

1. Handheld Gaming Console

Follow the dedicated instruction booklet to assemble the handheld gaming console. This model features two moving joysticks and two moving buttons, along with slots for interchangeable game cartridges.



Image: The handheld gaming console model, showcasing its buttons, joysticks, and interchangeable game cartridges.

2. Desktop Mini Computer

Refer to the specific instruction booklet for building the desktop mini computer. This model includes a keyboard, a monitor, and a slot for a disk.



Image: The desktop mini computer model, featuring a keyboard and monitor.

3. Mini Arcade Game Machine

Use the provided instruction booklet to construct the mini arcade game machine. This model captures the iconic retro details of classic arcade cabinets.



Image: The mini arcade game machine model, designed with retro arcade aesthetics.

Using the LEGO Builder App

For an enhanced building experience, download the LEGO Builder app. This app provides easy-to-follow 3D instructions, allows you to save sets, track progress, and zoom in/rotate models during construction. This can be particularly helpful for complex steps or for visualizing the final product.



Image: A child interacting with the LEGO Builder app on a tablet, showing digital building instructions.

Operating the Models

Once assembled, each model offers interactive features:

- **Handheld Gaming Console:** The joysticks and buttons are designed to move, simulating real gameplay. Insert the included game cartridges into the console's slot to change the displayed game scene.
- **Desktop Mini Computer:** The keyboard features movable keys, and the disk can be inserted into the computer unit.
- **Mini Arcade Game Machine:** Features movable joysticks and buttons, mimicking the controls of a classic arcade game.

These models are primarily for display and imaginative play, providing a tactile and visual experience.

Maintenance

To keep your LEGO Creator models in optimal condition:

- **Cleaning:** Dust regularly with a soft, dry cloth. For deeper cleaning, use a mild soap solution and a soft brush, then rinse thoroughly with clean water and air dry. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store assembled models or loose bricks in a cool, dry place away from direct sunlight to prevent discoloration or warping. Keep small pieces in a container to prevent loss.
- **Disassembly:** If you wish to build a different model, carefully disassemble the current one. Use a brick separator (not included in this set, but available separately) if needed to avoid damaging bricks.

Troubleshooting

If you encounter any issues during assembly or with your completed model, consider the following:

- **Missing Pieces:** Double-check all packaging and surrounding areas. If pieces are genuinely missing, contact LEGO Customer Service for replacements.
- **Incorrect Assembly:** Review the instruction booklet or the LEGO Builder app carefully. Sometimes a small error early in the build can affect later steps. Disassemble the problematic section and re-build.
- **Loose Connections:** Ensure all bricks are firmly pressed together. LEGO bricks are designed to fit snugly.

For further assistance, refer to the official LEGO support channels.

Specifications

Feature	Detail
Brand	LEGO
Model Name	Creator 31380
Model Number	6585551
UPC	673419421478
Number of Pieces	268
Recommended Age	8+ years
Material Type	Plastic
Item Dimensions (Console)	Over 3 in. (8 cm) high, 1.5 in. (4 cm) long and 5 in. (12 cm) wide
Included Components	LEGO Building Elements

Official Product Video

Watch a 360-degree spin of the LEGO Creator Retro Gaming Console (31380) to see its design from all angles.

Your browser does not support the video tag.

Video: A 360-degree view of the LEGO Creator Retro Gaming Console (31380) model.

Warranty and Support

LEGO products are manufactured to high-quality standards. For information regarding product warranty, missing parts, or further support, please visit the official LEGO website or contact their customer service directly. Keep your purchase receipt as proof of purchase.
Official LEGO Website: www.lego.com

© 2026 LEGO Group. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FMS75M6P

More documents and user manuals: **https://manuals.plus/**