Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RBA-1014

XINFUTE Replacement Remote Control User Manual

For Rebel RBA-1014 Walking Pad Desk Treadmill and Compatible Models

1. Introduction

This manual provides comprehensive instructions for the XINFUTE replacement remote control, designed for use with the Rebel RBA-1014 Walking Pad Desk Treadmill and other compatible models. Please read this manual carefully before use to ensure proper operation and longevity of your device.

2. Product Overview



Figure 1: XINFUTE Replacement Remote Control. This image displays the front view of the black remote control, highlighting its ergonomic design and button layout.

The XINFUTE replacement remote control is a dedicated device for managing your walking pad treadmill. It features a simple, intuitive design for ease of use. No downloads or pairing are required for operation with compatible models.

- **Quantity:** 1 x remote control
- **Condition:** New
- **Type:** Treadmill Remote
- **Material:** ABS Material
- **Color:** As Shown (typically black)

3. Compatibility



Figure 2: Compatibility Overview. This image illustrates three different walking pad treadmill models, indicating the remote's compatibility with them.

This remote control is specifically designed to be compatible with the following walking pad treadmill models:

- Rebel RBA-1014
- AD-4000 Plus
- DK-38AB-2
- UT-38AB IY
- Other models from the same brand (XINFUTE) that explicitly state compatibility.

Important Note: If the remote control is not compatible with your specific treadmill model, it will not function. Please verify compatibility before use.

4. Setup and Battery Installation

The remote control requires **2 AAA batteries** (not included) for operation.

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Close the battery compartment cover securely.

No downloads or pairing procedures are typically needed for this replacement remote control. It should function directly with compatible treadmills once batteries are installed.

5. Operating Instructions



Figure 3: Easy Operation Guide. This image labels each button on the remote control with its corresponding function, such as increasing speed, changing modes, and starting/stopping the treadmill.

Familiarize yourself with the remote control buttons and their functions:

1. Power Button ( ):

Turns off the walking pad when it is running. When the walking pad is in standby mode, pressing this button will turn off the display and enter sleep mode.

2. Start/Stop Button ( ):

Starts or stops the walking pad. When the power is turned on, pressing this button in the stop state will start the walking pad. Pressing the button when the walking pad is running will stop the walking pad.

3. Mode Button (M):

Selects the countdown mode for time, distance, or calories, as well as a free mode. Pressing this button will cycle through the options of "30:00" (time countdown mode), "1.0" (distance countdown mode), "50.0" (calorie countdown mode), and "0.0" (free mode).

4. Speed + Button (+):

Increases the speed of the walking pad after it is started. After a single press, the speed will be adjusted by 0.1 MPH. When the button is pressed continuously for more than 1 second, the speed will continue to increase.

5. Speed - Button (-):

Decreases the speed of the walking pad after it is started. After a single press, the speed will be adjusted by 0.1 MPH. When the button is pressed continuously for more than 1 second, the speed will continue to decrease.



Figure 4: Remote Control in Operation. This image shows the remote control being used alongside a walking pad treadmill, illustrating its function in controlling speed, time, distance, and calories.

The remote control offers a 360-degree, 33-foot long-distance control range with a response time of 0.2 seconds, ensuring responsive operation.



Figure 5: Control Range and Speed. This image highlights the remote's effective control distance of 33 feet and a quick response time of 0.2 seconds.

6. Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's responsiveness decreases or it stops functioning. Battery life is dependent on usage frequency and duration.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal components.

7. Troubleshooting

Problem	Possible Cause	Solution
Remote control not responding.	Dead or incorrectly inserted batteries.	Check battery polarity and replace with fresh AAA batteries.
Remote control not controlling the treadmill.	Treadmill power switch is off or remote is incompatible.	Ensure the treadmill's main power switch is on. Verify your treadmill model is listed as compatible. If not compatible, the remote will not work.
Intermittent control.	Low battery power or obstruction between remote and treadmill.	Replace batteries. Ensure a clear line of sight or reduce distance to the treadmill.

If you experience persistent issues, please refer to the support information provided in Section 9.

8. Specifications

Feature	Detail
Model Compatibility	Rebel RBA-1014, AD-4000 Plus, DK-38AB-2, UT-38AB IY
Power Source	2 x AAA Batteries (not included)
Material	ABS
Item Weight	2.82 ounces (approx. 80 grams)
Package Dimensions	10.63 x 5.12 x 1.57 inches (approx. 27 x 13 x 4 cm)
Control Range	Up to 33 feet (approx. 10 meters)
Response Time	0.2 seconds

9. Warranty and Support

Warranty: This product comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use.
Customer Support: All products are inspected before shipment. If you are not satisfied with your purchase or encounter any issues, please contact XINFUTE customer support within 24 hours of receiving your product. For further assistance, you may visit the XINFUTE Store on Amazon.

© 2025 XINFUTE. All rights reserved.
Manual Version: 1.0

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FN4613Z2

More documents and user manuals: **https://manuals.plus/**