Nitemode 21354 Light Kit

Nitemode LED Light Kit for Lego Twilight The Cullen House 21354 - Instruction Manual

Model: 21354 Light Kit

Introduction

This manual provides instructions for the Nitemode LED Light Kit, designed to enhance your Lego Ideas Twilight The Cullen House 21354 model. This kit adds adjustable lighting to bring your model to life. **Please note: This product includes the light kit ONLY. The Lego building blocks are NOT included.**



Image: Packaging clearly stating "ONLY LED LIGHTING, NO BUILDING BLOCK MODEL".

Safety Information

- Keep out of reach of small children due to small parts.
- Do not expose the light kit to water or extreme temperatures.
- Use only the specified power source (USB-powered).
- Avoid direct eye exposure to LED lights for prolonged periods.
- This product is intended for ages 14 and up (Manufacturer Minimum Age: 168 months).

Package Contents

Verify that all components are present before beginning installation.

- LED Light Strips and Wires
- Connection Cables
- USB Power Cable
- Touch Dimmer Switch
- Accessory Pieces (e.g., small bricks for attachment)

Note: The exact number and type of pieces may vary slightly. Refer to the online instructions for a detailed list.

Setup and Installation

This light kit is designed for integration with the Lego Ideas Twilight The Cullen House 21354 model. Detailed step-by-step instructions are provided electronically to ensure a smooth installation process.

Accessing Electronic Instructions:

1. **Receive Product:** After receiving your light kit, locate the instruction QR code.
2. **Scan QR Code:** Use a smartphone or tablet to scan the QR code provided on the packaging or a small card inside the box.
3. **Online Portal:** Alternatively, visit the official support website: http://support.nitemodetoy.com
4. **Input Model Query:** On the website, enter "21354" or "Twilight The Cullen House" to find the specific instructions for your model.
5. **Preview PDF:** The instructions will be available in PDF format for viewing and download.



Image: Steps for accessing the electronic instruction manual.

General Installation Tips:

- Follow the electronic guide carefully, step by step.
- Ensure all wires are neatly tucked away to avoid damage and maintain the model's aesthetic.
- Connect the USB power cable to a compatible USB power source (e.g., power bank, USB wall adapter).



Image: Detailed view of installed lighting fixtures within the model.



Image: The illuminated Lego model from different perspectives.

Operating Instructions

The Nitemode LED Light Kit features a touch dimmer switch for easy control.

- **Power On/Off:** A single, quick tap on the touch switch will turn the lights on or off.
- **Adjust Brightness:** Press and hold the touch switch to smoothly adjust the brightness level. Release the switch when the desired brightness is reached.



Image: Visual guide for operating the touch dimmer switch.



Image: Demonstration of the light kit in "Turn On" and "Turn Off" states.



Video: A demonstration of the Nitemode LED light kit installed in the Lego Twilight The Cullen House model, showcasing various illuminated sections including interior rooms, exterior lighting, and the illuminated truck and wolf figure.

Maintenance

- **Cleaning:** Gently wipe the LED components and wires with a dry, soft cloth. Do not use liquid cleaners.
- **Storage:** When not in use for extended periods, disconnect the power and store the model in a cool, dry place away from direct sunlight.
- **Wire Management:** Periodically check that all wires are securely connected and not pinched or damaged.

Troubleshooting

Problem	Possible Cause	Solution
Lights do not turn on.	No power, loose connection, faulty switch.	◦ Ensure USB power cable is securely connected to a working power source. ◦ Check all wire connections for looseness. ◦ Verify the touch switch is functioning by tapping it firmly.
Lights are dim or flickering.	Insufficient power, loose connection, brightness setting.	◦ Try a different USB power source with adequate output. ◦ Check all wire connections. ◦ Press and hold the touch switch to increase brightness.
Some lights are not working.	Damaged LED, loose connection to specific light strip.	◦ Carefully inspect the connections for the non-working lights. ◦ If a specific LED strip is damaged, contact customer support for assistance.

Specifications

- **Brand:** Nitemode
- **Model Compatibility:** Lego Ideas Twilight The Cullen House 21354
- **Operation Mode:** Manual (Touch Dimmer)
- **Power Source:** Rechargeable battery (USB-powered)
- **Material:** Plastic
- **Item Weight:** Approximately 4.16 ounces
- **Assembly Required:** Yes
- **Manufacturer Minimum Age:** 168 months (14 years)

Warranty and Support

Nitemode is committed to providing high-quality products and excellent customer service. If you encounter any issues or have questions regarding your LED light kit, please do not hesitate to contact us.

Contact Information:

- Through your Amazon "Your Orders" page, select "Ask Product Question".
- For electronic instructions and further support, visit: http://support.nitemodetoy.com

We aim to respond promptly to all inquiries.

© 2025 Nitemode. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question