PZL B0FNCVHS1V

PZL Replacement Walking Pad Remote Control User Manual

Model: B0FNCVHS1V
Brand: PZL

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your PZL Replacement Walking Pad Remote Control. This remote control is designed for use with various walking pad treadmills, including models from DeerRun (BA04, BA05, Q1 Urban, DR2-CT), Lacuffy (BA03, BA01, BA06), and COZYINN (WFTM010).
The package includes one (1) IR remote control. Please note that the CR2025 battery and detailed instructions are not included in the product packaging, but are provided within this manual.

Product Overview

The PZL Replacement Walking Pad Remote Control features a user-friendly design with sensitive buttons for easy operation. It is constructed from durable, environmentally friendly ABS material, providing a comfortable grip and stable signal transmission.



Image 1: The remote control in use with a walking pad treadmill, highlighting its compatibility with DeerRun BA04, BA05, BA03, BA01, BA06, DR2-CT models. The display shows metrics such as Time, Speed, Calories, and Distance.



Image 2: A hand holding the remote control while a person uses a walking pad treadmill. Text overlays indicate "Use Directly", "No Programming", and "Easy To Use", suggesting straightforward functionality.



Image 3: A visual breakdown of the remote control's features: sensitive buttons for fast response, environmentally friendly ABS material, comfortable grip, and quality assurance for service.



Image 4: The remote control held by a hand, with a signal icon pointing towards a treadmill, illustrating its upgraded chip for stable signal transmission.

Your browser does not support the video tag.

Video 1: This video provides a close-up view of the remote control, showcasing its design and button layout, including the plus, minus, mode, and on/off buttons.

Setup

Battery Installation

The remote control requires one CR2025 battery, which is not included in the package. Please follow these steps to install the battery:

1. Locate the battery compartment on the back of the remote control.
2. Open the back cover of the remote control.
3. Insert a new CR2025 battery with the positive (+) terminal facing upward. Ensure the battery is securely seated.
4. Close the back cover until it clicks into place.



Image 5: A visual reminder that a CR2025 battery is required for the remote control and must be purchased separately.

Note: Ensure the battery is inserted correctly to avoid damage to the remote control.

Pairing the Remote Control

To pair your remote control with your walking pad treadmill, follow these steps:

1. Turn on your walking pad treadmill.
2. Ensure the treadmill's display is functioning and shows "zero o'clock" or is in a ready state.
3. Press and hold the **[+]** or **[Power]** button on the remote control for approximately 5 seconds.
4. You should hear a beep from the treadmill, indicating successful pairing.
5. If pairing is unsuccessful, try the process again.

Your browser does not support the video tag.

Video 2: This video demonstrates the pairing process for a treadmill remote control. It shows how to power on the treadmill, check the display, remove the safety lock, and then point and press the remote to connect it successfully.

Operating Instructions

Once paired, the remote control allows you to manage your walking pad treadmill's basic functions:

- **Power On/Off:** Use the designated power button to turn the treadmill on or off.
- **Speed Adjustment:** Use the **[+]** button to increase speed and the **[-]** button to decrease speed.
- **Mode Selection (if applicable):** Some remotes may feature an 'M' button for cycling through different modes or programs. Refer to your treadmill's specific manual for details on mode functionality.

Your browser does not support the video tag.

Video 3: This video illustrates the remote control's functionality, demonstrating how to adjust the treadmill's speed and turn it on or off using the remote.

Maintenance

To ensure the longevity and optimal performance of your remote control:

- Keep the remote clean and dry. Avoid exposure to liquids.
- Store in a safe place to prevent physical damage.
- Replace the CR2025 battery when the remote's responsiveness decreases or it stops functioning.

Troubleshooting

If you encounter issues with your remote control, consider the following:

- **Remote not responding:**
  - Check if the CR2025 battery is installed correctly with the positive (+) terminal facing up.
  - Replace the battery with a new one.
  - Ensure there are no obstructions between the remote and the treadmill's receiver.
- **Pairing issues:**
  - Confirm the treadmill is powered on and its display is active.
  - Re-attempt the pairing process by holding the **[+]** or **[Power]** button for 5 seconds.
  - Ensure you are within close range of the treadmill during pairing.
- **Incompatibility:**
  - Verify that your treadmill model is listed as compatible with this PZL remote control (DeerRun BA04, BA05, Q1 Urban, DR2-CT; Lacuffy BA03, BA01, BA06; COZYINN WFTM010).

Specifications

Brand	PZL
Model Number	B0FNCVHS1V
Compatible Devices	Walking Pad Treadmills (DeerRun BA04, BA05, Q1 Urban, DR2-CT; Lacuffy BA03, BA01, BA06; COZYINN WFTM010)
Max Number of Supported Devices	1
Color	Black

Special Feature	Ergonomic design
Item Weight	0.634 ounces
Package Dimensions	4.29 x 2.09 x 0.67 inches

Warranty and Support

PZL is committed to providing timely customer service. If you have any questions regarding your order or the product model, please contact our after-sales service. We aim to provide support within 24 hours.
For further assistance, please refer to the seller's contact information on the platform where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question