Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

XINFUTE RC833A FMB1

XINFUTE RC833A FMB1 Remote Control User Manual

For TCL QD Mini-LED C71K 4K 2025 Voice TVs

Introduction

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your XINFUTE RC833A FMB1 remote control. This remote is designed for use with TCL QD Mini-LED C71K 4K 2025 Voice TVs.

Setup

1. Battery Installation

The XINFUTE RC833A FMB1 remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, pushing it until it clicks securely into place.



Image: Back of the remote control with the battery compartment open, illustrating correct AAA battery placement.

2. Initial Pairing (if required)

This remote control is typically ready for use with compatible TCL QD Mini-LED C71K 4K 2025 Voice TVs without manual pairing. If the remote does not respond, ensure batteries are correctly installed and try the following:

- Point the remote directly at the TV's sensor.
- For voice control functionality, your TV may require an initial pairing process. Refer to your TCL TV's user manual for specific instructions on pairing a new voice remote.

Operating Instructions

The XINFUTE RC833A FMB1 remote control features a standard layout for easy navigation and control of your TCL TV. Below is a general overview of key buttons and their functions.



Image: Front view of the XINFUTE RC833A FMB1 remote control, displaying its full button layout.

Button Functions

- **Power Button ( ):** Turns the TV on or off.
- **Number Pad (0-9):** Direct channel selection.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates menus and confirms selections.
- **Back (↶):** Returns to the previous screen or menu.
- **Home (⌂):** Accesses the TV's home screen or smart TV interface.
- **Volume Up/Down (VOL +/-):** Adjusts the TV's volume.
- **Channel Up/Down (CH +/-):** Changes TV channels.
- **Mute ( ):** Mutes or unmutes the TV's audio.
- **Settings (⚙):** Opens the TV's settings menu.
- **Voice Assistant ( ):** Activates the voice control feature (requires TV support and pairing).
- **Quick Access Buttons:** Dedicated buttons for popular streaming services (e.g., Netflix, YouTube, Disney+, TCL Channel).

For detailed functionality of specific buttons or advanced features, refer to your TCL TV's user manual.

Maintenance

Cleaning

To maintain the remote control's appearance and functionality:

- Wipe the surface with a soft, dry cloth.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases. Always replace both AAA batteries simultaneously with new ones. Do not mix old and new batteries, or different types of batteries.

Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries. Obstruction between remote and TV. Remote out of range.	Replace batteries with new AAA batteries, ensuring correct polarity. Remove any obstructions. Ensure you are within a reasonable distance and pointing the remote at the TV's sensor.
Voice control not working.	Remote not paired with TV for voice function. TV settings.	Refer to your TCL TV's user manual for voice remote pairing instructions. Check TV's settings to ensure voice control is enabled.
Some buttons not working.	Dirt or debris under buttons. Remote malfunction.	Clean the remote control. If the issue persists, the remote may require replacement.

Specifications

- **Model:** RC833A FMB1
- **Brand:** XINFUTE
- **Compatibility:** TCL QD Mini-LED C71K 4K 2025 Voice TVs
- **Power Source:** 2 x AAA Batteries (not included)
- **Material:** ABS Material
- **Color:** Black
- **Product Dimensions:** 6 x 3 x 1 inches
- **Item Weight:** 2.82 ounces
- **Special Feature:** Ergonomic design

Warranty Information

This XINFUTE remote control comes with a one-year warranty from the date of purchase. This warranty covers manufacturing defects under normal use.
For warranty claims or issues, please contact the seller within 24 hours of receipt of your purchase. All goods are inspected before shipment to ensure quality.

Customer Support

For further assistance or inquiries regarding your XINFUTE RC833A FMB1 remote control, please contact your retailer or the XINFUTE customer service department.
You can visit the XINFUTE Store on Amazon for more information.

© 2025 XINFUTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FND3TS15

More documents and user manuals: **https://manuals.plus/**