Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY MM-RC041-RC034

ALLIMITY Remote Control User Manual

Compatible with BLU:SENS TV Models RC041, RC034, RC036, RC042, RC044, RC054

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your ALLIMITY Remote Control. This remote is designed for direct compatibility with various BLU:SENS TV models, including RC041, RC034, RC036, RC042, RC044, and RC054, requiring no programming for basic functions. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your device.

Product Overview

The ALLIMITY Remote Control is a replacement remote designed to function seamlessly with specified BLU:SENS TV models. It features an ergonomic design for comfortable handling and provides stable remote control performance with a good transmission distance. The remote is pre-programmed for the listed compatible models, ensuring ease of use right out of the box.





Figure 1: Front view of the ALLIMITY Remote Control.

Compatible Models: This remote control is specifically designed for BLU:SENS TV models: RC041, RC034, RC036, RC042, RC044, RC054.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or press the latch to open it.

3. Insert two AAA batteries (not included) according to the polarity indicators (+ and -) inside the compartment.
4. Close the battery cover securely.





Figure 2: Back view of the remote control with battery compartment.

2. Initial Use

For the specified BLU:SENS TV models, the remote control is ready for use immediately after battery installation. No additional programming is required.

3. Learning Function (Advanced)

This remote control includes a learning function to copy commands from another remote. This is useful if you wish to consolidate functions from multiple remotes onto this one.

1. **Enter Learning Mode:** When the remote is in standby mode, press and hold the POWER+ button for approximately 5 seconds. The indicator light will flash five times and then remain lit, indicating learning mode.
2. **Select Key to Learn:** Press the key on the ALLIMITY remote that you wish to program. The indicator light will begin to blink.
3. **Align Remotes:** Align the infrared emitters of the ALLIMITY remote and your original remote control (distance should be approximately 2-3 cm).
4. **Transmit Command:** Press the corresponding button on your original remote control that you want to copy. The indicator light on the ALLIMITY remote will flash three times quickly, then remain lit, confirming successful learning.
5. **Repeat for More Keys:** Repeat steps 2-4 for any other keys you wish to program.
6. **Exit Learning Mode:** To exit the learning function, press the POWER+OK button simultaneously. The indicator light will flash three times, and then turn off.
7. **Reset Learning Function:** To delete all learned functions and restore the remote to its initial state, press the POWER+OK button for 3 seconds.

Operating Instructions

Once batteries are installed, point the remote control directly at your BLU:SENS TV. The remote operates using infrared (IR) signals.

- **Power Button:** Turns the TV on or off.
- **Number Buttons (0-9):** For direct channel selection.
- **Volume Up/Down (VOL+/VOL-):** Adjusts the audio volume.
- **Channel Up/Down (CH+/CH-):** Changes TV channels.
- **Mute:** Silences the TV audio.
- **Menu:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Input:** Selects input sources (HDMI, AV, etc.).
- **Exit:** Exits current menu or function.

- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** For media playback functions.
- **Color Buttons (Red, Green, Yellow, Blue):** For specific functions within certain TV menus or applications.
- Refer to your BLU:SENS TV's original manual for specific functions of advanced buttons like SUBTITLE, AUDIO, GOTO, REPEAT, CH/LIST, PLAYLIST, EGP, ECO, TV/TXT, HOLD, SIZE, SUBPAGE, and SLEEP.

Maintenance

Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the surface or internal components.

Battery Replacement

Replace batteries when the remote's performance degrades or if the indicator light (if present) signals low power. Always replace both batteries at the same time with new ones of the same type (AAA). Dispose of used batteries responsibly according to local regulations.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's IR receiver.
  - Make sure you are within the effective operating range (up to 10 meters).
- **Specific buttons not working:**
  - If you used the learning function, ensure the command was learned correctly. Try resetting the learning function (POWER+OK for 3 seconds) and re-learning the command if necessary.
  - For standard functions, ensure the remote is pointed directly at the TV.
- **Remote works intermittently:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure the IR emitter on the remote and the IR receiver on the TV are clean and unobstructed.

Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	MM-RC041-RC034
Compatible Devices	BLU:SENS TV models: RC041, RC034, RC036, RC042, RC044, RC054
Special Features	Ergonomic design, Learning function
Connector Type	Infrared
Batteries Required	Yes (2x AAA, not included)
Product Dimensions	Approximately 22 x 5.4 x 1 cm (8.66 x 2.13 x 0.4 inches)

Item Weight	59 g (approximately 2.1 oz)
Maximum Range	10 Meters





Figure 3: Dimensions of the ALLIMITY Remote Control.

Warranty and Support

Information regarding product warranty and customer support is not available in the provided product data. Please refer to the retailer or manufacturer's official website for details on warranty coverage and support options.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FNR2RTZL

More documents and user manuals: **https://manuals.plus/**