TOPZEE GLJP-1103

TOPZEE Electric Blanket User Manual

Model: GLJP-1103 | Brand: TOPZEE

1. Important Safety Instructions

Please read all instructions carefully before using the TOPZEE Electric Blanket. Retain this manual for future reference.

- **Electrical Safety:** This product is PSE certified, ensuring compliance with safety standards. Always use the blanket with a compatible power outlet.
- **Overheat Protection:** The blanket is equipped with a U-shaped NTC heating wire and a five-layer safety structure, including overheat protection, to prevent excessive temperatures.
- **Proper Placement:** Do not fold, bunch, or crease the blanket excessively while in use, as this can cause localized overheating.
- **Avoid Water:** Do not immerse the controller or power cord in water. Ensure the blanket is completely dry before connecting to power after washing.
- **Supervision:** This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- **Unplug When Not in Use:** Always unplug the blanket from the power outlet when not in use or before cleaning.
- **Storage:** Store the blanket in a cool, dry place when not in season.

2. Package Contents

Verify that all items are present in the package:

- TOPZEE Electric Blanket (x1)
- Controller (x1)
- Instruction Manual (x1)

3. Product Features

- **Luxurious Comfort:** Features a rabbit fur-like texture on the front and soft flannel on the back, offering a plush and smooth feel.
- **High-Density Material:** Constructed with 600g/m² high-density fabric, providing superior warmth retention.
- **Adjustable Heat:** 10 temperature settings ranging from 30°C to 48°C for personalized warmth.
- **Convenient Timer:** Integrated timer function allows setting operation for 1 to 9 hours, promoting energy saving and safe sleep.
- **Versatile Use:** Designed for use as both a heated throw blanket and an underblanket, effectively preventing cold from below.
- **Easy Maintenance:** Machine washable for hassle-free cleaning and hygiene.
- **Health & Hygiene:** Equipped with anti-bacterial, deodorizing, and mite-repellent treatments.
- **Even Heating:** U-shaped NTC heating wire ensures uniform heat distribution across the entire blanket.
- **Lightweight Design:** Easy to move and store.

4. Setup

1. **Unpack:** Carefully remove the electric blanket and controller from its packaging.
2. **Connect Controller:** Locate the connector on the blanket and firmly plug in the controller cable. Ensure a secure connection.
3. **Position the Blanket:** Place the electric blanket on your bed, sofa, or desired area. Ensure it lies flat without excessive folds or creases. If using as an underblanket, place it between your fitted sheet and mattress.
4. **Plug In:** Insert the power plug into a standard electrical outlet.



Figure 1: Connecting the controller and positioning the blanket.

5. Operating Instructions

1. **Power On/Off:** Press the power button on the controller to turn the blanket on or off.
2. **Adjust Temperature:** Use the temperature control buttons (usually '+' and '-') to select your desired heat level from 1 to 10. The display will show the current temperature setting.

3. **Set Timer:** Press the timer button to set the operating duration from 1 to 9 hours. The blanket will automatically turn off after the set time.



Figure 2: Controller with temperature and timer settings.

6. Maintenance

Cleaning

1. **Disconnect Power:** Always unplug the blanket from the power outlet and disconnect the controller before cleaning.
2. **Machine Washable:** The blanket is machine washable. Use a gentle cycle with cold water. Do not bleach or iron.
3. **Drying:** Tumble dry on low heat or line dry. Ensure the blanket is completely dry before reconnecting the controller and plugging it back in.



Figure 3: Proper drying of the electric blanket.

Storage

When not in use, ensure the blanket is clean and completely dry. Fold it neatly and store it in a cool, dry place away from direct sunlight and moisture. Do not place heavy objects on top of the folded blanket.

7. Troubleshooting

Problem	Possible Cause	Solution
Blanket does not heat up.	Not plugged in correctly, controller not connected, power outage, timer expired.	Check power connection, ensure controller is firmly attached, verify power supply, reset timer.
Blanket is too hot or not warm enough.	Temperature setting is incorrect.	Adjust the temperature setting on the controller to your preference.
Controller display is not working.	Power issue, controller malfunction.	Ensure power is connected. If problem persists, contact customer support.

8. Specifications

- **Model:** GLJP-1103
- **Brand:** TOPZEE
- **Dimensions:** 188 x 130 cm (approx. 74 x 51 inches)
- **Material:** Rabbit Fur-like (front), Flannel (back)
- **Color:** Khaki
- **Product Weight:** 2 kg (approx. 4.4 lbs)
- **Temperature Settings:** 10 levels (30°C - 48°C)
- **Timer Settings:** 1-9 hours
- **Safety Features:** Overheat Protection, U-shaped NTC Heating Wire, PSE Certified
- **Care Instructions:** Machine Washable (gentle cycle)

9. Warranty and Support

This TOPZEE Electric Blanket comes with a**1-year warranty** from the date of purchase.
If you encounter any product defects, have questions, or require assistance, please do not hesitate to contact our customer support team. Provide your model number (GLJP-1103) and purchase details for faster service.
Contact Information: Please refer to your purchase platform or the TOPZEE official website for the most up-to-date customer support contact details.

© 2026 TOPZEE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question