Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mattel JDL58

Mattel Disney Elsa Singing Doll JDL58 Instruction Manual

Model: JDL58

Introduction

Thank you for purchasing the Mattel Disney Elsa Singing Doll. This doll is inspired by the beloved character Elsa from Disney's Frozen and features her iconic outfit and the ability to sing a 30-second clip of "Let It Go" in multiple languages. This manual provides important information for the safe and proper use of your doll.

Safety Information

WARNING: Not suitable for children under 36 months. Contains small parts.
WARNING: Button cell batteries are dangerous. Button cell batteries can cause severe injuries if swallowed or placed inside any part of the body.

- Keep new and used batteries out of reach of children.
- Dispose of used batteries immediately.
- If you suspect that one or more batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.

Always supervise children during play. Ensure all packaging materials are removed before giving the toy to a child.

Package Contents

- 1 x Disney Elsa Singing Doll (Model JDL58)

The doll comes with its iconic dress and removable shoes. Batteries are included for the singing function.





Image: Elsa doll in its retail packaging, highlighting the 'Try Me!' feature and language options.

Setup

1. **Unpackaging:** Carefully remove the Elsa doll from its packaging. Ensure all ties and plastic fasteners are removed.
2. **Initial Check:** Verify that the doll's dress and shoes are properly attached.
3. **Battery Activation:** The doll comes with demonstration batteries. If the singing function does not work or is weak, replace the batteries as described in the Maintenance section.





Image: A young child smiling while playing with the Elsa singing doll.

Operating Instructions

Singing Function

1. Locate the button on the upper part of Elsa's bodice.
2. Press the button firmly to activate the singing function. The doll will sing a 30-second excerpt of "Let It Go."



Image: A hand pressing the button on Elsa's chest to activate the singing feature.

Language Selection

The doll can sing in English, German, Italian, and French. To change the language:

1. Locate the small hole on the back of the doll.
2. Insert a paperclip into this hole.
3. Press gently to cycle through the available languages until your preferred language is selected.



Image: Close-up view of Elsa's bodice, showing the button for singing and the texture of her dress.



Image: Close-up of Elsa's face and her signature braided blonde hair.

Maintenance

Cleaning

- Wipe the doll with a damp cloth to clean. Do not immerse the doll in water.

- Avoid using harsh chemicals or abrasive cleaners.

Battery Replacement

The doll requires 3 LR44 button cell batteries. To replace:

1. Locate the battery compartment on the back of the doll.
2. Using a small screwdriver, open the battery compartment.
3. Remove the old batteries and insert 3 new LR44 batteries, ensuring correct polarity (+/-).
4. Securely close the battery compartment with the screw.
5. Dispose of old batteries responsibly.

Troubleshooting

- **Doll does not sing:**
  - Ensure the button on the bodice is pressed firmly.
  - Check and replace batteries if necessary.
- **Sound is distorted or low:**
  - Replace batteries with fresh ones.
- **Cannot change language:**
  - Ensure the paperclip is inserted correctly into the small hole on the back and pressed gently.

Specifications

Brand	Mattel
Model Number	JDL58
GTIN (UPC)	194735286898
Material	Plastic (exterior), Fabric (interior)
Dimensions (L x W x H)	50 x 80 x 300 millimeters
Item Weight	291 Grams
Recommended Minimum Age	36 Months
Recommended Maximum Age	108 Months
Batteries Required	Yes, 3 x LR44
Special Features	Sings in multiple languages

Warranty and Support

Manufacturer's Warranty

This product comes with a 2-year manufacturer's warranty.

Contact Information

For customer support or warranty inquiries, please contact Mattel Europa B.V. at:

- **Address:** Gondel 1, Amstelveen 1186 MJ, Netherlands
- **Website:** service.mattel.com

© 2026 Mattel. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FNWZV7J6

More documents and user manuals: **https://manuals.plus/**