GE 7.5-ft Pre-lit LED Flocked Candlewood Pine Artificial Christmas Tree

GE 7.5-ft Pre-lit LED Flocked Candlewood Pine Artificial Christmas Tree User Manual

Model: 7.5-ft Pre-lit LED Flocked Candlewood Pine Artificial Christmas Tree

Introduction

Thank you for purchasing the GE 7.5-ft Pre-lit LED Flocked Candlewood Pine Artificial Christmas Tree. This manual provides important information regarding the safe assembly, operation, maintenance, and troubleshooting of your new Christmas tree. Please read these instructions carefully before assembly and retain for future reference.

Important Safety Information

- **Indoor Use Only:** This product is designed for indoor use only. Do not use outdoors or in wet conditions.
- **Electrical Safety:** Ensure the power outlet used is appropriate for the tree's electrical requirements. Do not overload electrical circuits.
- **Flammable Materials:** Keep the tree away from open flames, heaters, and other heat sources. The tree features flame retardant needles, but is not fireproof.
- **Assembly:** Assemble the tree according to the instructions provided. Ensure all sections are securely connected before plugging in.
- **Children and Pets:** Keep small children and pets away from the tree during assembly and operation to prevent accidents.
- **Damage:** Do not operate the tree if the power cord, lights, or any other part is damaged. Contact customer support for assistance.

Package Contents

Before assembly, ensure all parts are present:

- Tree Sections (typically 3 sections for a 7.5-ft tree)
- Metal Tree Stand

- Foot Pedal Switch
- Remote Control (with battery)
- Tree Top Connector
- Instruction Manual (this document)



Image: Overview of tree features including tree top connector, natural tips, lighting effects, dual color, and Easy Light Technology.

Assembly Instructions

1. **Assemble the Tree Stand:** Open the metal tree stand and secure it on a flat, stable surface. Tighten the eyebolt(s) to prepare for the tree pole.
2. **Insert Bottom Section:** Carefully insert the bottom section of the tree into the assembled stand. Tighten the eyebolt(s) on the stand to secure the tree pole.
3. **Connect Middle Section:** Insert the middle section of the tree into the top of the bottom section. The "Easy Light Technology" will automatically connect the lights between sections.
4. **Connect Top Section:** Insert the top section of the tree into the top of the middle section. Ensure all sections are firmly seated.
5. **Shape the Branches:** Gently spread out the branches, starting from the bottom section and working your way up. Fluff the individual branch tips to give the tree a full, natural appearance.
6. **Connect Power:** Plug the tree's power cord into the foot pedal switch, then plug the foot pedal into a standard electrical outlet.
7. **Tree Top Connector:** The tree includes an AC tree top connector for adding a lighted tree topper (sold separately). This connector is located at the top of the tree's central pole.



Image: The GE 7.5-ft Pre-lit LED Flocked Candlewood Pine Artificial Christmas Tree fully assembled and lit in a room setting.

Operating Instructions

Your GE Christmas tree features 600 Dualcolor LED 7mm color changing lights, with 80 of these lights having a G50 cap. You can control the lights using the included foot pedal or remote control.

Using the Foot Pedal

- Press the foot pedal to cycle through the available light settings: Warm White, Multicolor, or various Light Show settings.
- The foot pedal provides a simple way to change the light display without needing the remote.

Using the Remote Control

The remote control offers more detailed control over the lighting functions.



Image: Close-up view of the remote control with buttons for color, brightness, and light modes, alongside the foot pedal and tree top connector.

- **ON/OFF:** Powers the lights on or off.
- **TIMER:** Activates the built-in timer function (e.g., 6 hours on, 18 hours off). Refer to the remote's specific instructions for timer settings.
- **Brightness +/-:** Adjusts the intensity of the lights.
- **Color +/-:** Cycles through different color options or light patterns.
- **Soft White:** Selects a warm white light setting.
- **Day Light:** Selects a brighter, cooler white light setting.
- **Bright White:** Selects a pure white light setting.
- **Twinkling:** Activates a twinkling light effect.
- **Fade/Flash:** Cycles through fade and flash light effects.
- **Nightlight:** Activates a low-intensity nightlight mode.



Image: Detailed view of the flocked branches and the multi-color LED lights, showcasing the G50 cap lights.

Care and Maintenance

- **Cleaning:** To clean the tree, unplug it from the power source. Gently wipe the branches and lights with a soft, dry cloth. Do not use liquids or abrasive cleaners.
- **Light Replacement:** The LED lights are designed for long life and are generally not user-replaceable. If a section of lights fails, check connections first.
- **Storage:** Before storing, ensure the tree is completely dry. Disassemble the tree in reverse order of assembly. Gently compress the branches. Store the tree and its components in a cool, dry place, preferably in its original packaging or a dedicated tree storage bag, away from direct sunlight and extreme temperatures.
- **Inspection:** Before each season's use, inspect the tree, power cord, and lights for any signs of damage or wear.

Troubleshooting

Problem	Possible Cause	Solution
Lights do not turn on.	Not plugged in. Loose connection between tree sections. Foot pedal or remote not functioning. Power outage.	Ensure the power cord is securely plugged into the foot pedal and the wall outlet. Check that all tree sections are fully seated and connected. The "Easy Light Technology" relies on proper connection. Check remote battery. Try using the foot pedal. Verify power to the outlet.
Some lights are off or flickering.	Loose bulb or connection. Damaged LED.	Gently check and reseat any loose bulbs or connections. If individual LEDs are damaged, contact customer support.
Remote control not working.	Dead battery. Obstruction between remote and receiver.	Replace the battery in the remote control. Ensure a clear line of sight between the remote and the tree's receiver (usually near the foot pedal or bottom section).

Specifications

Feature	Detail
Model Name	7.5-ft Pre-lit LED Flocked Candlewood Pine Artificial Christmas Tree
Height	7.5 feet (90 inches)
Diameter	56 inches
Light Type	Dualcolor LED 7mm (600 lights total, 80 with G50 cap)
Light Functions	Warm White, Multicolor, Light Show settings (controlled by foot pedal or remote)
Assembly	3-Piece Easy Assembly with Easy Light Technology
Branch Construction	Flocked branch needles, accented with pine cones
Stand	Metal Stand
Recommended Use	Indoor Only
Item Weight	55 Pounds
UPC	803993201054

Warranty and Customer Support

For warranty information, please refer to the documentation included with your purchase or visit the official GE Christmas tree product website. If you encounter any issues not covered in this manual or require further assistance, please contact GE customer support.

Note: Specific warranty terms and contact details may vary. Please consult your product packaging or the manufacturer's website for the most current information.

© 2023 GE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question