Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SAPPHERO SO2214-04

SAPPHERO Chronograph Watch Model SO2214-04 User Manual

Comprehensive instructions for your SAPPHERO Chronograph Watch.

Product Overview

The SAPPHERO Chronograph Watch Model SO2214-04 is a sophisticated timepiece designed for daily wear and various activities. It features a precise quartz movement, chronograph functions, a date display, and luminous hands for visibility in low light. Constructed with durable stainless steel and a comfortable leather strap, it offers 50 meters of water resistance.



Image: Front view of the SAPPHERO Chronograph Watch Model SO2214-04 with a black dial and brown leather strap.

Components and Controls

Familiarize yourself with the main components and controls of your SAPPHERO Chronograph Watch:

- **Crown:** Used for setting time and date.
- **Pushers (A & B):** Used to operate the chronograph functions.
- **Main Dial:** Displays hours, minutes, and seconds.
- **Sub-dials:**
  - Chronograph Seconds
  - Chronograph Minutes
  - 24-Hour Indicator
- **Date Window:** Displays the current date.
- **Luminous Hands and Markers:** Provide visibility in low light conditions.



Image: Diagram illustrating the watch controls, including the crown for time/date adjustment and pushers for chronograph functions.

Setup Instructions

Setting the Time

1. Pull the crown out to the **second click position** (farthest out).
2. Rotate the crown to adjust the hour and minute hands to the correct time. Ensure the 24-hour sub-dial also reflects the correct AM/PM.
3. Push the crown back in to the **normal position** to start the watch.

Setting the Date

1. Pull the crown out to the **first click position**.
2. Rotate the crown clockwise or counter-clockwise (depending on the model) to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this is when the date mechanism is engaged and could be damaged.
3. Once the correct date is displayed, push the crown back in to the **normal position**.

Operating the Chronograph

The chronograph function allows for precise timing of events.

1. **Start:** Press the **upper pusher (A)** to start the chronograph. The chronograph seconds hand and minute sub-dial will begin to move.
2. **Stop:** Press the **upper pusher (A)** again to stop the chronograph. Read the elapsed time from the chronograph sub-dials.
3. **Reset:** After stopping, press the **lower pusher (B)** to reset the chronograph hands to their zero positions.

For a visual guide on operating the watch, please refer to the video below:

Your browser does not support the video tag.

Video: A demonstration of the SAPPHERO watch, showcasing its design and features, including how to operate the chronograph.

Maintenance and Care

Water Resistance (5 ATM / 50 Meters)

Your SAPPHERO watch is water-resistant up to 50 meters (5 ATM), making it suitable for daily use, hand washing, and short periods of swimming. However, to ensure its longevity:

- Do not operate the crown or pushers while the watch is wet or submerged.
- Avoid prolonged exposure to water, such as showering, bathing, or diving, as hot water and steam can compromise the seals.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.



Image: Illustration highlighting the 50-meter water resistance feature of the watch.

Cleaning and Storage

- Wipe the watch case and strap with a soft, dry cloth regularly to remove dirt and moisture.
- For leather straps, avoid excessive moisture and direct sunlight to prevent damage and discoloration.
- Store your watch in a cool, dry place away from direct sunlight and extreme temperatures when not in use.

Battery Replacement

The watch is powered by an LR44 battery. When the watch stops or the second hand begins to skip, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

Troubleshooting

If you encounter any issues with your SAPPHERO watch, please refer to the following common troubleshooting steps:

- **Watch Not Running:**
  - Check if the crown is fully pushed in.
  - The battery may need replacement. Consult a professional watch technician.
- **Date Not Changing:**
  - Ensure the time is set correctly, especially the AM/PM cycle. The date typically changes around midnight.
  - Manually advance the date using the crown in the first click position.
- **Chronograph Hands Not Resetting to Zero:**
  - Ensure the chronograph is stopped before attempting to reset.
  - If hands are misaligned, some quartz chronographs allow for calibration. Refer to a professional watch

technician if this feature is not explicitly detailed in your watch's specific manual.

- **Water Inside Watch:**
  - Immediately take the watch to a professional watch repair shop to prevent further damage.

Specifications

Detailed specifications for the SAPPHERO Chronograph Watch Model SO2214-04:



Image: Visual representation of the watch dimensions and key specifications.

Feature	Detail
Model Number	SO2214-04
Movement Type	Quartz
Case Material	Stainless Steel

Feature	Detail
Case Diameter	42 Millimeters
Case Thickness	11 Millimeters
Band Material Type	Leather
Band Length	220 Millimeters
Water Resistance Depth	50 Meters (5 ATM)
Crystal Type	Hardlex Mineral Glass
Additional Features	Chronograph, Date Display, Luminous Hands
Battery Type	LR44 (included)
Item Weight	4.66 ounces

Warranty and Support

Your SAPPHERO Chronograph Watch comes with a warranty card. Please refer to the card for specific warranty terms and conditions. SAPPHERO is committed to providing satisfactory after-sales service.
If you encounter any issues or have questions regarding your watch, please contact SAPPHERO customer support through the retailer where you purchased the product or visit the official SAPPHERO website for contact information.
For general inquiries or assistance, please retain your purchase receipt and warranty card.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FP4ND9RL

More documents and user manuals: **https://manuals.plus/**