Snoonwee 42V Max Cordless Electric Chainsaw

Snoonwee 42V Max Cordless Electric Chainsaw User Manual

Model: 42V Max Cordless Electric Chainsaw

Introduction

Thank you for choosing the Snoonwee 42V Max Cordless Electric Chainsaw. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your chainsaw. Please read this manual thoroughly before first use and keep it for future reference. Proper understanding and adherence to these instructions will ensure optimal performance and extend the lifespan of your tool.

Important Safety Information

Operating a chainsaw can be dangerous if proper safety precautions are not followed. Always prioritize your safety and the safety of others. Failure to follow these instructions may result in serious injury or property damage.

General Safety Rules:

- **Read the Entire Manual:** Understand all instructions and warnings before operating the chainsaw.
- **Wear Personal Protective Equipment (PPE):** Always wear safety glasses or goggles, hearing protection, a hard hat, heavy-duty gloves, and sturdy footwear. Leg protection (chainsaw chaps) is highly recommended.
- **Maintain a Safe Work Area:** Keep bystanders, children, and pets at least 50 feet (15 meters) away from the work area. Clear the area of obstacles that could cause you to trip or lose balance.
- **Inspect Before Each Use:** Check the chainsaw for loose parts, damage, or wear. Ensure the chain is sharp and properly tensioned, and the oil reservoir is filled.
- **Proper Grip:** Always hold the chainsaw firmly with both hands, with your thumbs and fingers encircling the handles.
- **Avoid Kickback:** Be aware of the kickback danger zone at the tip of the guide bar. Never cut with the tip of the bar.
- **Battery Safety:** Use only the specified batteries and charger. Do not expose batteries to water, heat, or direct sunlight.
- **Electronic Chain Brake:** Familiarize yourself with the electronic chain brake and its rapid activation feature (0.1-second stopping force).

Setup and Assembly

1. Unpacking and Included Components:

Carefully remove all items from the packaging. Verify that all components are present:

- Cordless Chainsaw Unit
- 18-inch Guide Bar
- 16-inch Guide Bar
- Chainsaw Chain (for 18-inch bar)
- Chainsaw Chain (for 16-inch bar)
- Two 4.0Ah Batteries
- Battery Charger
- Guide Bar Cover
- Maintenance Kit
- Safety Gloves

2. Battery Charging and Installation:

Before first use, fully charge both 4.0Ah batteries using the provided charger. Insert the charged batteries into the chainsaw's battery compartments. Ensure they click securely into place. The chainsaw operates with a dual-battery series setup for optimal power.

3. Guide Bar and Chain Installation:

Choose either the 16-inch or 18-inch guide bar and corresponding chain based on your cutting needs. The 16-inch bar is suitable for nimble pruning, while the 18-inch bar is ideal for heavier trunks.

1. Ensure the chainsaw is off and batteries are removed.
2. Remove the side cover by loosening the retention knob.
3. Place the chain around the sprocket and guide bar, ensuring the cutting edges face the correct direction.
4. Fit the guide bar onto the chainsaw studs, aligning the chain with the drive sprocket.
5. Replace the side cover and hand-tighten the retention knob.



Image: Close-up view of the chainsaw chain and guide bar, highlighting the high-hardness chain. This illustrates the components involved in chain installation.

4. Tool-Free Chain Tension Adjustment:

The Snoonwee chainsaw features a tool-free chain tensioning system for quick adjustments.

1. With the side cover slightly loose, rotate the side-mounted dial to adjust chain tension.
2. Turn clockwise to tighten the chain, and counter-clockwise to loosen.
3. The chain is correctly tensioned when it can be pulled away from the guide bar by about 1/8 to 1/4 inch (3-6 mm) at the center, but still snaps back into place.
4. Once tensioned, fully tighten the side cover retention knob.



Image: A woman holding the Snoonwee chainsaw, demonstrating the tool-free chain tensioning dial. This shows how to quickly adjust chain tension without additional tools.



Image: A close-up of hands adjusting the tool-free chain tension dial on the chainsaw. This provides a detailed view of the adjustment mechanism.

5. Automatic Oiling System:

The chainsaw is equipped with an automatic oiler system to ensure continuous lubrication of the chain and guide bar during operation. This helps maintain cutting performance and extends component life.

1. Locate the oil inlet cap on the chainsaw body.
2. Unscrew the cap and fill the reservoir with appropriate bar and chain oil. Do not overfill.
3. Replace the cap securely.
4. Regularly check the oil level during operation and refill as needed.



Image: The Snoonwee chainsaw with a graphic highlighting the automatic lubrication system and oil inlet. This shows where to add bar and chain oil.

Operating Instructions

1. Starting the Chainsaw:

Always ensure you are wearing appropriate PPE before starting the chainsaw.

1. Ensure both batteries are fully charged and securely installed.
2. Engage the electronic chain brake by pushing the front hand guard forward until it clicks.
3. Press and hold the safety switch (dual-action lock) with one hand.
4. With the safety switch held, squeeze the trigger switch to start the motor.
5. Release the chain brake by pulling the front hand guard back towards the handle. The chain will begin to move.



Image: A person demonstrating the electric start and engaging the chain brake on the Snoonwee chainsaw. This illustrates the safety features and starting procedure.



Image: The chainsaw with the safety switch highlighted, indicating its role in preventing accidental activation. This emphasizes a key safety feature.

2. Cutting Techniques:

Always maintain a stable stance and firm grip. Let the chainsaw do the work; do not force it. The 16-inch bar is suitable for smaller branches and pruning, while the 18-inch bar is designed for felling larger timber.

- **Bucking:** Cutting a fallen log into shorter lengths. Ensure the log is stable and supported.
- **Limbing:** Removing branches from a fallen tree. Work from the base of the tree towards the top.
- **Felling:** Cutting down a standing tree. This is an advanced technique and should only be performed by experienced users after proper training. Always plan your escape route and ensure the area is clear.



Image: A person operating the Snoonwee chainsaw to cut through a large log, demonstrating its cutting efficiency. This shows the chainsaw in a typical use scenario.



Image: A collage showing the Snoonwee chainsaw being used in different scenarios, including backyard work, forestry, and storm cleanup. This highlights the tool's versatility.

3. Safety Features:

- **Electronic Chain Brake:** Provides rapid chain stopping force (less than 0.1 seconds) in case of kickback or emergency.
- **Dual-Action Lock:** Prevents accidental starting of the chainsaw, requiring both the safety switch and trigger to be engaged.



Image: The chainsaw with the instantaneous chain brake mechanism highlighted, showing its quick activation. This illustrates a critical safety feature.

4. Official Product Video:

Your browser does not support the video tag.

Video: An official product video demonstrating the Snoonwee 2100W Battery Powered Chainsaw in operation. This video provides a visual guide to the chainsaw's use and capabilities.

Maintenance

Regular maintenance ensures the longevity and safe operation of your Snoonwee chainsaw.

1. Chain Sharpening:

A sharp chain is crucial for efficient and safe cutting. Sharpen the chain regularly or replace it when dull. Refer to the maintenance kit instructions for proper sharpening techniques.

2. Guide Bar Maintenance:

Clean the guide bar groove regularly to remove sawdust and debris. Flip the guide bar periodically to ensure even wear.

3. Cleaning:

After each use, remove the batteries and clean the chainsaw thoroughly. Use a brush or compressed air to remove sawdust, chips, and debris from the motor housing, chain, and guide bar area. Do not use water to clean the electrical components.

4. Battery Care:

Store batteries in a cool, dry place away from direct sunlight. Do not store fully discharged batteries for extended periods. Charge them periodically if not in use.

Troubleshooting

This section addresses common issues you might encounter with your chainsaw.

Problem	Possible Cause	Solution
Chainsaw does not start	Batteries not charged or improperly installed; Safety switch not engaged; Chain brake engaged.	Ensure batteries are charged and correctly inserted. Press the safety switch before squeezing the trigger. Disengage the chain brake.
Chain does not move	Chain brake engaged; Chain too tight; Obstruction.	Disengage the chain brake. Adjust chain tension. Check for and remove any obstructions.
Poor cutting performance	Dull chain; Incorrect chain tension; Insufficient oil.	Sharpen or replace the chain. Adjust chain tension. Refill the bar and chain oil reservoir.
Chainsaw overheats	Overuse; Blocked ventilation; Dull chain.	Allow the chainsaw to cool down. Clean ventilation slots. Sharpen or replace the chain.

Specifications

Detailed technical specifications for the Snoonwee 42V Max Cordless Electric Chainsaw.

Feature	Specification
Brand	Snoonwee
Power Source	Battery Powered (42V Max)
Engine Type	Brushless Motor
Output Power	1300W-2100W
Rotational Speed	25000 RPM
Horsepower	2.5 Horsepower
Guide Bar Lengths	16 Inches and 18 Inches (Interchangeable)
Chain Speed	11.5 Meters Per Second (38.2 FT/S)
Chain Pitch	0.325 Inches
Chain Gauge	0.058 Inches
Drive Links	72DL
Item Weight	12.5 Pounds (approx. 10.2 lbs without batteries)
Product Dimensions (L x W x H)	24"L x 8"W x 10"H
Included Components	2 Batteries, Cordless Chainsaw, Guide Bar Cover, Maintenance Kit, Safety Gloves



Image: A detailed diagram illustrating the parts and key specifications of the Snoonwee 42V Electric Chainsaw. This provides a visual overview of the tool's components and technical data.

Warranty and Support

Your Snoonwee 42V Max Cordless Electric Chainsaw is covered by a **2-Year Manufacturer Warranty**. This warranty covers

defects in materials and workmanship under normal use.
For warranty claims, technical support, or inquiries regarding replacement parts, please contact Snoonwee customer service.
Keep your purchase receipt as proof of purchase.
For additional support and product information, you may visit the Snoonwee Store on Amazon.

© 2026 Snoonwee. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where can I get replacement chains for the Snoonwee 42V Max Cordless Electric Chainsaw?

To obtain replacement chains for your Snoonwee 42V Max Cordless Electric Chainsaw, you should look for chains that match the following specifications provided in the manual:Chain Pitch: 0.325 InchesChain Gauge: 0.058 InchesDrive Links: 72DLLengths:...

Read full answer