PINDOWS PDS-8021

PINDOWS M8021n5 Digital Sport Watch User Manual

Model: PDS-8021

Introduction

Thank you for choosing the PINDOWS M8021n5 Digital Sport Watch. This manual provides essential information for the proper setup, operation, and maintenance of your watch. Please read it carefully to ensure optimal performance and longevity of your device.



Image: PINDOWS M8021n5 Digital Sport Watch in Transparent Blue. This image shows the overall design of the watch, featuring a clear transparent case and a digital display.

Product Overview

The PINDOWS M8021n5 Digital Sport Watch features a clear display and multiple buttons for various functions. Familiarize yourself with the button layout:



Image: Diagram illustrating the button functions of the PINDOWS Digital Sport Watch. The buttons are labeled as LIGHT (top left), MODE (bottom left), START/PAUSE (top right), and ADJUSTMENT/RESET (bottom right).

- **LIGHT Button (Top Left):** Activates the LED backlight.
- **MODE Button (Bottom Left):** Cycles through different modes (Time, Stopwatch, Alarm, Dual Time).
- **START/PAUSE Button (Top Right):** Used to start/stop functions in Stopwatch mode, and to adjust values during setting.
- **ADJUSTMENT/RESET Button (Bottom Right):** Used to reset functions in Stopwatch mode, and to select items for adjustment during setting.

Setup

Initial Power On

Your watch is typically ready for use upon arrival. If the display is off, check for a plastic tab under the crown (if applicable) or ensure the battery is active. The watch is powered by a long-lasting battery.

Setting Time and Date

1. From the Timekeeping mode, press the **MODE** button repeatedly until the seconds begin to flash, indicating time setting mode.
2. Press the **ADJUSTMENT/RESET** button to cycle through the settings: Seconds → Hour → Minute → Month → Date → Day of Week.
3. While the desired value is flashing, use the **START/PAUSE** button to increase the value. Hold the button to rapidly advance the numbers.
4. Once all settings are correct, press the **MODE** button to exit the setting mode.

12/24 Hour Format

In Timekeeping mode, press the **START/PAUSE** button to toggle between 12-hour and 24-hour (military) time formats. An 'A' or 'P' indicator will appear for AM/PM in 12-hour format.

Operating Modes

Timekeeping Mode

This is the default mode, displaying the current time, date, and day of the week.

Stopwatch Mode

1. Press the **MODE** button until 'ST' or 'STOP' appears on the display.
2. Press the **START/PAUSE** button to start the stopwatch.
3. Press the **START/PAUSE** button again to pause the stopwatch.
4. Press the **ADJUSTMENT/RESET** button to reset the stopwatch to zero.

Alarm Mode

1. Press the **MODE** button until 'AL' or 'ALARM' appears on the display.
2. Press the **ADJUSTMENT/RESET** button to select the hour or minute for setting.
3. Use the **START/PAUSE** button to adjust the flashing hour or minute.
4. Press the **MODE** button to exit alarm setting.
5. To turn the alarm ON/OFF, press the **START/PAUSE** button while in Alarm mode. An alarm icon will appear when activated.

Dual Time Mode

This mode allows you to keep track of a second time zone.

1. Press the **MODE** button until 'DT' or 'DUAL TIME' appears on the display.
2. Press the **ADJUSTMENT/RESET** button to select the hour or minute for setting.
3. Use the **START/PAUSE** button to adjust the flashing hour or minute.
4. Press the **MODE** button to exit dual time setting.

LED Backlight

Press the **LIGHT** button (top left) to illuminate the display for a few seconds. The high-brightness LED ensures clear visibility in low-light conditions.



Image: The PINDOWS Digital Sport Watch display illuminated by its bright green LED backlight in a dark environment, showing the time and date clearly.

Hourly Chime

To activate or deactivate the hourly chime, press the **ADJUSTMENT/RESET** button while in Timekeeping mode. A chime icon will appear when activated.

Water Resistance Guidelines

Your PINDOWS M8021n5 watch is rated 5ATM (50 meters) water resistant. This means it is suitable for:

- Splashes
- Rain
- Swimming in shallow water
- Washing hands
- Sweating

Important Cautions:

- **DO NOT** press any buttons underwater.
- **NOT** suitable for hot showers, baths, diving, or snorkeling. Exposure to hot water or steam can compromise the watch's seals.
- Avoid exposing the watch to strong water currents or high-pressure water.



Image: The PINDOWS Digital Sport Watch partially submerged in splashing water, illustrating its 5ATM water resistance for daily activities like hand washing or light swimming.

Maintenance

- **Cleaning:** Wipe the watch case and band regularly with a soft, dry cloth. For stubborn dirt, use a slightly damp cloth and mild soap, then rinse and dry thoroughly.
- **Avoid Chemicals:** Do not expose the watch to strong chemicals, solvents, or detergents, as these can damage the case, band, or seals.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) for prolonged periods, as this can affect battery life and watch accuracy.
- **Impact:** While durable, avoid strong impacts or dropping the watch to prevent damage to the internal components or mineral glass.
- **Battery Replacement:** The watch is equipped with a long-lasting battery. When replacement is eventually needed, it is recommended to have it done by a professional watch repair service to ensure water resistance is maintained.

Troubleshooting

- **Watch not displaying time:** Check if the battery is active. If the display is blank, the battery may need replacement.
- **Time is incorrect:** Follow the 'Setting Time and Date' instructions in the Setup section. Ensure you are adjusting the correct values (hour, minute, AM/PM).
- **Cannot switch between 12/24-hour format:** Ensure you are in Timekeeping mode and pressing the **START/PAUSE** button. If the watch is stuck in one format, try resetting the time.
- **Alarm goes off constantly or cannot be set:** Ensure you are correctly setting and activating/deactivating the alarm as per the 'Alarm Mode' instructions. If issues persist, try resetting the watch by holding all four buttons simultaneously for a few seconds (if applicable, consult manufacturer for specific reset procedure).
- **LED backlight not working:** Check if the battery is low. If other functions work but the light does not, contact support.
- **Water ingress:** If water appears inside the watch, stop using it immediately and seek professional repair. This may indicate a compromised seal.

Specifications



Image: Technical diagram showing the dimensions and key material specifications of the PINDOWS Digital Sport Watch, including case diameter, thickness, band width, and length.

Model Name	PDS-8021

Display Type	Digital
Movement Type	Japanese Quartz
Water Resistance	5ATM (50 Meters)
Case Material	Acrylonitrile Butadiene Styrene (ABS)
Band Material	Silicone
Crystal Type	Mineral Glass
Case Diameter	42 mm
Case Thickness	13 mm
Band Width	22 mm
Band Length	142 mm - 190 mm (5.6 - 7.4 inches)
Weight	50 g
Functions	Time, Date, Day, Stopwatch, Alarm, Dual Time, Hourly Chime, LED Backlight

Warranty and Support

Warranty Information

Your PINDOWS M8021n5 Digital Sport Watch is covered by a **12-month manufacturer's warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage resulting from misuse, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For any questions, concerns, or warranty claims regarding your watch, please contact PINDOWS customer service. We are committed to providing attentive service and support to ensure your satisfaction.
Please refer to your purchase documentation or the retailer's website for specific contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question