Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vonesse V3048A

Vonesse Office Chair V3048A User Manual

Model: V3048A

1. Introduction

Thank you for choosing the Vonesse Office Chair V3048A. This chair is designed to provide ergonomic support and comfort for extended periods of sitting, whether for office work or gaming. It features multiple adjustable functions, including reclining, height adjustment, and adjustable armrests, along with a retractable footrest and lumbar support. Please read this manual carefully before assembly and use to ensure proper function and longevity of your chair.



Image 1.1: Vonesse Office Chair V3048A, Black PU Leather.

2. Safety Information

- Ensure all components are securely fastened before use.
- Do not stand on the chair.
- Do not use the chair if any parts are damaged or missing.
- Keep children away from moving parts during adjustment.
- Maximum weight recommendation: 300 pounds (136 kg).

3. Package Contents

Verify that all parts are present before beginning assembly:

- Adjustable Armrests

- Retractable Footrest
- Double-layer Backrest
- Lumbar Support Pillow
- Pocket Spring Cushion Seat
- Power Gas Lift
- Star Base with Wheels
- Assembly Tools and Hardware (including extra screws)

4. Setup and Assembly

The Vonesse Office Chair V3048A comes with all necessary tools and step-by-step instructions for assembly. It is recommended to assemble the chair on a soft, clean surface to prevent damage. Follow the included guide for detailed steps.

Your browser does not support the video tag.

Video 4.1: Official Vonesse Office Chair overview and assembly demonstration.



Image 4.2: Chair dimensions for reference during assembly and placement.

5. Operating Instructions

5.1. Adjusting Chair Height

To adjust the seat height, locate the lever on the right side beneath the seat. While seated, pull the lever up to lower the chair. To raise the chair, stand up slightly and pull the lever up. Release the lever at your desired height.

5.2. Reclining the Backrest

The backrest can recline between 90° and 145°. To recline, pull the lever on the left side beneath the seat upwards and lean back. Release the lever to lock the backrest at any desired angle.



Image 5.1: Illustration of reclining mechanism, seat height adjustment, and 360-degree swivel.

5.3. Adjusting Armrests

The padded armrests are height-adjustable. Locate the buttons or levers on the side of each armrest. Press or lift the mechanism and move the armrest up or down to your preferred height. Release to lock.



Image 5.2: Detail of height-adjustable armrests.

5.4. Using the Retractable Footrest

To extend the footrest, pull it out from underneath the seat. To retract, push it back in until it is fully stored.

5.5. Lumbar Support

The chair includes a separate lumbar support pillow for additional lower back comfort. Position it as needed for optimal support.



Image 5.3: Overview of ergonomic features including headrest, lumbar support, and footrest.

6. Maintenance

6.1. Cleaning

Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the PU leather or fabric. For specific stains, use a mild soap solution and test on an inconspicuous area first.

6.2. General Care

- Periodically check all screws and bolts to ensure they are tight.
- Avoid prolonged exposure to direct sunlight to prevent material degradation.
- Do not overload the chair beyond its maximum weight capacity.

7. Troubleshooting

7.1. Chair Does Not Adjust Height

Ensure the gas lift lever is fully engaged. If the issue persists, check for any obstructions or contact customer support.

7.2. Squeaking Noises

Check and tighten all assembly bolts. A small amount of lubricant can be applied to moving metal parts if necessary, avoiding contact with upholstery.

7.3. Instability

Verify that the star base is correctly assembled and all wheels are securely attached. Ensure the chair is on a flat, even surface.

8. Specifications

Feature	Detail
Brand	Vonesse
Model Name	V3048A
Color	Black
Material	Faux Leather, High-density Supportive Foam, Metal Frame
Product Dimensions (D x W x H)	19.7"D x 25.6"W x 48"H
Item Weight	44 pounds (20 kg)
Maximum Weight Recommendation	300 pounds (136 kg)
Reclining Angle	90° to 145°
Arm Style	Height Adjustable Armrests
Back Style	Double-layer Backrest
Included Components	Adjustable Armrests & Footrest, Double-layer Backrest, Lumbar Support, Pocket Spring Cushion, Power Gas Lift & Star Base with Wheels

9. Warranty and Support

Vonesse provides a 30-day replacement policy and a 1-year repair service for this product. For any questions, concerns, or to claim warranty service, please contact our customer service team. Our team is ready to offer efficient and timely after-sales support.
For further assistance, please visit the Vonesse Store on Amazon.

© 2026 Vonesse. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FPM5PF69

More documents and user manuals: **https://manuals.plus/**