Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Canon ELPH 360 HS

Canon PowerShot ELPH 360 HS Digital Camera User Manual

Model: ELPH 360 HS (7283C001)

Introduction

This manual provides essential instructions for the safe and effective use of your Canon PowerShot ELPH 360 HS digital camera. Please read this manual thoroughly before using the camera and keep it for future reference.

The PowerShot ELPH 360 HS is a compact digital camera designed for capturing high-quality photos and videos. It features a 12x optical zoom, a 20.2 Megapixel CMOS sensor, and a DIGIC 4+ Image Processor for detailed images even in low light. Built-in Wi-Fi and NFC enable easy sharing.



Figure 1: Front view of the Canon PowerShot ELPH 360 HS A Silver camera.

Setup

1. Unpacking

Verify that all items are present in the box:

- Canon PowerShot ELPH 360 HS Digital Camera
- Battery Pack
- Battery Charger
- Wrist Strap
- User Manual (this document)



Figure 2: Included accessories with the camera.

2. Charging the Battery

1. Insert the battery into the battery charger.
2. Plug the charger into a power outlet.
3. The charging indicator light will show the charging status. Charge until the light indicates a full charge.

Caution: Use only the specified battery charger.

3. Inserting the Battery and Memory Card

1. Open the battery/card compartment cover on the bottom of the camera.
2. Insert the charged battery with the correct orientation until it clicks into place.
3. Insert a compatible SD memory card into the card slot until it clicks.
4. Close the compartment cover securely.



Figure 3: Battery and memory card compartment.

4. Initial Power On and Settings

1. Press the **ON/OFF** button to power on the camera.
2. Follow the on-screen prompts to set the date, time, and language.



Figure 4: Top controls including the ON/OFF button.

Operating Instructions

1. Taking Photos

1. Turn on the camera by pressing the **ON/OFF** button.
2. Select your desired shooting mode using the mode dial or menu. The camera features **Hybrid Auto** mode, which records a short video before each photo.
3. Frame your shot using the 3.0-inch LCD screen.
4. Use the zoom lever to adjust the 12x optical zoom.
5. Press the shutter button halfway to focus, then press fully to take the picture.



Figure 5: Rear controls and LCD screen.

2. Recording Videos

1. With the camera powered on, press the dedicated **Movie Button** (red dot icon) to start recording.
2. Press the **Movie Button** again to stop recording.
3. Videos are recorded in 1080p Full HD resolution.

3. Using Wi-Fi and NFC

The camera features built-in Wi-Fi and NFC for easy transfer of images and videos to a smartphone or other compatible devices.

1. Install the Canon Camera Connect app on your smartphone.
2. On the camera, select the Wi-Fi function from the menu.
3. Follow the on-screen instructions to connect to your smartphone via Wi-Fi or NFC.
4. Once connected, you can browse, transfer, and share your photos and videos.

Maintenance

1. Cleaning the Camera

- Use a soft, lint-free cloth to clean the camera body.
- For the lens, use a lens brush or a blower to remove dust, then gently wipe with a lens cleaning cloth.
- Do not use organic solvents or strong chemicals.

2. Battery Care

- Store the battery in a cool, dry place when not in use.
- Avoid exposing the battery to extreme temperatures.
- Recharge the battery regularly, even if not used, to maintain its life.

3. Storage

When storing the camera for extended periods, remove the battery and memory card. Store the camera in a dry, well-ventilated area, away from direct sunlight and high humidity.

Troubleshooting

Problem	Solution
Camera does not power on.	Ensure the battery is fully charged and inserted correctly. Check if the battery contacts are clean.
Cannot take pictures.	Check if a memory card is inserted and has sufficient free space. Ensure the lens cap is removed.
Images are blurry.	Ensure the lens is clean. Hold the camera steady or use a tripod. Check focus settings.
Wi-Fi connection fails.	Ensure the Canon Camera Connect app is installed and updated. Restart both the camera and smartphone. Check Wi-Fi settings on both devices.
Battery drains quickly.	Reduce screen brightness. Turn off Wi-Fi/NFC when not in use. Limit continuous video recording.

Specifications

Feature	Detail
Model Name	Canon PowerShot ELPH 360 HS

Feature	Detail
Model Number	7283C001
Color	Silver
Photo Sensor Resolution	20.2 MP
Optical Zoom	12x
Image Stabilization	Optical
Video Resolution	1080p (Full HD)
Screen Size	3.0 inches LCD
Connectivity	Wi-Fi, NFC
Battery Type	Lithium Ion
Supported File Format	JPEG, MP4
UPC	013803387711

Warranty Information

This Canon PowerShot ELPH 360 HS camera comes with a **1 Year Manufacturer Warranty**. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the warranty card included with your product or visit the official Canon website.

Support

For further assistance, technical support, or to download the latest software and drivers, please visit the official Canon support website:
Canon USA Support
You can also find FAQs and community forums on the Canon website.

© 2023 Canon Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FPZQPFYM

More documents and user manuals: **https://manuals.plus/**