Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TESSAN Rectangle-2AC

TESSAN Remote Control Outlet Plug User Manual

Model: Rectangle-2AC

1. Introduction

Thank you for choosing the TESSAN Remote Control Outlet Plug. This device provides convenient wireless control over your indoor lights, lamps, fans, and other small home appliances. With two independent outlets and a remote control, you can manage your devices with ease. Please read this manual carefully before use to ensure proper operation and safety.

2. Safety Information

- Do not exceed the maximum load capacity of 1875W (15A) for the outlet. Overloading can cause overheating and fire hazards.
- For indoor use only. Do not expose to water, moisture, or extreme temperatures.
- Ensure the plug is fully inserted into the wall outlet.
- Keep out of reach of children.
- Do not disassemble or modify the device.
- If the device appears damaged, discontinue use immediately.

3. Package Contents

- 1 x TESSAN Remote Control Outlet Plug (Rectangle-2AC)
- 1 x Wireless Remote Control
- 1 x User Manual

4. Product Overview

The TESSAN Remote Control Outlet Plug features two AC outlets and a wireless remote for convenient operation. The compact design ensures it does not block adjacent outlets.



Image: TESSAN Remote Control Outlet Plug highlighting its key features.

Remote Control Layout

- **Buttons 1 (On/Off):** Controls the first outlet independently.
- **Buttons 2 (On/Off):** Controls the second outlet independently.
- **All On:** Turns both outlets ON simultaneously.
- **All Off:** Turns both outlets OFF simultaneously.



Image: Instructions for using the remote control buttons to operate connected devices.

5. Setup

The TESSAN Remote Control Outlet Plug is designed for plug-and-play operation, requiring no complex programming.

1. **Insert the Remote Battery:** Open the battery compartment on the back of the remote control and insert the included battery, ensuring correct polarity.
2. **Plug in the Outlet:** Insert the TESSAN Remote Control Outlet Plug into a standard 120V AC wall outlet.
3. **Connect Appliances:** Plug your desired indoor appliances (e.g., lamps, fans) into the two outlets on the TESSAN device.
4. **Initial Pairing (if needed):** The device is pre-paired. If re-pairing is necessary, long-press the program button on the outlet for 5 seconds until the blue light flashes. Then, press the corresponding 'On' button (1 or 2) on the remote to pair.



Image: The TESSAN outlet in use, demonstrating its simple plug-and-play setup.

6. Operating Instructions

Use the wireless remote control to operate your connected devices.

- To turn on/off the appliance connected to Outlet 1, press the '1' On or '1' Off button on the remote.
- To turn on/off the appliance connected to Outlet 2, press the '2' On or '2' Off button on the remote.
- To turn on both appliances simultaneously, press the 'All On' button.
- To turn off both appliances simultaneously, press the 'All Off' button.

The remote control has a range of up to 100 feet and can work through doors and walls, providing flexibility in placement.



Image: The remote control demonstrating its 100ft range capability.

7. Maintenance

- Clean the device with a dry, soft cloth. Do not use liquid cleaners or aerosols.
- Replace the remote control battery when the indicator light on the remote no longer illuminates or the range decreases significantly.
- Store the device in a cool, dry place when not in use for extended periods.

8. Troubleshooting

- **Device not responding to remote:**
  - Check if the remote control battery needs replacement.
  - Ensure the outlet is properly plugged into the wall.
  - Re-pair the remote with the outlet (refer to Section 5: Setup).

- **Appliance not turning on/off:**
  - Verify the appliance itself is functioning correctly by plugging it directly into a wall outlet.
  - Ensure the appliance's power switch is in the 'ON' position if it has one.
  - Check if the total wattage of connected devices exceeds 1875W.
- **Reduced remote range:**
  - Replace the remote control battery.
  - Minimize obstructions between the remote and the outlet.

9. Specifications

Brand	TESSAN
Model	Rectangle-2AC
Voltage	120 Volts (AC)
Max Power Rating	1875W (15A)
Material	Plastic, Rubber
Plug Type	Type A
Remote Range	Up to 100 ft (30 meters)
Certifications	CE, CSA, NEMA, UL, cUL, cULus



Image: Dimensions of the TESSAN outlet and remote, illustrating its space-saving design.

10. Official Product Video

Your browser does not support the video tag.

Video: An official product video from Tessan Direct demonstrating the TESSAN Remote Control Outlet Plug in use.

11. Warranty and Support

TESSAN products come with a standard manufacturer's warranty. For detailed warranty information, product support, or technical assistance, please visit the official TESSAN website or contact their customer service. Keep your purchase receipt for warranty claims.

TESSAN Store: Visit the TESSAN Store on Amazon

© 2026 TESSAN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FQJ91TFT

More documents and user manuals: **https://manuals.plus/**