Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bewinner Bewinner0su7cfnvgt

Bewinner Portable HiFi MP3 Player with Bluetooth

Model: Bewinner0su7cfnvgt

Introduction Package Contents Product Overview Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for choosing the Bewinner Portable HiFi MP3 Player. This device is designed to deliver high-resolution, lossless audio playback with the convenience of Bluetooth connectivity. Featuring a 2.4-inch HD display and intuitive controls, it supports a wide range of audio formats and offers versatile connection options, including DAC input. This manual provides essential information for setting up, operating, and maintaining your new music player.



The Bewinner MP3 Player is suitable for various activities, including social gatherings, daily commutes, cycling, and running.

2. Package Contents

Please check the package for the following items:

- 1 x Bewinner HiFi Music Player
- 1 x USB Type-C Cable
- 1 x User Manual



The Bewinner MP3 Player and its included USB Type-C charging cable.

3. Product Overview

The Bewinner MP3 Player features a compact design with a 2.4-inch HD display and a combination of physical buttons and a scroll wheel for easy navigation.

3.1 Front View and Controls

The front panel includes the display, navigation buttons, and a retro scroll wheel for intuitive control.



Front view of the player showing the 2.4-inch HD display and control buttons.



The retro scroll wheel design allows for quick song selection and menu navigation.

3.2 Side and Back Views

The device features a Type-C USB port for charging and data transfer, a headphone output, and a line-out port for versatile audio connections.



Front and back view of the player, highlighting its sleek design and ports.



The compact size of the Bewinner MP3 Player makes it ideal for portable use.

4. Setup

4.1 Charging the Device

Before first use, fully charge the player. Connect the provided USB Type-C cable to the device's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The battery indicator on the screen will show charging status.

4.2 Powering On/Off

- **To Power On:** Press and hold the power button until the screen lights up.

- **To Power Off:** Press and hold the power button until the power-off prompt appears, then confirm.

4.3 Initial Setup

Upon first power-on, you may be prompted to select your preferred language and other basic settings. Follow the on-screen instructions using the scroll wheel and buttons to navigate.

4.4 Transferring Music

Connect the player to your computer using the USB Type-C cable. The device will appear as a removable disk. You can then drag and drop your music files directly into the player's internal 16GB storage or onto an inserted microSD card (up to 256GB, not included).

5. Operating Instructions

5.1 Basic Navigation

Use the scroll wheel to browse through menus and lists. Press the center button of the scroll wheel to select an item. Use the dedicated back button to return to the previous screen.

5.2 Playing Music

Navigate to the 'Music' section, select a song, album, or artist, and press the play button. The player supports a wide range of lossless and compressed audio formats, including FLAC, APE, DFF, MP3, WAV, WMA, M4A, MP2, AAC, ALAC, OGG, AIFF, and native DSD (up to 128 bits / 5.6 MHz).

5.3 Bluetooth Connection

To connect to Bluetooth headphones or speakers:

1. Go to 'Settings' and select 'Bluetooth'.
2. Turn Bluetooth 'On'.
3. Put your Bluetooth device into pairing mode.
4. Select your device from the list of available devices on the player's screen to pair.

The player supports bidirectional lossless transfer using the APTX protocol, allowing it to stream music to wireless devices or function as a wireless receiver.



The player connected wirelessly to headphones for an immersive audio experience.

5.4 Equalizer Settings

Customize your audio experience by adjusting the equalizer settings. Navigate to the 'Equalizer' option in the music playback menu. You can choose from preset modes like Rock, Pop, Jazz, Classical, Techno, Soft, or create a custom profile.



The equalizer interface allows for fine-tuning audio output with various presets and custom adjustments.

5.5 Using as DAC (Digital-to-Analog Converter)

The Bewinner MP3 Player can serve as a digital source when connected to a USB amplifier with DAC input. Additionally, it can function as an external decoder amplifier when linked to a mobile phone or computer, enhancing their audio output quality.



The player can be integrated into a high-fidelity audio setup as a digital source.

6. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the player in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Charge it regularly, even if not in use for extended periods.
- **Water Exposure:** This device is not waterproof. Avoid exposure to water or high humidity.

7. Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the device for at least 30 minutes.
No sound from headphones.	Volume too low; headphones not properly connected; incorrect output selected.	Increase volume; ensure headphones are fully plugged in; check audio output settings.
Cannot transfer files to the device.	USB connection issue; device not recognized by computer.	Ensure the USB cable is securely connected; try a different USB port or cable; restart both devices.
Bluetooth connection fails.	Device not in pairing mode; too far from the player; interference.	Ensure both devices are in pairing mode; move closer to the player; restart Bluetooth on both devices.
Screen is unresponsive.	Software glitch.	Press and hold the power button for 10-15 seconds to force a restart.

8. Specifications

Product Type	HiFi Music Player
Material	Zinc Alloy
Battery	750mAh Lithium Polymer (integrated)
Dimensions (L x W x H)	Approx. 97 x 60.4 x 13.9 mm (3.8 x 2.4 x 0.5 inches)
Display	2.4-inch HD Screen
Bluetooth Version	5.3
Signal-to-Noise Ratio (SNR)	93dB ± 2dB
Internal Memory	16GB
Expandable Memory	Up to 256GB via SD card or USB OTG (card/cable not included)
Charging Port	Type-C USB2.0
Playback Time	Up to 10 hours (high-resolution music)
Supported Audio Formats	FLAC, APE, DFF, MP3, WAV, WMA, M4A, MP2, AAC, ALAC, OGG, AIFF, DSD (up to 128 bits / 5.6 MHz)





Detailed dimensions of the Bewinner Portable HiFi MP3 Player.

9. Warranty and Support

9.1 Manufacturer's Warranty

This Bewinner product comes with a**2-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your Bewinner Portable HiFi MP3 Player, please refer to the official Bewinner website or contact your retailer. Please have your model number (Bewinner0su7cfnvgt) and proof of purchase ready when seeking support.

© 2025 Bewinner. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FQXJTNR2

More documents and user manuals: **https://manuals.plus/**