Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KCLASO V10

KCLASO V10 Cordless Vacuum Cleaner Instruction Manual

1. Introduction

Thank you for choosing the KCLASO V10 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

The KCLASO V10 is a powerful 550W cordless stick vacuum cleaner designed for home use, featuring 45KPa suction power and up to 50 minutes of runtime. It includes a smart touchscreen, 3 power modes, and a rechargeable battery, making it suitable for various surfaces including pet hair on carpets and hard floors.



Figure 1: KCLASO V10 Cordless Vacuum Cleaner

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance:

- Read all instructions before using the appliance.
- Use only the original adapter marked "V10 VACUUM" for charging. Using a non-OEM adapter may cause damage.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust cup and filters in place.
- Turn off all controls before unplugging.
- Do not handle plug or appliance with wet hands.

- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Use extra care when cleaning on stairs.
- This vacuum cleaner is recommended for use on short pile carpet, hardwood floors, or tile floors.
- If the vacuum ceases operation, clear any debris from the floor brush and the air intake.

3. Package Contents

Verify that all components are present in the package:

- 550W Powerful Motor (Main Unit) x1
- 0.5L Dust Cup x1
- Telescopic Tube x1
- Floor Brush x1
- 2-in-1 Brush x1
- Crevice Tool x1
- Clean Hook x1
- Storage Mount x1
- Charging Adapter x1



Figure 2: Package Contents

4. Product Overview

The KCLASO V10 Cordless Vacuum Cleaner consists of several key components designed for efficient cleaning and ease of use. Familiarize yourself with each part before assembly and operation.

- **Main Unit:** Contains the 550W motor, dust cup, and intelligent touchscreen display.
- **Telescopic Tube:** Connects the main unit to the floor brush, allowing for adjustable length.
- **Floor Brush:** Equipped with LED lights and a V-shaped roller brush for effective cleaning on various floor types.
- **Detachable Battery Pack:** Provides power to the vacuum and can be removed for charging.
- **2-in-1 Brush:** A versatile attachment for cleaning upholstery and other surfaces.
- **Crevice Tool:** Ideal for reaching narrow spaces and corners.

5. Assembly

Follow these steps to assemble your KCLASO V10 Cordless Vacuum Cleaner:

1. Attach the telescopic tube to the main unit until it clicks into place.
2. Connect the floor brush to the other end of the telescopic tube, ensuring it is securely fastened.
3. Ensure the dust cup is properly aligned and attached to the main unit.
4. If using, attach the desired accessory (2-in-1 brush or crevice tool) directly to the main unit or the telescopic tube.

6. Charging

Before first use or after long-term storage, fully charge the battery. The battery pack is detachable for flexible charging options.

- **Battery Activation:** After receiving or long-term storage, the battery will have low power. Complete 2-3 cycles of fully charging and total depletion to activate and optimize working hours.
- **Charging Time:** A full charge typically takes 5 hours.
- **Charging Options:** You can charge the battery directly by plugging the adapter into the main unit, or by removing the battery pack and charging it separately. The included wall mount also allows for convenient charging while stored.
- **Battery Life:** Expect 40-50 minutes in Min Mode, 30-35 minutes in Mid Mode, and 20-25 minutes in Max Mode.



Figure 3: Detachable Battery Pack

7. Operating Instructions

7.1 Power Modes and Suction Control

The KCLASO V10 features an intelligent touchscreen display and 3 adjustable suction levels to suit different cleaning needs:

- **Min Mode:** For light cleaning and extended runtime.
- **Mid Mode:** For daily cleaning tasks.
- **Max Mode:** Delivers powerful 45KPa suction for deep cleaning on carpets and stubborn dirt.

Adjust suction levels using the sensitive touch sensor system on the display. The display also shows real-time remaining battery life and alerts for maintenance issues.



Figure 4: Intelligent Touchscreen Display

7.2 Floor Cleaning

The flexible and durable floor brush is designed for effective cleaning on various surfaces:

- **V-shaped Roller Brush:** Reduces hair tangling and is suitable for all floor types, including low-pile carpets, hard floors, and tiles.
- **LED Headlights:** Illuminate the cleaning path, making hidden dust visible under furniture and in dimly lit areas.
- **Flexible Swivel Head:** Rotates 180° sideways and 90° up and down, allowing easy maneuverability around obstacles and under furniture.



Figure 5: Flexible Floor Brush with LED Headlights

7.3 Using Attachments

The KCLASO V10 comes with versatile accessories for specialized cleaning tasks:

- **2-in-1 Brush:** Use for cleaning upholstery, sofas, mattresses, and curtains.
- **Crevice Tool:** Ideal for removing dust from corners, edges, and narrow gaps.



Figure 6: Versatile Accessories in Use

7.4 Product Video Overview

Watch this video for a comprehensive overview of the KCLASO V10 Cordless Vacuum Cleaner's features and operation.

Video 1: KCLASO V10 Self-Standing High Suction Cordless Vacuum Cleaner Overview

8. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

8.1 Dust Cup Cleaning

The dust cup has an easy one-touch dump design for hygienic waste disposal. Empty the dust cup when the garbage exceeds the MAX line to maintain suction level and runtime.

8.2 Filter Cleaning and Replacement

The vacuum features a fully sealed cyclone filtration system with a HEPA filter. For optimal performance, clean the HEPA filter every 2-3 weeks. Ensure proper alignment during assembly after cleaning. It is recommended to replace the HEPA filter every 2-3 months.



Figure 7: Multi-layer HEPA Filtration System

8.3 Brush Roller Cleaning

The innovative V-shaped roller brush is designed to reduce hair tangling. However, if frequently used as a pet hair vacuum, promptly remove any tangled pet hair from the roller brush and the air intake to prevent blockages and maintain performance.

9. Troubleshooting

If you encounter issues with your KCLASO V10 Cordless Vacuum Cleaner, refer to the following common solutions:

- **Loss of Suction:** Check if the dust cup is full and empty it if necessary. Inspect the filters for blockages and clean

them. Ensure the floor brush and air intake are free of debris or tangled hair.

- **Vacuum Not Operating:** Ensure the battery is charged. Verify that the original "V10 VACUUM" adapter is used for charging. Check for any blockages in the floor brush or air intake that might trigger the tangle protection mechanism.
- **Reduced Runtime:** Overfilled dust cup can reduce runtime. Ensure the battery is fully charged before use.



Figure 8: Tangle Protection Mechanism and Cleaning Steps

10. Specifications

Feature	Specification
Brand	KCLASO
Model Name	V10

Power Source	Battery Powered
Wattage	550 watts
Suction Power	45KPa
Number of Power Levels	3
Runtime	Up to 50 minutes
Dust Cup Capacity	0.5 Liters (1.4 Pounds)
Filter Type	HEPA Filter
Special Feature	Cordless, Self-Standing, Touch Screen, LED Lights
Surface Recommendation	All floors, Low-pile Carpet, Hard Floor, Hardwoods, Tile, Upholstery
Item Dimensions (L x W x H)	15"L x 12"W x 7"H
Manufacturer	Suzhou Jinwuyang Electrical Technology Co., Ltd

11. Warranty and Support

For warranty information, technical support, or to purchase replacement parts, please refer to the contact information provided with your product packaging or visit the official KCLASO website. KCLASO is committed to providing comprehensive after-sales support to ensure a positive customer experience.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FR2DL35W

More documents and user manuals: **https://manuals.plus/**