saschedross 24.8V Adapter for K80

saschedross 24.8V Adapter

User Manual for bedee K80 Electric Weed Wacker

Introduction

This manual provides essential instructions for the safe and effective use of your saschedross 24.8V Adapter. This power supply is specifically designed for charging the bedee K80 Electric Weed Wacker String Trimmer. Please read this manual thoroughly before use and retain it for future reference.

Setup

Follow these steps to properly set up your saschedross 24.8V Adapter:

1. **Unpack the Adapter:** Carefully remove the adapter from its packaging. Inspect it for any signs of damage.
2. **Identify Components:** The package includes the 24.8V AC adapter with an integrated power cord and a barrel connector.
3. **Connect to Power:** Plug the AC adapter's power plug into a standard 100-240VAC wall outlet.
4. **Connect to Device:** Insert the barrel connector end of the adapter cable into the charging port of your bedee K80 Electric Weed Wacker. Ensure a firm and secure connection.



The saschedross 24.8V Adapter features a 6.5-foot power cord, providing ample reach for connecting to power outlets and your device.

Operating Instructions

Once the adapter is properly connected, it will begin charging your bedee K80 Electric Weed Wacker. Observe the charging indicator on your bedee K80 device to monitor the charging status. Refer to your bedee K80 user manual for specific details regarding its charging indicators and recommended charging times.

- **Charging:** The adapter provides a stable 24.8V output suitable for the bedee K80.
- **Safety Features:** The adapter is equipped with over-current, over-voltage, and over-heat protection to ensure safe charging.
- **Disconnection:** Always disconnect the adapter from the device and then from the wall outlet once charging is complete or if the device is not in use.



The image shows the saschedross 24.8V Adapter being plugged into a device, demonstrating its ease of connection.

Maintenance

Proper maintenance ensures the longevity and safe operation of your adapter:

- **Cleaning:** Use a soft, dry cloth to clean the adapter. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and moisture when not in use. Avoid wrapping the cable too tightly around the adapter.
- **Inspection:** Periodically inspect the adapter and cable for any signs of damage, such as frayed wires or cracked casing. If damage is found, discontinue use immediately.

Troubleshooting

If you encounter issues with your adapter, try the following steps:

- **Device Not Charging:**
  - Ensure the adapter is securely plugged into both the wall outlet and the bedee K80.

- Verify that the wall outlet is functional by plugging in another device.
- Check the bedee K80's charging port for any obstructions or damage.

- **Adapter Overheating:**
  - Unplug the adapter immediately.
  - Ensure the adapter is used in a well-ventilated area.
  - If overheating persists, discontinue use.

If these steps do not resolve the issue, discontinue use and contact customer support.

Specifications

Feature	Detail
Brand	saschedross
Input Voltage	100-240VAC
Input Frequency	50-60Hz
Output Voltage	24.8V (for bedee K80)
Connector Type	BARREL
Cable Length	6.5 feet
Compatible Devices	BEDEE K80 WACKER
Protection Features	Over-current, Over-Voltage, Over-heat protection
Manufacturer	Shenzhen Waweis Technology Co., Ltd



Detailed view of the saschedross 24.8V Adapter, illustrating its compact dimensions for easy portability and use.

Warranty and Support

For information regarding warranty coverage or to obtain technical support for your saschedross 24.8V Adapter, please contact your original retailer or the manufacturer directly. Keep your purchase receipt as proof of purchase.

© 2024 saschedross. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question